




CONDENSING WALL-HUNG COMBINATION BOILER

Central Heating and Instantaneous Domestic Hot Water - Fanned Flue system

Installation and Operating Instructions



Centora green 18-24

G.C.N: 47-980-21

PLEASE LEAVE THESE INSTRUCTIONS
WITH THE END-USER



**CHAFFOTEAUX
& MAURY**

These instructions are suitable for 'CENTORA GREEN' boilers :

Do not forget the Log Book!

Chaffoteaux & Maury supports Benchmark, the heating industry code to ensure the correct installation, commissioning and servicing of domestic central heating systems.

To The End User

Make sure you have a completed Log Book for your boiler. This provides a record of the commissioning of your boiler.

It contains important information about your particular installation that may be required by service engineers. The Log Book will also provide contact details for the installer should you need guidance in the use of this appliance or if there are any problems.

As with a car, your boiler will work more reliably and efficiently if regularly serviced. We recommend an annual service check. The service history of the appliance will be recorded in the Log Book.

In the unlikely event of any problems with your boiler or system you should first contact your installer. If your installer cannot resolve the problem he should telephone our national service helpline.

A charge may be made if Chaffoteaux & Maury Service is called out to resolve a non-product related fault.

Your statutory rights are not affected.

TO CONTACT C&M SERVICE, PLEASE CALL THE NATIONAL WARRANTY HELPLINE ON:

0870 243 0224

To The Installer

As part of the commissioning of this appliance it is vital that the Log Book is completed and given to the End User. Please ensure that your customer is aware of the importance of keeping the Log Book safe as a record of the installation and the appliance service history.

Please ensure that your customer is aware of the correct operation of the system, boiler and controls.

CUSTOMER CARE

Chaffoteaux & Maury, as a leading manufacturer of domestic and commercial water heating appliances is committed to providing high quality products and a high quality after sales service. If it is necessary to contact an engineer, then telephone the national warranty helpline 0870 243 0224.

Advice on installation or servicing can also be obtained by contacting the C&M Services Department at Telford.

CUSTOMER SERVICES DEPARTMENT

Tel: 01952 222288

Fax: 01952 260915

GUARANTEE

The manufacturer's guarantee is for 12 months from the date of purchase. The guarantee is invalidated if the appliance is not installed in accordance with the recommendations made herein or in a manner not approved by the manufacturer. To assist us in providing you with an efficient after sales service, please return the guarantee registration card enclosed with the boiler without delay.

STATUTORY REQUIREMENTS

The installation of this appliance must be carried out by a CORGI Registered person or other competent person and in accordance with the requirements of the Gas Safety (Installation and Use) Regulations.

In addition, the installation must also comply with the current Water Regulations, Water Byelaws Building Regulations, IEE Wiring Regulations, Local Authority Building Standards (Scotland) Regulations and the Safety Document 635 The Electricity at work Regulation. The appliance named below does not contain any asbestos or asbestos products, or mercury derivatives. Additional CFC's have not been used in this product.

The appliance does not contain any potential hazard in relation to the COSHH regulations.

It should also be carried out in accordance with current editions of the following British Standards Codes of practice: BS 6891, BS 5440 parts 1 and 2, BS 5449 part 1, BS 7593, BS 6798, BS 5546, BS 4814, BS 7074 part 1 and 2, BS 7671 and BG DM2.

If there is a possibility of the incoming mains water pressure exceeding 10 bar then a suitable pressure limiting valve must be fitted where pressures exceed 6 bars a pressure limiting is preferred.

Precautions: During servicing, keep the dust generation to a minimum and avoid inhaling any dust and contact with the skin and eyes. Normal handling and use will not present any discomfort, although some people with a history of skin complaints may be susceptible to irritation. When disposing of the ceramic lining, ensure that it is securely wrapped and wash hands after contact.

CUSTOMER CARE

	Page
Guarantee	2
Statutory Requirements	2
Contents	3
INTRODUCTION	4
INSTALLATION INSTRUCTIONS	5
1 DESCRIPTION	5
2 DIMENSIONS	6
3 HYDRAULIC DATA	6
4 INSTALLATION REQUIREMENTS	7
Location	7
Flue	7
Ventilation	7
Gas Supply	7
Electrical Supply	7
Showers	7
Flushing and Water Treatment	7
System Controls	7
5 INSTALLING THE BOILER	8
Method of Positioning the Boiler On the Wall	8
Connecting the Boiler to the System	8
Safety Valve and Condensate Drains	8
Fitting the Horizontal Flue	8
6 ELECTRICAL CONNECTIONS	10
Making the Electrical Connections	10
7 COMMISSIONING AND TESTING	10
Pre-Commissioning	10
D.H.W.	10
Central Heating	10
Lighting the Boiler	10
By-pass and Pump	11
Post Commissioning	11
Handing Over to the End User	11
8 FITTING THE CASING	11
9 ADJUSTMENTS AND SETTINGS	12
10 INCORRECT OPERATION	17
11 GAS CONVERSION	17

USER INSTRUCTIONS

	Page
12- CONTROL PANEL	18
13- HOW TO USE	19
Switching On	19
Switching On the Central Heating	19
Switching On the Domestic Hot Water	19
Switching On the Domestic Hot Water and Central Heating Together	19
Stand-by Mode	20
Turn Off the Boiler	20
14 MAINTENANCE	20
15 GUARANTEE	20
16 PRACTICAL INFORMATION	20
17 GAS CONVERSION	21
18 INCORRECT OPERATION	21
19 TECHNICAL DATA	22

This instruction booklet is specifically designed for appliances installed in the United Kingdom

INTRODUCTION

The 'CENTORA GREEN' is a fully automatic, wall mounted, low water content condensing combination boiler. It is a room sealed, fan assisted, balanced flued appliance providing central heating and mains pressure domestic hot water on demand. It has electronic ignition and is suitable for all modern electrical control systems. The boiler is designed for sealed systems only. A circulating pump, expansion vessel, pressure gauge and safety valve are included within the boiler.

The standard horizontal flue kit is suitable for lengths 300 mm minimum to 600 mm maximum and includes an elbow adapter that can be rotated through 360°. The horizontal flue can be extended up to 3 metres using 1 metre flue extension kits, 45° and 90° flue bends are also available as accessories.

INSTALLATION INSTRUCTIONS

1

Description




Fig. 1

- 1 - Steel chassis complete with expansion vessel
- 2 - Sealed chamber
- 3 - Burner and heat exchanger assembly
- 4 - Air/gas connection
- 5 - 24 V modulating fan
- 6 - Gas valve
- 7 - Ignition electrode
- 8 - Ionisation probe
- 9 - Ignitor
- 10 - Combustion products manifold
- 11 - 24 V transformer
- 12 - Siphon trap
- 13 - Electrical box
- 14 - Pump
- 15 - Secondary heat exchanger
- 16 - Pressure gauge
- 17 - Three way valve
- 18 - Automatic air separator and automatic vent
- 19 - Central heating flow switch
- 20 - Domestic hot water flow switch
- 21 - Central heating control thermistor
- 22 - Hot water control thermistor
- 23 - Overheat sensor




Fig. 2

- 24 - Display
- 25 - Domestic Hot Water switch
- 26 - Green indicator – Domestic Hot Water mode ON
- 27 - D.H.W. temperature reducing key
- 28 - D.H.W. temperature increasing key D.H.W. mode indicator
- 29 - Central Heating switch
- 30 - Green indicator – Central Heating mode ON
- 31 - Central Heating temperature reducing key
- 32 - Central Heating temperature increasing key
- 33 - Green indicator – Power ON
- 34 - Orange indicator - Burner ON
- 35 - Red indicator - Lock out/flame failure
- 36 - Reset key




Fig 3

2



3

Pump head available



Pump head chart measured at the outlet of the boiler



The boiler comprises a double speed pump and an adjustable by-pass.

The chart (fig. 5) shows the pump head available relating to the flow rate. GVF means high speed by-pass closed, PVF means low speed by-pass closed, GVO means high speed by-pass fully open, PVO means low speed by-pass fully open.

For adjustment procedure, please refer to section 9.

The minimum flow rate to ensure the correct function of the pump, should be over 300 l/h (with all heating thermostatic valves fully closed)

Maximum water capacity of Central Heating system :

The expansion vessel is pre-charged to 0.7 bar (10 lb/in²).

The vessel is suitable for systems up to 145 litres capacity.

For systems of greater capacity an additional expansion vessel will be required. Refer to the chart below and BS 7074 pt 1 or BS 5449.

The minimum initial pressure of the system should be over 0.7 bar (1 to 1.5 bar is recommended).

Location

The boiler can be installed on any suitable internal wall. Provision must be made to allow the correct routing of the flue and siting of the terminal to allow the safe and efficient removal of the flue products. A compartment or cupboard may be used provided that it has been purpose-built or modified for the purpose. It is not necessary to provide permanent ventilation for cooling purposes. Detailed recommendations are given in BS 5440 pt 2. If it is proposed that it is installed in a timber framed building then reference must be made to British Gas Document DM2, or advice sought from CORGI.

Avoid installing the boiler where the air inlet can be polluted by chemical products such as chlorine (swimming pool aera), or ammonia (hair dresser), or alkaline products (launderette)

Flue

Detailed information on flue assembly is contained in the appropriate starter pack.

The boiler must be installed so that the flue terminal is exposed to the free passage of external air at all times. It must not be allowed to discharge into another room or space such as an outhouse or closed lean-to. The minimum acceptable clearances are shown below:

- A Directly below an opening, window, etc	300 mm
- B Above an opening, window, etc	300 mm
- C Horizontally to an opening, window, etc	300 mm
- D Below gutters, soils pipes or drain pipes	75 mm
- E Below eaves	200 mm
- F Below balconies or car port roof	200 mm
- G From a vertical drain pipe or soil pipe	150 mm
- H From an internal or external corner	300 mm
- I Above ground roof or balcony level	300 mm
- J From a surface facing the terminal	600 mm
- K From a terminal facing the terminal	1200 mm
- L From an opening in the car port into the dwelling	1200 mm
- M Vertically from a terminal on the same wall	1500 mm
- N Horizontally from a terminal on the same wall	300 mm
- Q Fixed by Ubbink Rolux 4 GM flue terminal	

It may be necessary to protect the terminal with a guard. Reference should be made to the Building Regulations for guidance. Suitable guards may be obtained from the following manufacturer:

Quinnel Barret & Quinnel Wireworks
Old Kent Road
London SE15 1NL
Tel: (020) 7639 1357

Ventilation

The room in which the boiler is installed does not require specific ventilation. **If it is installed in a cupboard or compartment permanent ventilation is not required for cooling purposes.**

Gas Supply

The gas installation and soundness testing must be in accordance with the requirements of BS 6891. The boiler requires a 22 mm supply. Ensure that the pipe size is adequate for demand including other gas appliances on the same supply.

Combustion system protection

The sulphur level contained in the gas should comply with the European Standards which are:

- maximum 150 mg/m³ for a short period in a year
- average level of 30 mg/m³ during one year

Electrical Supply

The appliance requires an earthed 230V - 50 Hz supply and must be in accordance with current I.E.E. Regulations. It must also be possible to be able to completely isolate the appliance electrically. Connection should be via a 3 Amp

fused double-pole isolating switch with a contact separation of at least 3 mm on both poles. Alternatively, a fused 3 Amp. 3 pin plug and unswitched socket may be used, provided it is not used in a room containing a bath or shower. It should only supply the appliance.

The boiler is suitable for sealed systems only. The maximum working pressure for the appliance is 10 bar. All fittings and pipework connected to the appliance should be of the same standard. If there is a possibility of the incoming mains pressure exceeding 10 bar, particularly at night, then a suitable pressure limiting valve must be fitted.

The boiler is designed to provide hot water on demand to multiple outlets within the property. If there is a requirement for greater demands, for example if the property has several bathrooms and cloakrooms, a vented or unvented hot water storage system may be used.

Showers

Any shower valves used with the appliance should be of a thermostatic or pressure balanced type. Refer to the shower manufacturer for performance guidance and suitability.

Flushing and Water Treatment

The performance of the appliance could be impaired by system debris or the effects of corrosion. The system must be flushed thoroughly to remove metal filings, solder, machining oils and other fluxes and greases before connecting the boiler. If it is an existing system, an appropriate flushing and descaling agent should be used. Refer to BS 7593 (1992) for guidance. For more information on the use of corrosion inhibitors, flushing and descaling agents, advice can be sought from the manufacturers of water treatment products such as:




Fig. 7

Betz Dearborn Ltd
Foundry Lane
Widnes
Cheshire
WA8 8UD
Tel: 0151 424 5351
Fernox Manufacturing
Britannica Works
Clavering
Essex
CB11 4QZ
Tel: 01799 550811

System Controls

The boiler is electrically controlled and is suitable for most modern electronic time and temperature controls. The addition of such external controls can be beneficial to the efficient operation of the system. The boiler connections for external controls are 24V and so only controls of 24V or that have voltage free contacts should be used.

Please check that you are familiar with the installation requirements before commencing work.(section 4)

The installation accessories described in the following list are included in the boiler packaging.

- Hanging bracket
- A paper template (showing the dimensions of the boiler with 5 mm side clearances, fitting instructions and commissioning instructions)
- Connection tails
- Screws and wall plugs
- Connection washers and filters
- Installation manual

Method of positioning the boiler on the wall.

The paper template can be used to ensure the correct positioning of kitchen cabinets etc. It also details the commissioning instructions.

The paper template has to be fixed to the wall and used to locate the position of the hanging bracket and the centre for the flue hole.

Drill and plug the wall and secure the hanging bracket using the screws provided. Remove the boiler from its packaging as shown in fig. 8 and unscrew the 4 screws **A** and remove the casing (Fig. 9).

Place the boiler on the wall on the hanging bracket (Fig. 11).

If required, there is space for all piping to pass behind the boiler. Using Fig. 11 for reference, connect the gas and water pipes and the valves to the base of the appliance using the tails provided. There is a 190 mm space between the valves and the wall to make these connections.

Connecting the boiler to the system

- Push in the tabs "**P**" (Fig. 13) on either side of the boiler and pivot the electrical box forward to gain access to the valve connections

- Remove the yellow caps and connect the boiler to the taps using the washers provided in the plastic bag.

4 x fibre washers for the C/H flow and return, hot water outlet and cold water inlet connections

1 x rubber washer "**R**" for gas connection.

Provision must be made to fill and recharge the system pressure. This can be achieved using a filling loop or other methods approved by the local water authority.

Before fitting the tails onto the connecting bracket, please check the correct location of the flow restrictor **L** (Fig.10) on the main inlet.

Safety valve and condensate drains

The pressure relief valve tube is clear silicone. It should terminate below the boiler over a tundish or 22 mm pipe (see I Fig. 4) which should in turn discharge safely outside the premises. Care should be taken that it does not terminate over an entrance or window or where a discharge of heated water could endanger occupants or passers by.

External termination via condensate siphon

The condensate drainage pipe should have a minimum diameter of 22 mm and the external pipe length should not be more than 3m. The external length should be kept as short as possible to minimize the effect of freezing.

Please refer to **BS 6798:2000**

The system should be carefully checked for leaks, as frequent refilling could cause premature system corrosion or unnecessary scaling of the heat exchanger. The pipe from the siphon 12 (Fig. 1) should be connected to a drain as described in the relevant British regulations.

Pay a special attention to not bend the condensate drain pipe as the flow will be interrupted. Please use exclusively drain pipe material compatible with condensate products. (refer to **BS 6798:2000**)

The condensate flow can reach 2 l/hr; because of the acidity of the condensate products (Approx. Ph2), take care before operation.

Fitting the Horizontal Flue

Attention ! Before starting the boiler, the siphon (12 Fig. 1) must be filled with water. Before fitting the flue terminal onto the boiler, please pour 1/4 litre of water into the exhaust pipe as shown in (Fig. 12).

The instructions for the vertical and biflux (twin pipe) flue options are included with the relevant adapter kits.

The standard flue supplied with the appliance is suitable for lengths from 300 mm minimum to 720 mm maximum.

This means for rear flueing, the standard kit will accommodate a maximum wall thickness of 600 mm, and for side flueing a maximum wall thickness of 587 mm. This takes into account the minimum appliance side clearances of 5 mm.

If the flue is a side exit installation, then calculate the position of the hole with a slope of 5 mm / metre towards the boiler from the terminal. The flue should rise up slightly to the terminal in order to allow the condensate back into the boiler.

Attention ! Use only a C&M condensation flue kit.




Fig. 8




Fig. 10




Fig. 9




Fig.11




Fig.12

Making the Electrical Connections

Lower the electrical box to gain access to the electrical connections. Push in the tabs **P** (Fig. 13) on either side of the boiler and pivot the box forward. Undo the two retaining screws **V**, remove the cover and remove the cable clamp. **C** (Fig. 14)

Connect the live and neutral wires to the multipin plug **J1** (Fig. 14) leaving sufficient earth wire to connect to the earthing point **T** (Fig. 14).

Note: The connections should be made so that should the lead be pulled from its anchorage, the current carrying wires become taut before the earth wire.

If using a room thermostat or other external control, they can be connected in place of the link **S** (Fig. 14) on the multipin Plug.

Note: Use only controls designed for voltage free switching or 24V supply. Do not connect to a 230V supply.

Connect the multipin plug into the socket on the printed circuit board. Secure the cable using the cable clamp and replace the cover. NB The room thermostat options setting can be made before replacing the electrical box cover **1** (Fig. 14).

All necessary settings for room thermostat operations are described in Section 9 ADJUSTMENTS AND SETTINGS.




Fig. 13




Fig. 14

Pre-commissioning

Ensure that the system has been adequately flushed.
Purge the gas supply of air and test for soundness.
Carry out final electrical tests to ensure the correct polarity and earthing continuity.

D.H.W.

Open the main cold feed valve **40** (Fig. 15).
Open all hot taps to purge the D.H.W. system.
Check for water soundness.
Check the flow rate at the bath tap is set correctly (see technical data).

Central Heating

Open the flow and return valves on the boiler **37** and **41** (Fig. 15)
Open the automatic air vent **18** (Fig. 2)
Fill the system and vent the radiators.
Set the system pressure and remove the filling loop.
Check for leaks.
Manually check the pump is free to turn.
Switch on the electrical supply.
Press the Central Heating switch **29** (Fig. 3) to switch on the heating mode. Press the '+' key **32** (Fig. 3) to set the heating temperature to

maximum.

Allow the pump to run for several minutes.

Isolate the electrical supply.

Drain the boiler and check the water filter for installation debris.

Replace the filter and recharge system.

Lighting the Boiler

Connect a gas pressure gauge to the test point **39** (Fig. 21).

Turn on the gas supply and boiler gas tap **39** (Fig. 21).

Ensure the electrical supply is on.

Ensure all external controls are calling for heat.

Press the Central Heating switch **29** (Fig. 3) to switch on the heating mode.

Press the '+' key **32** (Fig. 3) to set heating temperature to maximum.

The boiler will light. Allow the boiler to heat the system.

Check the inlet gas pressure (working pressure) while the boiler is operating in D.H.W. mode. (Refer to technical data).

Check the operation of the boiler controls and safety devices. (see the servicing leaflet for details). Set the by-pass (refer to the page 12).

Re-flush the system to remove any dissolved oils and fluxes.

Recharge system pressure and introduce any water treatment as required.

By-pass and Pump

The boiler is fitted with a pre-adjusted by-pass. Although adjustment is not normally necessary, the by-pass can be reset by turning screw **D** (Fig. 15) anticlockwise to open the by-pass using the chart below for guidance. If used on a system with thermostatic radiator valves, the flow rate with the thermostatic valves closed should be adjusted to at least 300 l/hr. The enclosed charts indicate the residual head of the pump available for the system. The pump fitted on the boiler is a double speed model. (GV = High speed and PV = low speed). The speed setting is described in Section 9. Speed selection is only available in C.H. mode.

Post Commissioning

Ensure the system pressure has been set correctly.
 Set all the parameters of the boilers as shown in Section 9 ADJUSTMENTS AND SETTINGS.
 Set the boiler thermostat and controls.
 Set the programmer to the requirements of the End User.
 Set the external controls.
 Ensure the Log Book is fully completed with your contact details and all the required details of the installation.

Handing Over to the Householder

Demonstrate the lighting and operation of the boiler.
 Demonstrate how to maintain the system pressure.
 Demonstrate the operation and setting of the built-in clock.
 Explain the benefits of annual maintenance by a competent person.
 Explain how to register the guarantee.
 Ensure the End User countersigns the Log Book to confirm that these demonstrations have been carried out and understood.




Fig. 15

Fitting the casing

Remove the protective film from the casing :

- Position the casing as shown fig. 17
- Slide down the casing and locate the casing holes on the plastic pins on top of the chassis
- Ensure the correct positioning of the casing onto the boiler
- Tighten the 4 screws located at the bottom as shown in Fig. 16.




Fig.16




Fig. 17

The boiler is delivered with pre-set values described in menus 3 and 4.

All settings can be changed by the installer or a qualified person. To gain access to the setting keys please, open the front door P. (Fig. 18)




Fig. 18

To gain access to the setting menus press both the \ominus and \oplus keys on the D.H.W. side for 5 seconds. (Fig. 18). Menu 1 is displayed.

Changing the menu :

Press the \oplus key (C.H. side) (Fig.18). The menu number is displayed for 3 seconds. Press the + key (C.H. side) again to show the next menu.

Changing section in a menu (available only for menus 3 and 4):

Press the \oplus or \ominus key (D.H.W. side) to change from one section to the next in a menu.

Note : When you arrive at the last section of a menu, pressing the \oplus key will change to the 1st section. When you are at the first section, pressing the \ominus key will change to the last section of the menu.

Setting a parameter in a section:

Press the \ominus key (C.H. side) to enter the modification mode. The 2nd and 3rd digits will flash. Press the \oplus or \ominus key (D.H.W. side) to select the correct value then press the \ominus key (C.H. side) to validate the modification and to exit the setting mode. The 2nd and 3rd digits will stop flashing.




















Recalling the basic configuration:








Select menu 3 or 4 then press the \oplus key (D.H.W. side) and the \oplus key (C.H. side) for more than 5 seconds. The digits will flash CM [7 7] for a while to indicate that the operation is completed.
















Erasing the default register :












Select menu 1 then press both the \oplus key (D.H.W. side) and the \oplus key (C.H. side) for more than 5 seconds. The digits will flash CM [7 7] for a while to indicate that the operation is completed.

Note : To exit the setting mode, leave the boiler for approx. 1 minute, the computer will then switch back to user mode.

ACTION	CONFIGURATION	DISPLAY																															
 	<p align="center">Menu - 1 - Default register Records the last 10 defaults</p> <table border="1"> <thead> <tr> <th>Section</th><th>Digit 1</th><th>Digit 2 and 3</th></tr> </thead> <tbody> <tr> <td>Last default occurred</td><td>0.</td><td>code from 01 to 99</td></tr> <tr> <td>Last but one default occurred</td><td>1.</td><td>code from 01 to 99</td></tr> <tr> <td>...</td><td>...</td><td>code from 01 to 99</td></tr> <tr> <td>Last default occurred before the previous one</td><td>9.</td><td>code from 01 to 99</td></tr> </tbody> </table> <p>Note -- is displayed if no default is recorded.</p>	Section	Digit 1	Digit 2 and 3	Last default occurred	0.	code from 01 to 99	Last but one default occurred	1.	code from 01 to 99	code from 01 to 99	Last default occurred before the previous one	9.	code from 01 to 99	   																
Section	Digit 1	Digit 2 and 3																															
Last default occurred	0.	code from 01 to 99																															
Last but one default occurred	1.	code from 01 to 99																															
...	...	code from 01 to 99																															
Last default occurred before the previous one	9.	code from 01 to 99																															
 	<p align="center">Menu - 2 - Boiler conditions Indicates the conditions or the configurations of the boiler</p> <table border="1"> <thead> <tr> <th>Section</th><th>Digit 1</th><th>Digit 2 and 3</th></tr> </thead> <tbody> <tr> <td>Software version of display P.C.B.</td><td>0.</td><td>10 to 99</td></tr> <tr> <td>Nominal Power of the boiler (type 18 or 24 kW)</td><td>1.</td><td>24</td></tr> <tr> <td>Flue type</td><td>2.</td><td>1 : FF variable speed</td></tr> <tr> <td rowspan="2">Room thermostat is calling for heat</td><td>3.</td><td>0 : no</td></tr> <tr> <td>3.</td><td>1 : yes</td></tr> <tr> <td rowspan="2">Theoretical position of the 3 way valve</td><td>4.</td><td>0 : D.H.W.</td></tr> <tr> <td>4.</td><td>1 : C.H.</td></tr> <tr> <td>DHW flow temperature in °C</td><td>5.</td><td>from 00 to 99</td></tr> <tr> <td>CH flow temperature in °C</td><td>7.</td><td>from 00 to 99</td></tr> <tr> <td>Software version of main P.C.B.</td><td>9.</td><td>10 to 99</td></tr> </tbody> </table>	Section	Digit 1	Digit 2 and 3	Software version of display P.C.B.	0.	10 to 99	Nominal Power of the boiler (type 18 or 24 kW)	1.	24	Flue type	2.	1 : FF variable speed	Room thermostat is calling for heat	3.	0 : no	3.	1 : yes	Theoretical position of the 3 way valve	4.	0 : D.H.W.	4.	1 : C.H.	DHW flow temperature in °C	5.	from 00 to 99	CH flow temperature in °C	7.	from 00 to 99	Software version of main P.C.B.	9.	10 to 99	          
Section	Digit 1	Digit 2 and 3																															
Software version of display P.C.B.	0.	10 to 99																															
Nominal Power of the boiler (type 18 or 24 kW)	1.	24																															
Flue type	2.	1 : FF variable speed																															
Room thermostat is calling for heat	3.	0 : no																															
	3.	1 : yes																															
Theoretical position of the 3 way valve	4.	0 : D.H.W.																															
	4.	1 : C.H.																															
DHW flow temperature in °C	5.	from 00 to 99																															
CH flow temperature in °C	7.	from 00 to 99																															
Software version of main P.C.B.	9.	10 to 99																															

ACTION	CONFIGURATION	DISPLAY								
	Menu - 3 - Boiler options									
once		<table><tr><th>Section</th><th>Digit 1</th><th>Digit 2 and 3</th></tr><tr><td>Under floor heating system</td><td>0</td><td>0 : no 1 : yes</td></tr></table>	Section	Digit 1	Digit 2 and 3	Under floor heating system	0	0 : no 1 : yes	 	Factory setting 
Section		Digit 1	Digit 2 and 3							
Under floor heating system	0	0 : no 1 : yes								
	x times									
										

ACTION	CONFIGURATION			DISPLAY										
	Menu - 4 - Boiler settings			- 4 -										
once	<table><tr><th>Section</th><th>Digit 1</th><th>Digit 2 and 3</th></tr><tr><td>Room thermostat operation</td><td>0</td><td>0 : Burner only</td></tr><tr><td></td><td>0</td><td>1 : Burner and pump</td></tr></table>	Section	Digit 1	Digit 2 and 3	Room thermostat operation	0	0 : Burner only		0	1 : Burner and pump				
Section	Digit 1	Digit 2 and 3												
Room thermostat operation	0	0 : Burner only												
	0	1 : Burner and pump												
x times	Pump speed	1	0 : High speed		✓									
		1	1 : Low speed		✓									
	Pump post circulation duration	2	0,0 min											
	From 0 to 5 minutes by step of 0.5 min.	2	0,5 min											
		2	1,0 min		✓									
		2	5,0 min											
	Maximum Central Heating flow temperature	4	50°C											
	C.H. anti cycling delay	4	80°C		✓									
	TAC	8	0,0 min											
	From 0 to 5 minutes by step of 0.5 min.	8	0,5 min											
		8	2,5 min		✓									
		8	5,0 min											
	C.H. maximum output limitation by step of 1 kW		Power value											
	For a 24 kW model	9	8 to 18		✓									

ACTION	CONFIGURATION	DISPLAY				
 press once	Menu - 5 - Combustion rate control mode					
wait 5 "	<table><tr><th>Effect</th><th>Display</th></tr><tr><td colspan="2">Combustion rate control mode OFF</td></tr></table>	Effect	Display	Combustion rate control mode OFF		 
Effect	Display					
Combustion rate control mode OFF						
 press once	<table><tr><td>Switching on the combustion rate control mode. Central heating output reaches the maximum power set in menu 4 section 9.</td><td>Central heating temperature is displayed in °C. The 3 dots indicate that the combustion rate control is ON at maximum output.</td></tr></table>	Switching on the combustion rate control mode. Central heating output reaches the maximum power set in menu 4 section 9.	Central heating temperature is displayed in °C. The 3 dots indicate that the combustion rate control is ON at maximum output.			
Switching on the combustion rate control mode. Central heating output reaches the maximum power set in menu 4 section 9.	Central heating temperature is displayed in °C. The 3 dots indicate that the combustion rate control is ON at maximum output.					
 press once	<table><tr><td>Switching the combustion rate down to minimum power.</td><td>Central heating temperature is displayed in °C. The dot indicates that the combustion rate control is ON at minimum output.</td></tr></table>	Switching the combustion rate down to minimum power.	Central heating temperature is displayed in °C. The dot indicates that the combustion rate control is ON at minimum output.			
Switching the combustion rate down to minimum power.	Central heating temperature is displayed in °C. The dot indicates that the combustion rate control is ON at minimum output.					
 press once	<table><tr><td>Switching on the combustion rate to maximum output set in menu 4 section 9.</td><td>Central heating temperature is displayed in °C. The 3 dots indicate that the combustion rate control is ON at maximum output.</td></tr></table>	Switching on the combustion rate to maximum output set in menu 4 section 9.	Central heating temperature is displayed in °C. The 3 dots indicate that the combustion rate control is ON at maximum output.			
Switching on the combustion rate to maximum output set in menu 4 section 9.	Central heating temperature is displayed in °C. The 3 dots indicate that the combustion rate control is ON at maximum output.					
 press once	<table><tr><td>Switching off the combustion rate control mode.</td><td></td></tr></table>	Switching off the combustion rate control mode.				
Switching off the combustion rate control mode.						

Locking conditions of the combustion rate control mode :

- boiler in stand by mode
- D.H.W. draw off
- room thermostat is not calling for heat
- room thermostat is calling for heat but the maximum temperature is reached
- boiler in lockout mode
- after a reset or if the main supply fails
- end of the mode if the operator exits menu 5
- after 15 minutes if no keys are pressed.

Note : As soon as the combustion rate control mode is on, the Central Heating and Domestic Hot Water keys will become inactive.

C.H. power output setting :

If you would like to change the setting of C.H. power output to 12 kW, please proceed as follows :

(**Note:** the factory setting is 18 kW and the following explanation refers to menu 4 section 9)

- 1** - Switch to installer mode, press the **+** and **-** keys on the D.H.W. side for 5 seconds.

The display shows :

-1- then **0.-** if there is no default in the default register.

- 2** - press the **+** key (C.H. side) 3 times to gain access to menu **-4-**,

The display shows :

-4- then the value set for section 0 (**00** or **01** respectively (action on burner only or pump and burner)

- 3** - Select section 9 (Adjustment of C.H. heat output). Press the **+** key (D.H.W. side) 9 times.

The display shows :

918 (this corresponds to 18 kW which is the factory setting)

9 = section 9 **18** = 18 kW


- 4** - press the **-** key (C.H. side) once, the 2nd and 3rd digits will flash together. Then press the **-** key (D.H.W. side) to change to 3.0 on the 2nd and 3rd digits.

The display shows :

912 press the **-** key (C.H. side) to confirm this value. The display will stop flashing. The setting procedure is finished.

To exit from the setting mode, leave the boiler for approx. 1 minute the computer will then return to the user mode.

After programming is completed please close the door. **P** (fig. 17)




5''

Display

- 1 -

0. - -




x 3

- 4 -

0 0


or

0 1



x 9

9 1 8



9 1 8

9 1 2

10

Incorrect Operation

In case of a problem, or when the boiler displays a message, the 2 digits will flash.. Please refer to the table below to diagnose the default.

For default 01 and 03, the red indicator **35** will light (Fig.19)

Overheat lock-out

FAULT - 01




Fig. 19

Code display	Fault description	Operation Information
01	Overheat lock-out	Anti freezing system, pump on Anti freezing system, pump and burner on
03	No flame detection	
05		
06		
07	No water circulation in primary circuit	
08	No water in the primary circuit	
09	Domestic Hot Water thermistor faulty (open circuit)	
10	Domestic Hot Water thermistor faulty (short circuit)	
11	Central Heating thermistor faulty (open circuit)	
12	Central Heating thermistor faulty (open circuit)	
18		Attempt to re-light
20	Wiring problem	
23	Fan speed too low	
24	Fan control system defective	
29	Three way valve blocked in C.H. mode	
31	Communication problem with the display P.C.B.	
32	Communication problem with the main P.C.B.	

11

Gas Conversion

If the boiler is not set for the gas type, conversion kits are available. To convert the boiler, please use originally Chaffoteaux & Maury parts and proceed as is mentioned in the instruction manual provided with the conversion kit.

USER INSTRUCTIONS

12

Control Panel




Fig. 20

Control panel (Fig. 20)

- | | |
|---|---|
| 16.- Pressure gauge | 30.- Green indicator: Central Heating mode ON and RESET (Reset button) |
| 24.- Display | 31.- Key to reduce the Central Heating temperature |
| 25.- Switch for Domestic Hot Water mode | 32.- Key to increase the Central Heating temperature |
| 26.- Green indicator Heating Domestic Hot Water mode ON | 33.- Green indicator - Power ON |
| 27.- Key to reduce the Domestic Hot Water temperature | 34.- Orange indicator - Burner ON |
| 28.- Key to rise up the Domestic Hot Water temperature | 35.- Red indicator - Lock out/flame failure |
| 29.- Switch for Central Heating mode | 36.- Reset button |





Fig. 21

Connecting bracket (Taps shown in the open position) (Fig. 21)

- | | |
|---|---|
| 37 : Central heating flow isolating valve | 40 : Water service tap |
| 38 : Domestic Hot Water outlet | 41 : Central Heating return isolating valve |
| 39 : Gas service tap | 43 : Central Heating pressure relief valve |
| | 45 : D.H.W. drain screw |


Switching on



1. Check that the pressure in the central heating system is above 0.7 bar and below 1.5 bar with the pressure gauge **16** (Fig.20)
2. Check that the gas service tap is opened at the gas meter and the main power is on. Green indicator  (Power ON) **33** (Fig.20).
3. Open the gas tap **39** (Fig.21).



The boiler is now ready to use.



Attention ! If the boiler has been off for a long period of time without working, some air in the gas pipe can hinder the first attempts to ignite. (please refer to section 18 (Incorrect Operation))

Switching on the Central heating



Press the  key **29**, the green indicator **30** (Fig.20) light and the display will show the Heating flow temperature. 


Keys **31**  and **32**  (Fig.20) allow the temperature to be adjusted as required in the Central Heating system depending on the weather conditions.

- press  to increase the temperature when the weather is cold
- press  to reduce the temperature when the weather is fair

During the temperature setting operation the display will flash.

If the room thermostat is calling for heat, a dot will be displayed at the bottom of the 3rd digit

Switching on the Domestic Hot water






Press the  key **25**, the green indicator **26** (Fig.20) will light :

If there is no water demand

the display will show the following graphic 

During draw off

a square made of 4 digits will move clockwise on the display 

Keys **27**  and **28**  (Fig.20) allow the temperature to be adjusted as required for the Domestic Hot Water flow. During the temperature setting operation the display will flash.


Note : The configuration of the C.H. system can generate some gravity effect when the boiler is set to the D.H.W. mode only. It may result in a temperature rise of the heating pipes close to the boiler (or eventually a radiator). To avoid this, it is possible to close the heating flow isolating tap **37** (Fig.21) during the summer period (Central Heating switched off) Don't forget to open it before switching on the Central Heating mode again.

Switching on the Domestic Hot Water and the Central Heating together


Press the  key **29** the green indicator **30** (Fig.20) will light.

Press the  key **25** the green indicator **26** (Fig.20) will light.

If there is no water demand

the display will show the heating flow temperature 

During draw off

a square made of 4 digits will move clockwise on the display 

Stand by mode

A fixed digit at the centre of the display and the green indicator **33** (Fig.20) will light.

Putting the boiler in stand-by mode and anti-freeze system. :

Press the and keys, **25** and **29** (Fig.20) to switch off both the D.H.W. and the C.H. mode. The green indicators **30** and **26** (Fig.20) will go out.

During the duration of the stand by mode, an automatic anti-sticking system will activate the pump for 1 minute and operate the 3 way valve every 23 hours. The stand-by mode will disable the anti-freeze function of the room thermostat (if fitted). To leave the room thermostat anti-freeze system operative, please leave the Central Heating mode on.

The boiler is equipped with an automatic anti freeze system which is permanently on.

If the Central Heating temperature decreases below 7°C, the pump will start.

If the Central Heating temperature decreases below 4°C, the pump and the burner will start.

Turn off the boiler

- Press the and keys, **25** and **29** to (Fig.20) switch off both the D.H.W. and the C.H. mode. The green indicators **30** and **26** (Fig.20) will go out.
- Switch off the main electrical supply
- Shut off the gas service tap **39** (Fig. 21)

Note : In this condition, the **anti-freeze** system is inoperative.

As with a car, your boiler will work more reliably and efficiently if regularly serviced. We recommend an annual service check. The service history of the appliance will be marked in the Log Book.

The manufacturer's guarantee is valid for 12 months from the date of installation. The guarantee is voidable if the appliance is not installed in accordance with the recommendations made herein or in a manner not approved by the manufacturer. To assist us in providing you with an efficient after sales service, please return the guarantee registration card enclosed with the boiler without delay.

Pump anti-sticking device

When the boiler is switched on, an automatic anti-sticking system will activate the pump for 1 minute and operate the 3 way valve every 23 hours. This is a normal function.

Precaution to avoid freezing

We recommend you to contact your installer or local service centre for further information.

• D.H.W. system

Turn off the mains cold water supply and drain the boiler :

- Open a hot water tap
- Unscrew the cold water inlet tail
- Drain the water from the boiler with the D.H.W. drain screw **45** (Fig. 21)

• C.H. system

Chose one of the following solution :

- 1) Drain the Central Heating system completely.
- 2) Protect the Central Heating system with anti freeze chemical products and periodically check the concentration
- 3) Leave the Central Heating mode switched on and set the room thermostat to its anti-freeze mode (between 5 and 10°C)
- 4) Leave the boiler in stand-by mode, the anti-freeze device will activate the pump and the burner if necessary.

This appliance is suitable for Natural gas or L.P.G. Any gas conversion must be made by a competent person.

Fault	Cause	Solution
The boiler doesn't start	No gas, no water or no electricity	Control gas, water and electrical supply, fuses...
	Air in the gas pipe	Follow the procedure in section 7
		Set up the room thermostat
Red indicator illuminates	Room thermostat switched off	Wait for a few minutes Press the reset button 36 (Fig.21) the red L.E.D. goes out and the boiler attempts to re-light. If the red indicator illuminates frequently, please call your localfaïtes service centre.
Noises in the C.H. system	Air is present in the C.H. system or. system pressure is insufficient.	Purge the system of air and increase the system pressure (section 7)
Radiators rise in temperature During summer season	Gravity effect in the C.H. system	Close the C.H. flow isolating valve. Don't forget to open it again before you switch on the Central Heating.
If these solutions do not cure the fault, call a qualified professional		

Model**Centora green 18-24**

Appliance category.....	II 2H3P	
Gross heat input C.H. max.....	20.9 kW	71,290 Btu/h
Gross heat input D.H.W. max	27.8 kW	94,800 Btu/h
Heat output C.H. 50°/30° max.....	19.5 kW	66,550 Btu/h
Heat output C.H. 80°/60° max.....	18 kW	61,430 Btu/h
Heat output D.H.W. max	24 kW	80,910 Btu/h
C.H. operating temperature.....	80°C max	25°C min
C.H. circuit pressure min operating.....	0.7 bar	10 lb/in²
C.H. circuit pressure max operating.....	2.5 bar	36.3 lb/in²
D.H.W. flow rate ΔT 30°C.....	12 l/min	2.66 gal/min
D.H.W. flow rate ΔT 35°C	10.3 l/min	2.29 gal/min
Cold water mains pressure min operating.....	0.5 bar	7.25 lb/in²
Cold water mains pressure max operating.....	10 bar	145 lb/in²
Flow limiter rate.....	8 l/min	
Compartment ventilation	not required	
Natural gas G20		
Gas rate C.H. max	1.98 m³/h	70 ft³/h
Gas rate D.H.W. max	2.65 m³/h	93 ft³/h
Gas rate C.H. & D.H.W. min	0.87 m³/h	31 ft³/h
Gas valve restrictor diameter	5.55 mm	
Propane L.P.G. G31		
Gas rate C.H. max.	1.46 kg/h	27 ft³/h
Gas rate D.H.W. max.	1.94 kg/h	36 ft³/h
Gas rate C.H. & D.H.W. min	0.64 kg/h	12 ft³/h
Gas valve restrictor diameter	4.15 mm	
Safety discharge	3 bar	43.5 lb/in²
Expansion vessel - Pre-charge pressure	0.7 bar	9.4 lb/in²
Net capacity at 3 bar in litres.....	5.44	
Adjustable by-pass		
Electrical characteristics		
Supply	230V~	
Consumption	150W	
Protection	IP4 XD	
Fuse F1	2 A	
Fuse F2	1.25 A	
Fuse F3	0.315 A	
Fuse F4	0.250 A	
External controls	24V~	

Chaffoteaux & Maury are continuously improving their products and therefore reserve the right to change specifications without prior notice and accepts no liability for any errors or omission in the information contained in this document.

Manufacturer: **Chaffoteaux & Maury - France**

Commercial subsidiary: **MTS (GB) Limited**
MTS Building
Hughenden Avenue
High Wycombe
Bucks HP13 5FT
Telephone: (01494) 755600
Fax: (01494) 459775
internet: www.chaffoteaux.co.uk
E-mail: info@mtsgb.ltd.uk
Technical Support Help Line: (01952) 222288




**CHAFFOTEAUX
& MAURY**

MAINTENANCE AND SERVICE GUIDE


Centora
green

Fanned Flue Condensing Wall Hung Combination Boiler Central Heating and Instantaneous Domestic Hot Water

Dimensions



Flue types:
C 13: horizontal




Technical Data

Gross heat input C.H. max	9.2 to 20,9 kW
Gross heat input D.H.W. max	9.2 to 27.8 kW
Heat output C.H. 50°C/30°C max.....	8.3 to 19.5 kW
Heat output C.H. 80°C/60°C max.....	8 to 18 kW
Heat output D.H.W. max	8.3 to 24 kW
C.H. operating temperature.....	80°C max
C.H. circuit pressures Min operating	0.7 bar
C.H. circuit pressures Max operating	2.5 bar
D.H.W. flow rates ΔT30°C.....	12 l/min
D.H.W. flow rates ΔT35°C	10.3 l/min
Cold water mains pressures Min operating...	0.5 bar
Cold water mains pressures Max operating..	10 bar
Flow limiter rate	8 l/min
Safety discharge	3 bar
Expansion vessel - Pre-charge pressure	0.7 bar
Nett capacity at 3 bar in litres.....	5.44
Supply	230 V~
Consumption	150 W
Protection	IPX4D
Fuse F1/F2/F3/F4	2 A/1.25 A/0.315 A/0.250 A
External controls	24 V~

Natural Gas G20	
Gas rate C.H. max	1.98 m³/h
Gas rate D.H.W. max.....	2.65 m³/h
Gas rate C.H. & D.H.W. min	0.87 m³/h
Gas valve restrictor diameter	5.55 mm
Propane L.P.G. G31	
Gas rate C.H. max.	1.46 kg/h
Gas rate D.H.W. max.....	1.94 kg/h
Gas rate C.H. & D.H.W. min	0.64 kg/h
Gas valve restrictor diameter	4.15 mm


Pump and Expansion Vessel Characteristics

Pump head available



GV F= high speed by-pass closed
GVO = high speed by-pass open
PV F= low speed by-pass closed
PVO = low speed by-pass open



Pf Central heating initial pressure when cold (in bar)




System capacity chart

Note : The system initial pressure should be over the following value :
 $\frac{\text{System static height (in metre)}}{10} + 0.7 = \text{Initial pressure (in bar)}$

Components Location




- 1.- Steel chassis complete with expansion vessel (not visible)
- 2.- Sealed chamber
- 3.- Burner and heat exchanger assembly
- 4.- Air/gas connection
- 5.- 24 V modulating fan
- 6.- Gas valve
- 7.- Ignition electrode
- 8.- Ionisation probe
- 9.- Ignitor
- 10.- Combustion products manifold
- 11.- 24 V transformer
- 12.- Siphon
- 13.- Electrical box
- 14.- Pump
- 15.- Secondary heat exchanger
- 16.- Pressure gauge
- 17.- Three way valve
- 18.- Automatic air separator and automatic vent
- 19.- Central Heating flow switch
- 20.- Domestic Hot Water flow switch
- 21.- Central Heating control thermistor
- 22.- Domestic Hot Water control thermistor
- 23.- Overheat sensor
- 37.- Central Heating flow isolating valve
- 38.- Domestic Hot Water outlet
- 39.- Gas service tap
- 40.- Water service tap
- 41.- Central Heating return isolating valve
- 43.- Central Heating pressure relief valve
- 46.- User instructions
- 47.- Connecting tails (x5)
- 48.- Condensate drain
- 49.- Adjustable by-pass
- 50.- Right hydraulic assy
- 51.- Left hydraulic assy




FUNCTIONING

Control Panel




- 24.- Display
- 25.- Domestic Hot Water switch
- 26.- Green indicator – Domestic Hot Water mode ON
- 27.- D.H.W. temperature reducing key
- 28.- D.H.W. temperature increasing key D.H.W. mode indicator
- 29.- Central Heating switch
- 30.- Green indicator – Central Heating mode ON
- 31.- Central Heating temperature reducing key
- 32.- Central Heating temperature increasing key
- 33.- Green indicator – Power ON
- 34.- Orange indicator - Burner ON
- 35.- Red indicator - Lock out / flame failure
- 36.- Reset key



Switching On



1. Check that the pressure in the Central Heating system is above 0.7 bar and below 1.5 bar with the pressure gauge **16**.
2. Check that the gas service tap is open at the gas meter and the main power is on. Green indicator  Power ON **33**.
3. Open the gas tap **39** (Fig.21).
The boiler is now ready to use.



Attention ! If the boiler has been off for a long period of time, some air in the gas pipe can hinder the first attempts to ignite.
(please refer to Section 19 Incorrect Operation).

Switching on Central Heating



Press the  key **29**, the green indicator **30** will light and the display will show the Central Heating flow temperature. 

Keys **31**  and **32**  allow the temperature to be adjusted as required for the Central Heating system depending on the weather conditions.


- press  to increase the temperature when the weather is cold
- press  to reduce the temperature when the weather is fair


During the temperature setting operation the display will flash.

If the room thermostat is calling for heat, a dot will be displayed at the bottom of the 3rd digit



Switching on the Domestic Hot water




Press the  key **25** the green indicator **26** will light :



If there is no water demand

the display will show the following graphic 

During draw off


a square made of 4 digits will move clockwise on the display




Keys **27**  and **28**  allow the temperature to be adjusted as required for the Domestic Hot Water flow. During the temperature setting operation the display will flash.

Note : The configuration of C.H. system can generate some gravity effect when the boiler is set in D.H.W. mode only. It may result in a temperature rise of the heating pipes close to the boiler (or eventually a radiator). To avoid this, it is possible to close the heating flow isolating tap **37** (Fig. 21) during the summer period (Central Heating switched off). Don't forget to open it again before you switch on the Central Heating mode again.

Switching On the Domestic Hot Water and Central Heating Together


Press the  key **29**, the green indicator **30** will light.

Press the  key **25**, the green indicator **26** will light.

If there is no water demand the display will show the heating flow temperature



During draw off a square made of 4 digits will move clockwise on the display





Stand-by Mode



A fixed digit at the centre of the display and the green indicator **33** will illuminate.

Putting the boiler in stand-by mode and anti-freeze system. :

Press the  key **29** and the  key **25**, to switch off both the D.H.W. and C.H. mode. The green indicators **30** and **26** will go off.

During the duration of the stand by mode, an automatic anti-sticking system will activate the pump and 3 way valve for 1 minute every 23 hours.



The stand by mode will disable the anti-freeze function of the room thermostat (if fitted). To leave the room thermostat anti-freeze system operative, leave the Central Heating mode on.

The boiler is equipped with an automatic anti-freeze system which is permanently on.

If the Central Heating temperature falls below 7°C, the pump will start.


If the Central Heating temperature falls below 4°C, the pump and the burner will start.


Turn Off the Boiler

- Press the  key **29** and the  key **25**, to switch off both the D.H.W. and C.H. mode. The green indicators **30** and **26** will go off.
- Switch off the main electrical supply
- Shut off the gas service tap **39** (Fig. 21)

Note : In this condition, the **anti-freeze** system is inoperative.



Domestic Hot Water Mode

To be able to supply Hot Water, the D.H.W. mode should be ON. Press the  key **25**, the green indicator **26** will illuminate.

If there is no water demand, the display will show the following graphic 

During draw off, a square made of 4 digits will move clockwise on the display



Keys **27**  and **28**  allow the temperature to be adjusted as required for D.H.W. flow. During the temperature setting operation, the display will flash. When a tap or a shower is turned on, a flow of mains water above 2 l/min, will activate the D.H.W. flow switch **20**, the 3 way valve **17** will move to the D.H.W. position. The pump can now circulate primary water heated by the main exchanger through the secondary heat exchanger. The C.H. flow switch checks that the flow rate is over 4 l/min to allow the ignition sequence to begin.

The fan on the gas valve assembly starts and when the lighting speed is reached (detected by a hall effect sensor) the 2 safety solenoids open together to allow gas to the burner. The ignition sequence begins and a continuous high speed spark ignites the gas. As soon as a flame is detected, the orange indicator bulb **34** will light and the regulation system will be able to adjust the gas rate according

to the heat load. If a flame is not detected, after 10 seconds, the security solenoids close together and shut off the gas. The red lockout indicator bulb **35** will light. Press the reset button to re-attempt ignition.


The Domestic Hot Water temperature is controlled by the Hot Water control thermistor **22** and the Central Heating control thermistor **21**. The system anticipates changes of temperature in the secondary heat exchanger and ensures accurate temperature regulation.



When the tap is closed, the burner is extinguished and the pump stops. The boiler will now stay in the Hot Water mode for 3 minutes to maintain temperature and to ensure a fast response in the event of a subsequent Hot Water demand.

Priority will be given to a demand for Hot Water. This will interrupt the Central Heating for the duration of Hot Water delivery.

Central Heating Mode

To be able to supply Central Heating, the C.H. mode should be switched ON.

Press the  key **29**, the green indicator **30** will light, and the display will show the Heating Flow temperature.

Keys **31**  and **32**  allow the temperature to be adjusted as required for the Central Heating system relating to the weather conditions. During the setting operation, the display will flash.

When there is a demand for heating, (either from the room thermostat or the clock) the pump starts. If the boiler temperature control is calling for heat and the Central Heating flow rate is over 4 l/min, the Central Heating flow switch operates, allowing the ignition sequence to begin. The fan on the gas valve assembly starts and when the lighting speed is reached (detected by a hall effect sensor) the 2 safety solenoids open together to allow gas to the burner. The ignition sequence begins and a continuous high speed spark ignites the gas. As soon as a flame is detected, the orange indicator bulb **34** will light and the regulation system will be able to adjust the gas rate according to the heat load. If a flame is not detected after 10 seconds, the security solenoids close together and shut off the gas. The red lockout indicator bulb **35** will light. Press the reset button to re-attempt ignition.

The Central Heating flow temperature is controlled by the Central Heating control thermistor **21**. The boiler has been designed to minimise cycling and will not attempt to re-light for at least 3 min. after the boiler thermostat has been satisfied. When the room thermostat is satisfied, the burner will switch off and the pump will run for a further 3 minutes before stopping.

Note:

It is possible to override the 3 minute delay by pressing the reset button **36**.


Lockout Procedure

Flame extinguishes:
When the ionisation probe 8 fails to detect flame presence. The orange indicator bulb 34 will go off and a lighting cycle starts. If a flame is not detected, within 10 seconds, the safety solenoids will close. The red lockout indicator 35 illuminates and the display shows the

error code. The pump runs and the 3 way valve 17 stays in its position. After a few seconds, it will become possible to reset the boiler by pressing the reset button 36.
Overheat Detection :
If a temperature over 100°C is detected in the primary circuit by the sensor 23,


the safety solenoids close and the fan stops. The orange bulb 34 will go off and the pump will run for a further 3 minutes. It is possible to reset the boiler when the primary circuit temperature falls below 76°C.

CENTORA GREEN FUNCTIONAL DIAGRAM



ELECTRICAL WIRING


DIAGRAM




ACTION

CONFIGURATION


DISPLAY



5 "



x times

**Menu - 1 - Default Register**

Records the last 10 defaults

Section	Digit 1	Digits 2 and 3
Last default occurred	0.	code from 01 to 99
Last but one default occurred	1.	code from 01 to 99
...	...	code from 01 to 99
Last default occurred before the previous one	9.	code from 01 to 99


Note -- is displayed if no default is recorded.

- 1 -


0. _ _

1. _ _

9. _ _



once



x times

**Menu - 2 - Boiler Conditions**

Indicates the conditions or the configurations of the boiler

Section	Digit 1	Digit 2 and 3
Software version of display P.C.B.	0.	10 to 99
Nominal Power of the boiler (type 18 or 24 kW)	1.	24
Flue type	2.	1 : FF variable speed
Room thermostat is calling for heat	3.	0 : no
	3.	1 : yes
Theoretical position of the 3 way valve	4.	0 : D.H.W.
	4.	1 : C.H.
D.H.W. flow temperature in °C	5.	from 00 to 99
C.H. flow temperature in °C	7.	from 00 to 99
Software version of main P.C.B.	9.	10 to 99

- 2 -

0. _ _

1. 24

2. 1

3. 0

3. 1

4. 0


4. 1

5. _ _


7. _ _

9. _ _


ACTION



once



x times



CONFIGURATION

Menu - 3 - Boiler Options

Section	Digit 1	Digits 2 and 3
Under floor heating system	0	0 : no 1 : yes

DISPLAY

- 3 -


Factory
setting

0 0


0 1

✓

ACTION



once



x times



CONFIGURATION

Menu - 4 - Boiler Settings

Section	Digit 1	Digits 2 and 3
Room thermostat operation	0	0 : Burner only
	0	1 : Burner and pump
Pump speed	1	0 : High speed
	1	1 : Low speed
Pump post circulation duration	2	0.0 min
From 0 to 5 minutes by step of 0.5 min.	2	0.5 min
	2	1.0 min
	2	5.0 min
Maximum Central Heating flow temperature	4	50°C
C.H. anti cycling delay	4	80°C
TAC	8	0.0 min
From 0 to 5 minutes by step of 0.5 min.	8	0.5 min
	8	2.5 min
	8	5.0 min
C.H. maximum output limitation by step of 1 kW		Power value
For a 24 kW model	9	8 to 18

DISPLAY

- 4 -

Factory
setting

0 0

0 1

1 0

1 1

20.0

20.5

2 1.0

2 5.0

4 50

4 80

8 0.0

8 0.5

8 2.5

8 5.0

9 18

✓

✓

✓

✓


✓

✓

ACTION

CONFIGURATION

DISPLAY



press once

Menu - 5 - Combustion Rate Control Mode

- 5 -


wait 5 "

Effect

Display

Combustion rate control mode OFF

- . - .




press once

Switching on the combustion rate control mode. Central Heating output reaches the maximum power set in menu 4 section 9.

Central Heating temperature is displayed in °C.
The 3 dots indicate that the combustion rate control is ON at maximum output.

X.X.°.




press

Switching the combustion rate down to minimum power.

Central Heating temperature is displayed in °C.
The dot indicates that the combustion rate control is ON at minimum output.

X.X.°.




press once

Switching on the combustion rate to maximum output set in menu 4 section 9.

Central Heating temperature is displayed in °C.
The 3 dots indicate that the combustion rate control is ON at maximum output.

X.X.°.



press once

Switching off the combustion rate control mode.

- 1 -

Locking conditions of the combustion rate control mode :

- boiler in stand by mode
- D.H.W. draw off
- room thermostat is not calling for heat
- room thermostat is calling for heat but the maximum temperature is reached
- boiler in lockout mode
- after a reset or if the main supply fails
- end of the mode (if operator leaves menu 5)
- after 15 minutes if no keys are pressed.

Note: As soon as the combustion rate control mode is on, the Central Heating and Domestic Hot Water keys will become inactive.

C.H. Power Output Setting :

If you would like to change the setting of the C.H. power output to 12 kW, please proceed as follows :

Note: the factory setting is 18 kW and the following explanation refers to menu 4 section 9)


Display

- 1** - Switch to installer mode, press both the **+** and **-** keys (D.H.W. side) for 5 seconds.


The display shows :

-1- then **0.--** if there is no default in the default register.

1



5 "




- 2** - press the menu key **+** (C.H. side) 3 times to gain access to menu **-4-**,

The display shows :

-4- then the value set for section 0 (**00** or **01** respectively action on burner only or pump and burner)

2



x 3



or




- 3** - change to section 9 (Adjustment of C.H. Power Output). Press the **+** (D.H.W. side) 9 times.

The display shows :

918 (which corresponds to the 18 kW which is the factory setting)

9 = section 9 **18** = 18 kW

3



x 9



- 4** - press the **-** key (C.H. side) once, the 2nd and 3rd digits flash together. Press the **-** key (D.H.W. side) to change to 3.0 on the 2nd and 3rd digits. The display shows :



912 press the setting key to confirm this value. The display stops flashing.

Setting procedure is finished.

To exit the setting mode, leave the boiler for approx. 1 minute, the computer will revert to the user mode.

After programming is completed please close the door **P** (fig. 17)

4



REGULATION

Temperature regulation for both C.H. and D.H.W. circuits are controlled by 2 thermistors. The C.H. knob allows the temperature to be adjusted between 35°C and 85°C. The D.H.W. temperature is limited to 60°C. The D.H.W. and C.H. thermistors are identical and interchangeable.

Resistance value are

- 5000 Ω	at	25°C
- 2631 Ω	at	40°C
- 620 Ω	at	80°C
- 255 Ω	at	110°C

FLOW SWITCHES

Flow in both D.H.W. and Central Heating circuits are detected by 2 flow switches. A piston with a magnet at the top operates a REED switch. The piston is lifted by the flow rates listed below :

Flow rate threshold :

D.H.W.	120 l/h \pm 20 l/h
C.H.	250 l/h \pm 20 l/h

ROUTINE SERVICING

To ensure continued efficient operation of the appliance, it is recommended that it is checked and serviced as necessary at regular intervals. The frequency of servicing will depend upon the particular installation, condition and usage. In general, once a year should be adequate.

It is the law that any service work must be carried out by a competent person such as your local Chaffoteaux Service Centre, British Gas or other CORGI registered personnel in accordance with the current Gas Safety (Installation and Use) regulations.

Attention! The air/gas connection pipe between the gas valve and the burner should never be opened. The seal can only be checked in the factory.

The service schedule should include the following operations :

- Check the pressure in the system
- Check the correct operation of the appliance
- Check the correct operation of the gas controls
- Check the functions of the safety controls
- Clean the electronic board of the fan located on the gas valve assembly and the different transformers in the sealed chamber.
- Check combustion chamber insulation panels for damage
- Check the condition of the lighting and ionisation electrodes
- Clean the burner (Never use a metallic brush which can damage the stainless steel)
- Clean the heat exchanger (Never use a metallic brush which can damage the stainless steel)
- Clean the siphon and pay attention to the acidity of its contents
- Check the correct seal of the drain system
- Clean the gas and water filters
- Check the expansion vessel charge pressure
- Clean and check the operation of the safety valve
- Check the correct seal of the flue system.

Additional procedures that may be necessary :

- Check the burner pressure and the gas flow rates
- Check, clean and replace components as necessary
- Carry out combustion test utilising the test points in the flue turret

Suggested sequence for servicing :

Before disconnecting or removing any part, isolate the gas and electricity supplies. Ensure that the appliance is cool, and be careful of the condensate products content in the siphon which are acid.

(For detail, please see section on Parts Removal and Replacement)

Preliminary checks


- Remove the outer case
- Check the system pressure is at least 0.7 bar when cold
- Check the modulation of the gas valve in D.H.W. mode by progressively reducing the flow rate at a tap.
- Check that the burner is extinguished fully when both solenoids are closed and the fan is off.
- Test ionisation functions and check that lockout occurs by turning off the gas tap.
- Whilst the boiler is operating, check the operation of the Central Heating flow switch by closing the Central Heating flow valve and the by-pass screw (turn clockwise) noting the number of turns so that it may be reset correctly.
- Check the correct flood of condensate in the siphon which is transparent.

REMOVAL AND REPLACEMENT OF PARTS

Before removing the appliances case, isolate the gas and electrical supplies. Isolate the boiler from the system and drain before removing any component in the waterways. Ensure that the appliance is cool.

1. Outer Case

Remove the four screws in the base of the boiler and lift free. When replacing,



carefully place the casing on lugs **T** located on the top edge of chassis.

2. Sealed Chamber Front Panel

Unscrew the four self tapping screws securing the sealed chamber front panel and lift off of the corner locating lugs. Reassemble in reverse order.

3. Combustion Chamber Front Panel and Air/Gas Connection

Carry out steps 1 and 2 as above. Unscrew the three screws securing the air/gas connection pipe onto the gas valve assembly. Disconnect both the ionisation and lighting electrodes from their wiring. Unscrew the six nuts to release the combustion chamber front panel and pull the assembly towards you. Reassemble in reverse order.

4. Ionisation Probe

Carry out steps 1 and 2 as above. Disconnect the ionisation probe from its wiring. Loosen the 2 screws and pull it out from the combustion chamber front panel. Replace the gasket provided. Reassemble in reverse order.

5. Ignition Electrode

Carry out steps 1 and 2 as above. Disconnect the ignition electrode from its wiring. Loosen the 2 screws and pull it out from the combustion chamber front panel. Replace the gasket provided. Reassemble in reverse order.

6. Burner

Carry out steps 1, 2 and 3 as above. Remove the four Philips screws retaining the burner. Pull it out with care to avoid any damage to the ceramic panel protecting the combustion chamber front panel. Replace the burner gasket. Reassemble in reverse order.

7. Gas Valve Assembly

Carry out steps 1 and 2 as above. Unscrew the three screws securing the air/gas connection pipe onto the gas valve assembly. Disconnect the connectors from the gas solenoids and fan. Loosen the gas pipe nut. Unscrew the six nuts to release the combustion chamber front panel and pull the assembly towards you. Replace the gas filter before fitting the full assembly back into the boiler.

8. Fan Assembly

Carry out all operations mentioned in step 7. Unscrew the three screws securing the air/gas connection pipe onto the gas valve assembly. Separate the gas valve assembly and the venturi from the fan assembly by loosening the two hexagonal head screws. Reassemble in reverse order and replace the necessary gaskets.

9. Gas Section

Carry out all operations mentioned in step 7. Unscrew the three screws securing the air/gas connection pipe onto the gas valve assembly. Separate the gas valve assembly and the venturi from the fan assembly by loosening the two hexagonal head screws. The venturi and the gas section can be separated by loosening the two screws located at the top of the gas valve. Replace all necessary gaskets before reassembling in reverse order.


10. Venturi in the Gas Section

Carry out all operations mentioned in step 7. Unscrew the three screws securing the air/gas connection pipe onto the gas valve assembly. Separate the gas valve assembly and the venturi from the fan assembly by loosening the two hexagonal head screws. The venturi and the gas section can be separated by loosening the two screws located at the top of the gas valve. Replace all necessary gaskets before reassembling in reverse order.

11. Drain Down

2 drain points are located on the boiler.

Air Separator



1 = D.H.W. circuit drain point

2 = Central Heating circuit drain point

12. Water Filters (D.H.W. and C.H.)

The D.H.W. filter ensures a seal between the connecting bracket and the pipe to the D.H.W. flow switch. Drain the boiler as in step 12. Unscrew the pipe nut and remove the clip on the hydraulic assy. Pull the pipe toward you and remove the water filter from its location. The C.H. filter is located in the right hydraulic assembly. Remove the return pipe as described previously and remove the filter. Reassemble in reverse order.

13. Flow Switches


Drain boiler as in step 12. Disconnect the electrical plug, turn the top cover anti-clockwise, remove the O-ring and the brass piston. Reassemble in reverse order.

14. 3-Way Valve

Drain boiler as in step 12. Remove the three clips on the 3-way valve. Remove the clip on the exchanger flow pipe. Pull the pipe down then pull it out of the 3-way valve. Disconnect the plug from the motor. Unscrew the nut on the pipe between the connecting bracket and the 3-way valve and pull it toward you. Rotate the 3-way valve body anti-clockwise to unclip it from the left hydraulic assembly.

15. Secondary Heat Exchanger


Drain both circuits of the boiler as in step 12. Unscrew the 2 fixing screws **D** and remove the D.H.W. exchanger from the front. Prior to reassembly, check that the 4 gaskets are correctly positioned. The heat exchanger is designed so that it cannot be remounted incorrectly.



16. Main Heat Exchanger


Carry out steps 1 and 2 as above. Drain down the boiler as in step 12. Unscrew three screws securing the air/gas connection pipe onto the gas valve assembly. Disconnect the ionisation and ignition electrodes from their wiring. Unscrew the six nuts to release the combustion chamber front panel and pull the assembly towards you. Remove the two clips for the pipes to the main exchanger and pull down the pipes. Unscrew the three screws located at the bottom, top left and at the right with the retaining system to be able to pull the main heat exchanger towards you.

Reassemble in reverse order taking care about the location of the gasket on the fumes collector and replace the necessary gaskets.



17. Pump

Drain the boiler as in step 12. Pivot the electrical box downwards. Open the electrical box cover removing the 2 screws. Remove the pump plug from the power board and earth plug from earth socket. Unscrew nut **F** on the return pipe from the volute. Remove the clip **G** on the pump volute and pull the pump toward you. Reassemble in reverse order.




18. Pressure Relief Valve

The pressure relief valve can be serviced from the front of the appliance. Drain the boiler first, undo the retaining screw and pull out the valve. Reassemble in reverse order.

19. Thermistors

Drain the boiler as step 12. Disconnect the plug, remove the retaining clip pull the thermistor out. Reassemble in reverse order.




22 = D.H.W. thermistor

21 = Central Heating thermistor

20. Safety Thermostat

Remove the casing as step 1 and pivot the electrical box downwards. Disconnect the 2 cables, pull out the sensor with the clip **23**. Reassemble in reverse order.




21. Spark Generator

Carry out steps 1 and 2 as above. Unplug the connector from the spark generator located on the right hand side of the main heat exchanger. Loosen the two screws to remove the igniter. Reassemble in reverse order.

22. Main Control Board

Carry out step 1 as above and pivot the electrical box downwards by pressing the retaining tabs **P** on either side. Remove the wiring cover **C**. Undo the four screws of the electrical rear panel and remove it. Unplug all cables from the P.C.B., remove the earth plug from earth socket. Remove the Main P.C.B. Reassemble in reverse order.



23. Display P.C.B.

Carry out step 1 as above and pivot the electrical box downwards by pressing the retaining tabs **P** on either side. Remove the pressure gauge clip. Rotate the electrical box back to the upper position. Undo the 2 screws retaining the front panel, put your two hands at the bottom of the front panel and pull it down to release it from the 2 clips. Pivot the electrical box downwards. Undo the four screws of the electrical rear panel and remove it. Unplug the display board cables from the Main P.C.B. Reassemble in reverse order.


24. Expansion Vessel

Remove the casing as step 1 and drain the boiler as step 12 above. Unscrew the connecting tails nuts and lift out the boiler from the wall. Place it on its side on the floor. Remove the expansion vessel bracket retaining screws, disconnect the pipe from the vessel and pull it toward you. Reassemble in reverse order.


25. Pressure Gauge

Carry out step 1 as above and drain the boiler as step 12. Pivot the electrical box downwards by pressing the retaining tabs **P** on either sides. Press the clip to remove it and pull it out. Remove the clip which holds the connection of the capillary on the pump hose. Pull out the pressure gauge with its capillary. Reassemble in reverse order.

FAULT FINDING CHART Part 2



SHORT LIST



Key N°	Description	G.C N°	Manf. Pt. N°	Type	CENTORA GREEN	Manf. date	
						from	to
102	ELECTRODE KIT		1309624	●	FF		
401	GAS VALVE		1308957	●			
407	FAN ASSY		1307585	●			
505	3-WAY VALVE		1010000	●			
507	OVERHEAT THERMOSTAT 100°C		1010572	●			
510	THERMISTOR		1000733	●			
514	WATER/WATER HEAT EXCHANGER		1011164	●			
532	WATER THROTTLE		81471	●			
560	AIR SEPARATOR HEAD ASSEMBLY		1002653	●			
572	PUMP UP 15/50 230V		1010612	●			
606	TRANSFORMER		1308149	●			
607	IGNITER		1002105.20	●			
615	PRINTED CIRCUIT BOARD		1307645	●			
616	PRINTED CIRCUIT BOARD		1307647	●			
627	FUSE 250V 2A - TEMPORIZED		1003456	●			
628	FUSE 250V 1A - TEMPORIZED		1003634	●			
629	FUSE 250V 1.25A - TEMPORIZED		1003635	●			
630	FUSE 250V 0.315A - TEMPORIZED		1307845	●			
805	PRESSURE GAUGE		1303158	●			
938	PRESSURE RELIEF VALVE		1020933	●			


Chaffoteaux & Maury are continuously improving their products and therefore reserve the right to change specifications without prior notice and accepts no liability for any errors or omission in the information contained in this document.

Manufacturer: **Chaffoteaux & Maury - France**

Commercial subsidiary: **MTS (GB) Limited**
MTS Building
Hughenden Avenue
High Wycombe
Bucks HP13 5FT
Telephone: (01494) 755600
Fax: (01494) 459775
internet: www.chaffoteaux.co.uk
E-mail: info@mtsgb.ltd.uk
Technical Support Help Line: (01952) 222288

DOMESTIC BOILERS

CENTORA GREEN





CENTORA GREEN SYSTEM 24
CENTORA GREEN 24
CENTORA GREEN SYSTEM 30
CENTORA GREEN 30

B



CENTORA GREEN

- 100** BURNER
200 FAN
300 SEALED CASE









[illegible]




Key N°	Description	G.C N°	Manf. Pt. N°	Type					Manf. date	
									from	to
500	HYDRAULIC BLOCK									
501	TUBE-EXCHAN TO THREE-WAY VALVE		1307591		●	●	●	●		
502	CLIP	277830	1010012		●	●	●	●		
503	"O" RING D: 18.4-2.7	277831	24164.22		●	●	●	●		
504	"O" RING D: 17-4	E00604	24164.51		●	●	●	●		
505	VALVE BLOCK ASSY		1010436		●		●			
	THREE-WAY VALVE	277833	1010000			●		●		
507	OVERHEAT THERMOSTAT 100°C	277783	1010572		●	●	●	●		
509	DRAIN SCREW ASSY	266043	81028		●	●	●	●		
510	THERMISTOR TEMP. SENSOR	277834	1000733		●	●	●	●		
511	TEMPERATURE SENSOR CLIP	277835	1002083		●	●	●	●		
514	JOINING PLATE		1010439		●		●			
	WATER/WATER HEAT EXCHANGER	E00612	1011164			●		●		
515	SCREW CBL SX M 5-40	277837	1010129		●	●	●	●		
516	CLIP		1307589		●	●	●	●		
518	LEFT HAND HYDRAULIC BLOCK	277839	1010003		●	●	●	●		
520	BYPASS TUBE	277840	1010044		●	●	●	●		
521	TAPPING SCREW CBL SX D: 6.3-19	277785	1010127		●	●	●	●		
522	CLIP	277841	1010005		●	●	●	●		
526	"O" RING D: 8.9-2.7	E00605	1009834.14		●	●	●	●		
528	HOT WATER BEND	277842	1010056			●		●		
529	HEATING FLOW BEND	277843	1010057		●	●	●	●		
530	SHEET GASKET D: 24-17-1.5	265389	61855.19		●	●	●	●		
531	HYDRAULIC PLATE	277845	1010042		●	●	●	●		
532	WATER THROTTLE	277846	81471		●	●	●	●		
535	BYPASS BODY		1016387		●	●	●	●		
537	"O" RING D: 13.6-2.7	366048	24164.18		●	●	●	●		
538	CLIP	277830	1010112		●	●	●	●		
539	"O" RING D: 1.9-8	277849	1009833.34		●	●	●	●		
540	ADJUSTING SCREW OF BY-PASS	277850	1010111		●	●	●	●		
542	CLIP	277851	79845		●	●	●	●		
543	TAPPING SCREW CBL SX D: 4.2-9.5	277792	1010125		●	●	●	●		
548	SHEET GASKET D: 24-18.2-1.5	265091	22835.01		●	●	●	●		
550	BEND RETURN	277852	1010055		●	●	●	●		
551	GAS TUBE		1307590		●	●				
	GAS TUBE		61309556				●	●		
553	WATER FILTER	277854	1007727		●	●	●	●		
558	PUMP LEAD (2 SPEEDS)	277855	1004115		●	●	●	●		
559	"O" RING D: 45-3.5	E00613	1009833.46		●	●	●	●		
560	AIR SEPARATOR HEAD ASSEMBLY	277857	1002653		●	●	●	●		
561	RIGHT HAND HYDRAULIC BLOCK	277858	1010167		●	●	●	●		
564	"O" RING D: 24.6-3.6		1009834.30		●	●	●	●		
565	HEATING FILTER		1305560		●	●	●	●		
567	CLIP	366887	30898.03		●	●	●	●		
569	LIP SEAL	277860	1002249		●	●	●	●		
570	HEATING RETURN TUBE		1307592		●	●	●	●		
571	"O" RING D: 16-1.9	E00615	1009833.37		●	●	●	●		
572	PUMP UP 15/50 230V	E11662	1010612		●	●	●	●		
573	CAPACITOR	E00616	1000652.10		●	●	●	●		
574	PLUG M 10-100	277508	15709		●	●	●	●		
575	"O" RING D: 17.86-2.62		1308091		●	●	●	●		
581	CLIP	277782	1010050		●	●	●	●		






600 ELECTRICAL BOX







[illegible]







[illegible]



1000 FLUE CONNECTION









from ... to 10/02







from 11/02 to ...

5000 ACCESSORIES



6000 MAINTENANCE



Key N°	Description	G.C N°	Manf. Pt. N°	Type					Manf. date	
									from	to
5000	ACCESSORIES									
5001	CONVERSION KIT > G25		1310865		●	●			...	10/02
5002	CONVERSION KIT > G31		1310866		●	●			...	10/02
	CONVERSION KIT G20 > G31		1311759		●	●			11/02	...
	CONVERSION KIT G20 > G31		1311760				●	●		
5014	CONNECTION - FIRST FITTING		1313069		●		●			
	CONNECTION - FIRST FITTING	277922	1010429			●		●		
5015	CONNECT. ELM	E00648	1010182		●	●	●	●		
	CONNECT. VAILLANT	E00649	1010183		●	●	●	●		
	CONNECT. CELTIC	E00650	1010517		●	●	●	●		
	CONNECT. JUNKER	E00652	1011063		●	●	●	●		
	CONNECT. SAULNIER DUVAL FF		1303293		●	●	●	●		
5020	SLEEVE		1018789		●	●				
	SLEEVE		61309802				●	●		
5021	CHOCK - BOTTOM SIDE	E00654	1010655		●	●				
	CHOCK - BOTTOM SIDE		61309803				●	●		
5022	CHOCK - DRAUGHT DIVERTER SIDE	E00655	1010080		●	●				
	CHOCK - DRAUGHT DIVERTER SIDE		61309804				●	●		
5023	SIDE CHOCK	E00656	1010081		●	●	●	●		
5030	JIG PLATE		1309325		●	●	●	●		
5033	ROD PLATE	E23679	1010932		●	●	●	●		
5035	SOUNDPROOFING KIT		1305676		●	●	●	●		
5040	USERS' INSTRUCTIONS		1309033			●		●		
	USERS' INSTRUCTIONS		1310360		●		●			
5045	WALL SPACER KIT	E23683	1016144		●	●	●	●		
6000	MAINTENANCE									
6002	DESCALING INTERFACE/WATER EXCH		1011075			●		●		
6003	SIMULATING BOX 3 WAY VALVE	E23686	1012597			●		●		
6006	SPANNER		1302650		●	●	●	●		
6007	STOPPED W/THROT. CONNECTOR KIT		1306970		●	●	●	●		

