

Installation and Servicing

Ultrapower sxi


High Efficiency System Store

100sxi

G.C. No. 41-019-09

170sxi

G.C. No. 41-019-10



Guarantee Registration

Thank you for installing a new Glow-worm appliance in your home.

Glow-worm appliances are manufactured to the very highest standard so we are pleased to offer our customers a Comprehensive Guarantee.

This product is guaranteed for 24 months from the date of installation or 30 months from the date of manufacture, whichever is the shorter, for parts. In addition this product is guaranteed for 12 months from the date of installation or 18 months from the date of manufacture, whichever is the shorter, for labour.

The second year of the parts guarantee, from the beginning of the 13th month onwards after installation or manufacture, is conditional upon the boiler having been serviced by a CORGI registered gas installer, in accordance with the manufacturer's recommendations. We strongly recommend regular servicing of your gas appliance, but where the condition is not met, any chargeable spare parts or components issued within the applicable guarantee period still benefit from a 12 month warranty from the date of issue by the manufacturer.

We recommend you complete and return as soon as possible your guarantee registration card.

If your guarantee registration card is missing you can obtain a copy or record your registration by telephoning the Glow-worm Customer Service number 01773 828100.

In addition Glow-worm offers a guarantee of 10 years for the stainless steel cylinder against faulty materials or manufacture provided that:

The following information is important as without it your guarantee may be invalid.

1. The warranty will become invalid if the damage is due to scaling, frost damage, transient voltages, lightning strikes or any act of vandalism or misuse.
2. The proof of purchase must be produced in the event of any warranty claim (bill of sale).
3. The appliance must be installed by a **competent person** to the prevailing standards, installation book and building regulations at the time of installation.
4. The benchmark log book must be completed on installation and kept up to date.
5. The appliance must be serviced annually.
6. The installation must be in an appropriate location and its use is restricted to potable water (chloride levels less than 200 mg/l).
7. Tampering or modification will invalidate the warranty.
8. The guarantee card must be completed and returned to Glow-worm within 30 days of purchase.

PLEASE NOTE THIS EXTENDED GUARANTEE IS NOT TRANSFERABLE AND RESTS WITH THE ORIGINAL HOUSEHOLDER.

Customer Service:

01773 828100

Technical Helpline:

01773 828300

General and Sales enquiries:

Tel. 01773 824639

Fax: 01773 820569

**To register your Glow-worm appliance
call:**

0800 0732142



The code of practice for the installation,
commissioning & servicing of gas central heating

These instructions consist of, Installation, Servicing, Fault Finding, Replacement of Parts and Spares. The instructions are an integral part of the appliance and must, to comply with the current issue of the Gas Safety (Installation and Use) Regulations, be handed to the user on completion of the installation.

CONTENTS	DESCRIPTION	SECTION	PAGE
INTRODUCTION	Warnings		4
	Important Information		4
	Statutory Requirements		5
	Boiler Design		6
	Boiler Safety Devices		6
	Servicing, Maintenance & Spare Parts		6
INSTALLATION	Boiler Specifications	1	7
	Boiler Location, Clearances & Ventilation	2	10
	Flue Options and Terminal Clearances	3	11
	Heating System	4	13
	Domestic Hot Water	5	14
	Condensate Drain	6	16
	Installation Preparation	7	18
	Gas, Water & Boiler Connection	8	20
	Condensate & Safety Discharge Valve Connections	9	22
	Flue Preparation and Installation	10	23
	Electrical Connection	11	37
	Commissioning	12	40
	MAINTENANCE	Servicing	13
Fault Finding		14	49
Replacement of Parts		15	56
Spare Parts		16	69

WARNINGS

Gas Leak or Fault

Turn off the gas emergency control valve immediately. Eliminate all sources of ignition, i.e. smoking, blowlamps, hot air guns etc.

Do not operate electrical lights or switches either on or off. Open all doors and windows, ventilate the area.

Metal Parts

This boiler contains metal parts (components) and care should be taken when handling and cleaning, with particular regard to edges.

Sealed Components

Under no circumstances must the User interfere with or adjust sealed parts.

Important Information

Gas Category

This boiler is for use only on G20 natural gas.

Gas Safety (Installation and Use) Regulations

In your own interests and that of safety, it is the Law that ALL gas appliances are installed by a **competent person** in accordance with the current issue of the above regulations.

Control of Substances Hazardous to Health

Under Section 6 of The Health and Safety at Work Act 1974, we are required to provide information on substances hazardous to health.

The adhesives and sealants used in this appliance are cured and give no known hazard in this state.

Insulation Pads / Ceramic Fibre

These can cause irritation to skin, eyes and the respiratory tract.

If you have a history of skin complaint you may be susceptible to irritation. High dust levels are usual only if the material is broken.

Normal handling should not cause discomfort, but follow normal good hygiene and wash your hands before eating, drinking or going to the lavatory.

If you do suffer irritation to the eyes or severe irritation to the skin seek medical attention.

Manual Handling

With regards to the "Manual Handling Operations, 1992 Regulations", it should be noted that each appliance module exceeds the recommended weight for a one man lift.

Electrical Supply

The boiler MUST be earthed.

The boiler MUST be connected to a permanent 230V ac, 50Hz supply.

Connection of the whole electrical system of the boiler, including any heating controls, to the electrical supply MUST be through one common isolator and must be fused 3 Amp maximum.

Isolation should be by a double pole switched fused spur box, with a minimum gap of 3mm for both poles. The fused spur box should be readily accessible and preferably adjacent to the appliance. It should be identified as to its use.

Alternatively connection can be made through an unswitched shuttered socket and 3A fused 3-pin plug both to the current issue of BS 1363, provided they are not used in a room containing a bath or shower.

Wiring to the boiler must be PVC 85°C insulated cable, not less than 0.75mm² (24/0.20mm).

Immersion Heater - a thermostatically controlled immersion heater with manual reset is fitted to the cylinder as a back up for domestic hot water in the event of the boiler being inoperable. The immersion heater **MUST** be wired separately using 3kW 13amp wiring and in accordance with the relevant standards.

Testing and Certification

This boiler is tested and certificated for safety and performance. It is, therefore, important that no alteration is made to the boiler, without permission, in writing, by Glow-worm.

Any alteration not approved by Glow-worm, could invalidate the certification, boiler warranty and may also infringe the current issue of the statutory requirements.

CE Mark

This boiler meets the requirements of Statutory Instrument, No. 3083 The Boiler (Efficiency) Regulations, and therefore is deemed to meet the requirements of Directive 92/42/EEC on the efficiency requirements for new hot water boilers fired with liquid or gaseous fuels.

Type test for purposes of Regulation 5 certified by: Notified body 0087.

Product/production certified by: Notified body 0086.

The CE mark on this appliance shows compliance with:

1. Directive 90/396/EEC on the approximation of the laws of the Member States relating to appliances burning gaseous fuels.
2. Directive 73/23/EEC on the harmonisation of the Laws of the Member States relating to electrical equipment designed for use within certain voltage limits.
3. Directive 89/336/EEC on the approximation of the Laws of the Member States relating to electromagnetic compatibility.

Statutory Requirements

IMPORTANT

Where no British Standards exists, materials and equipment should be fit for their purpose and of suitable quality and workmanship.

The installation of this boiler must be carried out by a **competent person** in accordance with the rules in force in the countries of destination.

Manufacturer's instructions must not be taken as overriding statutory requirements.

Statutory Requirements

Installation of this boiler falls within the scope of the Building Regulations 1995 (Part G). This requires that the installation of an unvented system should be notified to the local authority Building Control Department and that the work must be carried out by a **competent person** as defined in the approved document G3.

In GB the installation of the boiler must comply with the requirements of the current issue of BS6798 and be carried out by a **competent person** as described in the following regulations:

The manufacturer's instructions supplied.

The Gas Safety (Installation and Use) Regulations.

The appropriate Buildings Regulations either The Building Regulations, The Building Regulations (Scotland), The Building Regulations (Northern Ireland).

The Water Fittings Regulations or Water byelaws in Scotland.

The Health and Safety at Work Act, Control of Substances Hazardous to Health (COSHH).

The Current I.E.E. Wiring Regulations.

Where no specific instructions are given, reference should be made to the relevant British Standard Code of Practice.

In IE, the installation must be carried out by a **competent person** and installed in accordance with the current edition of I.S.813 "Domestic Gas Installations", the current Building Regulations and reference should be made to the current ETCI rules for Electrical Installation.

In GB the following Codes of Practice apply:

BS4814, BS6798, BS5440 Part 1 and 2, BS5546 Part 1, BS5449, BS6891, BS6700, BS7074 Part 1 and 2, BS7593, BS7671.

In IE: I.S.813, BS5546, BS 5449, BS 7074, BS 7593.

NOTE: For further information, see the current issue of the Building Regulations, approved document L1 (in the UK) and the following current issues of:

1) Central heating system specification (CheSS)

and

2) Controls for domestic central heating system and hot water. BRECSU.

Gas Supply

The gas installation must be in accordance with the relevant standards.

In GB this is BS6891.

In IE this is the current edition of I.S.813 "Domestic Gas Installations".

The supply from the governed meter must be of adequate size to provide a steady inlet working pressure of 20mbar (8in wg) at the boiler.

On completion, test the gas installation for soundness using the pressure drop method and suitable leak detection fluid, purge in accordance with the above standard.

Domestic Hot Water

All domestic hot water circuits, connections, fittings must be in accordance with the relevant standards and water supply regulations.

For GB: Guidance G17 to G24 and recommendation R17 to R24 of the Water Regulations Guide.

For IE: The current edition of I.S.813 "Domestic Gas Installations".

Heating System

In GB it is necessary to comply with the Water Supply (Water Fittings) Regulations 1999 (for Scotland, the Water Byelaws 2000, Scotland).

To comply with the Water regulations your attention is drawn to: The Water Regulations guide published by the Water Regulations Advisory Service (WRAS) gives full details of the requirements.

In IE the requirements given in the current edition of I.S.813 "Domestic Gas Installations" and the current Building Regulations must be followed.

Electrical Supply

The electrical installation must be installed by a **competent person** and in accordance with the relevant standards.

The boiler and immersion heater must be earthed.

All system components shall be of an approved type and all wiring to current I.E.E. wiring regulations.

External wiring must be correctly earthed, polarised and in accordance with the relevant standards.

In GB this is BS 7671.

In IE this is the current edition of I.S.813 "Domestic Gas Installations"

Boiler Design

Boiler Design

This boiler is designed as a high efficiency central heating appliance, close coupled to an un-vented cylinder. The pumps, expansion vessels and associated safety devices are all fitted within the appliance, providing a one box solution for properties requiring a high domestic hot water demand. The intelligent control system is designed for both simple operation and maximum control. Once the controls are set the boiler will operate automatically.

Additionally a thermostatically controlled immersion heater with manual reset is fitted to the cylinder as a back up for domestic hot water in the event of the boiler being inoperable. It is intended for use as a back up should the boiler fail, it will not give optimum DHW performance.

Plumbing from flue terminal

Like all condensing boilers this appliance will produce a plume of condensation from the flue terminal in cool weather. This is due to the high efficiency and hence low flue gas temperature of the boiler. This is normal and not an indication of a fault.

Boiler Safety Devices

Electrical Supply Failure

The boiler will not work without an electrical supply.

Normal operation of the boiler should resume when the electrical supply is restored.

Reset any external controls, to resume normal operation of the central heating.

If the boiler does not resume normal operation press the reset button. If the boiler does not resume normal operation after this, refer to fault finding.

Overheating Safety

In the event of the boiler overheating the safety devices will cause a safety shutdown. A "Reset" may be required if a fault code ('F' followed by a number) appears on the digital display, refer to 'F' codes, section 14 Fault Finding. A manual reset button is also provided on the thermostat in the immersion heater.

Safety Discharge Valves

Three safety discharge valves and discharge pipes are fitted to the boiler, two PRV's and one pressure/temperature relief valve. The valves **must not** be touched.

Should there be any discharge from the pipes, isolate the boiler electrical supply and call your installer or Glow-worm's own service organisation using the telephone number on the inside front cover of this booklet.

Frost protection

The appliance has a built in frost protection device that protects the boiler from freezing. With the gas and electric supplies ON and irrespective of any room thermostat setting, the frost protection device will operate the pump when the temperature of the boiler water falls below 8°C.

After 10 minutes the pump will be stopped if the temperature is higher than 10°C or has already reached 35°C.

The burner will activate if the boiler temperature does not reach 10°C after 30 minutes or at any time if the temperature drops to 5°C.

The burner will switch off when the temperature reaches 35°C.

Frost protection is also built into the cylinder. Should the cylinder temperature fall below 10°C, the tank is re-heated to a temperature of 15°C.

The cylinder has a built in disinfection cycle which raises the water temperature to 70°C for 1 hour every Wednesday at 2:00am.

Condensate Drain Blockage

As a safety feature the boiler will stop working if the condensate drain becomes blocked. During freezing conditions this may be due to the forming of ice in the condensate drain external to the house. Release an ice blockage by the use of warm cloths on the pipe, the boiler should then restart.

Servicing, Maintenance and Spare Parts

Servicing and Maintenance

To ensure the continued efficient and safe operation of this boiler, it is recommended that it is checked and serviced as necessary at regular intervals. The frequency of servicing will depend upon the particular installation conditions and usage. If this boiler is installed in a rented property there is a duty of care imposed on the owner of the property by the current issue of the Gas Safety (Installation and Use) Regulations, Section 35.

Servicing/maintenance should be carried out by a **competent person** in accordance with the rules in force in the countries of destination.

"Benchmark" scheme

Glow-worm support the Benchmark initiative. It is very important that the service record is completed by the installation engineer and handed over to the user.

Spare Parts

Remember, when replacing a part on this appliance, use only spare parts that you can be assured conform to the safety and performance specification that we require. Do not use reconditioned or copy parts that have not been clearly authorised by Glow-worm.

If a part is required contact Glow-worm's own service organisation.

Please quote the name and model of the boiler.

The name badge is on the front of the appliance and the model type is positioned on the top edge of the tank module front panel.

If in doubt seek advice from the local gas company or Glow-worm's own service organisation using the telephone number on the inside front cover of this booklet.

1 Boiler Specifications

Data

All dimensions are given in millimetres (except as noted).


See diagram 2.1 and the Boiler Specification Table below.

The data label is positioned inside the boiler module on the base.

BOILER SPECIFICATION	100sxi	170sxi
Lift weight - Tank Module	39kg (86lb)	48kg (106lb)
- Boiler Module	50.5kg (111lb)	50.5kg (111lb)
Total weight (installed inclusive water)	175kg (385lb)	225kg (495lb)
Gas connection Ø O.D.	22mm. copper (15mm on jig)	22mm. copper (15mm on jig)
Heating and return connection Ø O.D.	22mm. copper	22mm. copper
Domestic hot water connection Ø O.D.	22mm. copper	22mm. copper
Condensate connection Ø I.D.	21.5mm. plastic	21.5mm. plastic
Safety valve discharge connection Ø O.D.	22mm. copper	22mm. copper
CH safety valve (preset)	3 bar (43/5lbf/in ²)	3 bar (43/5lbf/in ²)
Heating system minimum pressure	0.7bar (10.1lbf/in ²)	0.7bar (10.1lbf/in ²)
Maximum flow temperature	82°C	82°C
DHW recovery from 15°C to 65°C	10 mins	17 mins
DHW recovery from 70% draw off	9 mins	12 mins
CH Expansion vessel capacity	10 litres (2.2 gallons)	10 litres (2.2 gallons)
CH Expansion vessel charge pressure	0.75bar (11lbf/in ²)	0.75bar (11lbf/in ²)
DHW Expansion vessel capacity	12 litres	12 litres
DHW Expansion vessel capacity pre charge	3 bar (44lbf/in ²)	3 bar (44lbf/in ²)
Pressure reducing valve (preset)	3.5 bar (51.5lbf/in ²)	3.5 bar (51.5lbf/in ²)
Pressure and temp relief valve	90°C and 7 bar	90°C and 7 bar
Pressure relief valve on inlet manifold	6 bar (88lbf/in ²)	6 bar (88lbf/in ²)
Electrical supply	230V~50Hz	230V~50Hz
Electrical rating	210W fused 3A	210W fused 3A
IP classification	X4D	X4D
Internal fuse rating on main PCB	2A	2A
Gas supply (governed meter only)	l ₂ H G20 natural gas	l ₂ H G20 natural gas
Inlet gas working pressure	20mbar	20mbar
Burner % CO ₂ case on (after 5 mins)	9.2 nominal	9.2 nominal
Burner % CO ₂ case off (after 5 mins)	9 nominal	9 nominal
Approximate max. gas rate after 10 mins. from cold	3.30 m ³ /hr 116.5 ft ³ /hr	3.30 m ³ /hr 116.5 ft ³ /hr
DHW - Heat input NETT Q = kW	31.6 max. 8.9 min.	31.6 max. 8.9 min.
DHW - Heat output NETT Q = kW	31.6 max. 8.9 min.	31.6 max. 8.9 min.
CH - Heat input	24.5kW	24.5kW
CH - Heat output	24.33kW	24.33kW
Flue type	C13, C33, C53	C13, C33, C53
NOx	Class 5	Class 5

13340

1 Boiler Specifications



13247

Diagram 2.1

1 Boiler Specifications

13290




Diagram 2.2

2 Boiler Location, Clearances and Ventilation

2.1 Location

This boiler is not suitable for outdoor installation.

This boiler may be installed in any room, although particular attention is drawn to the installation of a boiler in a room containing a bath or shower where reference must be made to the relevant requirements.

This boiler is suitable for installation in bathroom zones 2 and 3.

In GB this is the current I.E.E. WIRING REGULATIONS and BUILDING REGULATIONS.

In IE reference should be made to the current edition of I.S.813 "Domestic Gas Installations" and the current ETCI rules.

2.2 Clearances

The boiler should be positioned so that at least the minimum operational and servicing clearances are provided, see diagram 2.1.

Additional clearances may be beneficial around the boiler for installation and servicing.

For flue installations where external access is not practicable, consideration should be given for the space required to insert the flue internally, which may necessitate a clearance larger than those specified in diagram 2.1.

2.3 Timber Frame Buildings

If the boiler is to be installed in a timber frame building it should be fitted in accordance with the Institute of Gas Engineers document IGE/UP/7/1998. If in doubt seek advice from local gas undertaking or Glow-worm.


2.4 Room Ventilation

The boiler is room sealed so a permanent air vent is not required.


2.5 Cupboard or Compartment Ventilation

Due to the high efficiency and hence low casing temperature of this boiler, cupboard or compartment ventilation is not necessary.

Leave existing air vents.



3 Flue Options and Terminal Clearances



3.1 Flue Options

There are various flue options to choose from as illustrated in diagram 3.3. The flue lengths and installation are described in section 10.

3.2 Flue Terminal Position

The minimum acceptable siting dimensions for the terminal from obstructions, other terminals and ventilation openings are shown in diagram 3.1. For Ireland the minimum distances for flue terminal positioning must be those detailed in I.S.813 "Domestic Gas Installations".

The terminal must be exposed to the external air, allowing free passage of air across it at all times.

Being a condensing boiler some plumbing may occur from the flue outlet. This should be taken into consideration when selecting the position for the terminal.

NOTE: If necessary it is permitted to increase the terminal protrusion through the outside wall to greater than the minimum dimension of 87mm but no more than 600mm.

Carports or similar extensions of a roof only, or a roof and one wall, require special consideration with respect to any openings, doors, vents or windows under the roof. Care is required to protect the roof if made of plastic sheeting. If the carport comprises of a roof and two or more walls, seek advice from the local gas supply company before installing the boiler.

H* and J* See diagram 3.1. These dimensions comply with the building regulations, but they may need to be increased to avoid wall staining and nuisance from plumbing depending on site conditions.

Plume Management Kit: Part No.A2044100 (white) or A2044000 (black) can be used to overcome many site issues.

3.3 Terminal Guard

A terminal guard is required if persons could come into contact with the terminal or the terminal could be subject to damage.

If a terminal guard is required, it must be positioned to provide minimum of 50mm clearance from any part of the terminal and be central over the terminal.

The guard should be similar to that shown in diagram 3.2.

A suitable guard is manufactured by: -


Tower Flue Components

Morley Rd.

Tonbridge


Kent TN9 1RA.

Size: 280mm x 280mm x 270mm.




3 Flue Options and Terminal Clearances


Flue Options



Top horizontal telescopic flue Ø60/100
Part No. A2043600




Top horizontal standard flue Ø60/100
Part No. A2043400



Plume Management Kit


Basic set, concentric flue Ø60/100
White - Part No. A2044100
Black - Part No. A2044000
for use with Part No. A2043400
and Part No. A2043600



Vertical Flue

Vertical Flue Adapter,
concentric flue Ø60/100
Part. No. A2024600

Vertical flue terminal kit,
concentric flue Ø60/100
Part. No. 2000460480



Twin Flue

Twin Flue Adapter,
concentric flue Ø80
Part No. A2011000

13245

Diagram 3.3

4 Heating System

General

The boiler is for use only with sealed central heating systems.

The digital readout on the controls fascia indicates the system pressure when there is no demand.

The circulation pump is integral with the boiler.

4.1 Safety Valve

The safety valve is factory fitted and is an integral part of the boiler and it must not be adjusted or used for any other purpose. The pipe from the safety discharge valve must not discharge above an entrance, window or any type of public access area.

4.2 Expansion Vessel

The boiler has an integral expansion vessel with a capacity of 10 litres (2.2 gallons), with a charge pressure of 0.75bar.

NOTE: The expansion vessel volume depends on the total water system volume and the initial system design pressure. Guidance on vessel sizing is also given in the current issue of BS5449 and BS7074 Part 1, for IE refer to the current edition of I.S.813 "Domestic Gas Installations".

4.3 Flow Rate

If it is necessary to alter the flow rate, the system can be fitted with a lockable balancing valve in the main flow or return pipes shown as valve "A" in diagram 4.1.

4.4 Bypass

The boiler is fitted with an automatic adjustable bypass.

Diagram 4.2 shows the pump head remaining for the heating system depending on the bypass setting and the speed setting of the pump, see section 12 Commissioning.

4.5 Filling the Sealed System

NOTE: The water pressure at the boiler must be at least 0.7bar to enable filling the boiler to a minimum pressure. The boiler is supplied with a filling device, see diagrams 4.1 and 12.2.

4.6 Water Treatment

In the case of an existing system, it is **ESSENTIAL** that prior to installing the new boiler the system is thoroughly flushed. For optimum performance after installation of a new system, the boiler and its associated central heating system should also be flushed. Flushing should be carried out in accordance with BS7593: 1992 using a cleanser such as Sentinel X300 or X400, Fernox Restorer or Salamander corrosion guard cleaner.

For long-term corrosion protection, after flushing, an inhibitor suitable for stainless steel exchangers should be used, refer to the current issue of BS 5449 and BS 7593 on the use of inhibitors in central heating systems. Examples are Sentinel X100 Fernox Protector or Salamander corrosion guard inhibitor.




Diagram 4.1

4 Heating System




Diagram 4.2

5 Domestic Hot Water

General

All domestic hot water circuits, connections, fittings must be in accordance with the relevant standards and water supply regulations.

The boilers are suitable for connection to most types of washing machine and dishwasher appliances.

When connecting to suitable showers, ensure that:

- The cold water inlet to the boiler is fitted with an approved anti-vacuum or siphon non-return valve.
- Hot and cold water supplies to the shower are of equal pressure

5.1 Water Pressure Flow Rate

This boiler will operate satisfactorily at low water inlet pressure, however for optimum performance it is recommended that 22mm feed pipe is used with an inlet pressure, at the appliance, of 2 bar.

NOTE: Higher pressure can be tolerated as the boiler is fitted with a pressure reducing valve set at 3.5 bar.

5.2 'Hard' Water Areas

The temperatures within the heat exchanger are limited by the boiler control system to minimise scale formation within the hot water pipework. However, in areas where the water is 'hard' (i.e. more than 200mg/litre), it is recommended that the hot water setting is reduced and that a scale reducer is fitted, refer to the manufacturer's instructions or consult the local water company for additional advice.

5.3 Expansion Vessel

The boiler has an integral expansion vessel with a capacity of 12 litres (2.6 gallons), with a charge pressure of 3 bar.

NOTE: The expansion vessel volume depends on the total water system volume and the initial system design pressure.

Guidance on vessel sizing is also given in the current issue of BS5449 and BS7074 Part 1, for IE refer to the current edition of I.S.813 "Domestic Gas Installations".

5.4 Draining Point

A draining point is provided at the bottom of the hot water storage tank located next to the condensate drain, see diagram 6.1.

5.5 Safety Valves

The safety valves are factory fitted and an integral part of this boiler and they must not be adjusted or used for any other purpose. The pipe from the safety discharge valve must not discharge above an entrance, window or any type of public access area.




Diagram 5.1

5 Domestic Hot Water

5.6 SYSTEM REQUIREMENTS – Domestic Hot Water

Domestic Hot Water Requirements

NOTE: Attention is drawn to the following extracts from the Building Regulations 1991.

Regulation 11(1) (Giving of a building notice or deposit of plans)

“Subject to the following provisions of this regulation, a person who intends to carry out building work or to make a material change of use shall:

- a) Give to the local authority* a building notice in accordance with 12; or
- b) Deposit full plans with the local authority* in accordance with regulation 13”.

Regulation 12(4) (Particulars and plans where a building notice is given)

“.....a building notice shall be accompanied by a statement which specifies:

*Attention is drawn to regulation 18 (supervision of building work otherwise than by local authorities).

- a) The name, make, model and type of hot water storage system to be installed;
- b) The name of the body, if any, which has approved or certified that the system is capable of performing in a way which satisfies the requirements of paragraph G3 of Schedule 1;
- c) The name of the body, if any, which has issued any current registered operative identity card to the installer or proposed installer of system.”

Regulation 13(3) (Full plans)

“Full plans shall consist of:

- a) Description of the proposed building work or material change of use, and the plans, particulars and statements required by paragraphs (1) to (4) of regulation 12: and

NOTE:

Bye-laws of the appropriate Water Undertake also apply.

Discharge Pipework

It is a requirement of Building Regulation G3 that any discharge from an unvented system is conveyed to where it is visible but will not cause danger to persons in or about the building. The tundish and discharge pipes should be fitted in accordance with requirements and guidance notes of Building Regulation G3. The G3 Requirements and Guidance section 3.9 are reproduced in the following sections. Information Sheet No. 33 available from the British Board of agreement gives further advice on discharge pipe installation. For discharge pipe arrangements not covered by G3 Guidance or BBA info sheet no. 33 advice should be sought from your local Building Control Officer.

G3 Requirement

“....there shall be precautions..... to ensure that the hot water discharged from safety devices is safely conveyed to where it is visible but will not cause danger to persons in or about the building”.

G3 Guidance SECTION 3.9

The discharge pipe (D1) from the vessel up to and including the tundish is generally supplied by the manufacturer of the hot water storage system. Where otherwise, the installation should include the discharge pipe(s) (D1) from the safety device(s). In either case the tundish should be vertical, located in the same space as the unvented hot water storage system and be fitted as close as possible and within 500mm of the safety device e.g. the temperature relief valve.

NOTE: The tundishes are factory fitted during manufacture. The discharge pipe (D2) from the tundish should terminate in a safe place where there is no risk to persons in the vicinity of the discharge, preferably be of metal and:

- a) Be at least one pipe size larger than the nominal outlet size of the safety device unless its total equivalent hydraulic resistance exceeds that of straight pipe 9m long i.e. discharge pipes between 9m and 18m equivalent resistance length should be at least two sizes larger than the nominal outlet size of the safety device, between 18 and 27m at least 3 sizes larger and so on. Bends must be taken into account in calculating the flow resistance.

An alternative approach for sizing discharger pipes would be to follow BS67100:1987 specification for design installation, testing and maintenance of services supplying water for domestic use within buildings and their curtilages. Appendix E section E2 and table 21.

- b) Have a vertical section of at least 300mm long, below the tundish before any elbows or bends in the pipework.
- c) Be installed with a continuous fall.
- d) Have discharges visible at both the tundish and the final point of discharge but where this is not possible or is practically difficult there should be clear visibility at one or other of these locations. Examples of acceptable discharge arrangements are:

- i) Ideally below a fixed grating and above the water seal in a trapped gully.
- ii) Downward discharges at low level; i.e. up to 100mm above external surfaces such as car parks, hard standings, grassed areas etc. are acceptable providing that where children may play or otherwise come into contact with discharges a wire cage or similar guard is positioned to prevent contact whilst maintaining visibility.

- iii) Discharges at high level; e.g. into a metal hopper and metal down pipe with the end of the discharge pipe clearly visible (tundish visible or not) or onto a roof capable of withstanding high temperature discharges of water and 3m from any plastic guttering system that would collect such discharges (tundish visible).

- iv) Where a single pipe serves a number of discharges, such as in blocks of flats, the number served should be limited to not more than 6 systems so that any installation discharging can be traced reasonably easily. The single common discharge pipe should be at least one pipe size larger than the largest individual discharge pipe (D2) to be connected. If unvented hot water storage systems are installed where discharges from safety devices may not be apparent i.e. in dwellings occupied by blind, infirm or disabled people, consideration should be given to the installation of an electronically operated device to warn when discharge takes place.

5 Domestic Hot Water

NOTE: The discharge will consist of scalding water and steam. Asphalt, roofing felt and non-metallic rain water goods may be damaged by such discharges.

Worked example of discharge pipe sizing

The example given in diagram 6.2 is for a G1/2 temperature relief valve with a discharge pipe (D2) having 4 No. elbows and length of 7m from the tundish to the point of discharge.

From Table 1:

Maximum resistance allowed for a straight length of 22mm copper discharge pipe (D2) from a G1/2 temperature relief valve is 9.0m.

Subtract the resistance for 4 No. 22mm elbows at 0.8m each = 3.2m.

Therefore the permitted length equates to 5.8m.

5.8m is less than the actual length of 7m therefore calculate the next largest size. Maximum resistance allowed for a straight length of 28mm pipe (D2 from a G1/2 temperature relief valves equates to 18m. Subtract the resistance of 4 No. 28mm elbows at 1.0m each: 4.0m.

Therefore the maximum permitted length equates to: 14m. As the actual length is 7m a 28mm min (D2) copper pipe will be satisfactory.


WARNING:

- Under no circumstances should the factory fitted temperature/pressure relief valve be removed other than by authorised personnel. To do so will invalidate any warranty claim.
- Table 1. Sizing of copper discharge pipe (D2).
- Control and safety valves **MUST NOT** be tampered with.
- The discharge pipe **MUST NOT** be blocked or used for any other purpose.
- The tundish is factory fitted and **MUST NOT** be removed.

TABLE 1

Valve outlet size	G 1/2
Discharge pipe D1	15mm
Discharge pipe D2 from tundish	22mm
Maximum resistance allowed, expressed as a length of straight pipe (i.e. no elbow or bends)	up to 9m
Resistance created by each elbow or bend	0.8m

13449



12529

6 Condensate Drain

6.1 Condensate Drain

A plastic drain pipe must be fitted to allow discharge of condensate to a drain.

Condensate should, if possible, be discharged into the internal household draining system. If this is not practical, discharge can be made externally into the household drainage system or a purpose designed soak away, see diagram 6.1 for more details.

6.2 Condensate Connection

A flexible condensate connection pipe is supplied and should be used to connect to a drain outlet pipe 22mm to 25mm OD. non corrosive plastic. The drain outlet pipe should have a fall of at least 2.5° away from the boiler.


It is recommended that any external condensate drain pipe is insulated and also preferably of 32mm diameter, to prevent freezing in adverse weather conditions.

The condensate is discharged periodically in 'slugs' by siphonic action.


It is not necessary to provide air breaks or extra traps in the discharge pipe as there is already a trap inside the boiler. Fitting an extra trap may cause the boiler siphon to work incorrectly.

6 Condensate Drain


13443




Internal Soil and Vent Pipe




External Soil and Vent Pipe or Rainwater Pipe




External Termination to a Gully or Hopper



Internal Termination into Combined Sink Waste



Internal Termination Downstream of Sink Waste




External Termination into Soakaway

NOTE: PIPEWORK SHOULD ALWAYS FALL AWAY FROM BOILER BY AT LEAST 2.5 44mm FOR EVERY 1M.


Diagram 6.1

7 Installation Preparation



PLUMBING JIG

13405



13248

Diagram 7.1

7 Installation Preparation

7.1 Loose Items Pack

Please check the contents of loose items pack as shown in diagram 7.1.

The plumbing jig is located within the tank module polystyrene top pack.

7.2 Site Requirements

The appliance should be sited on a level floor, however slight adjustment can be made using the adjustable feet at the base of the tank module.

The floor strength should be suitable for the combined weight of appliance and water:

100sxi 175kg

170sxi 225kg

NOTE: Due to the varied site conditions we do not supply fixings and advise that the installer should supply those which are suitable.

7.3 Floor Template

Take the floor template from the loose items pack and place in the desired position on the floor, giving due consideration to the required boiler clearances, see diagram 2.1, and the flue you are fitting.

Mark the position of the flue center, if fitting a side flue, extend the flue centerline into the corner then along the adjacent wall, see diagram 7.2.

For extended side flues, the flue hole centre should be determined by extending the dashed inclined line on the template to the side wall. This dashed line is drawn at 44mm/metre (2.5°) rise from the boiler. Where this line reaches the side wall, a horizontal line should be marked. The vertical centre line of the flue should then be marked on the back wall.

To allow for the flue passing through the wall at this angle a 125mm hole should be drilled irrespective of internal or external installation.

7.4 Flue Hole Cutting

External access flue installation can use a 105mm diameter core drill.

Internal access only flue installation will need a 125mm diameter core drill.



NOTE: The flue is designed with an internal fall of 44mm/metre (2.5°), therefore the hole can be drilled horizontally.

If flue extension pipes are to be used then a core drill size of 125mm is required. This will allow the extension pieces to slope at 44mm/metre (2.5°) towards the boiler.

7.5 Plumbing Jig

Align the template with the flue hole then mark the position of the fixing holes for the jig, see diagram 7.3.

Align the location notches on the jig and secure to the floor using suitable screws.



8 Gas, Water & Boiler Connection

8.1 Systems Connection

The water and gas isolation valve connections are on the jig.

The condensate drain and safety discharges connections are not on the jig but their pipe runs are shown on the template.

Assemble the copper tails and washers to the jig, secure, then plumb the system as shown in diagram 8.1. taking into account the need to plumb the condensate and safety valves also.

NOTE: Do not subject isolation valves to heat.

Slacken the test point screw, see diagram 8.1, connect a manometer.

The whole of the gas installation, including the meter, should be inspected, tested for soundness and purged in accordance with the current issue of BS6891 and in IE the current edition of I.S.813 "Domestic Gas Installations".

Remove the manometer and secure the test point screw.

On completion of system connections and as an aid to installation, slacken the jig securing screws, this will allow a greater tolerance of site conditions when connecting the isolation valves to the boiler.

IMPORTANT: With regards to the Health and Safety Manual Handling requirements, two persons shall be required to lift the appliance. It should be noted that the appliance is made up of two modules each module requiring two persons to lift.

8.2 Tank Module Connection

IMPORTANT: The electrical cables to the boiler and the immersion heater need to be routed before the installation of the tank module.

Remove the tank module top polystyrene packing, then the carton sleeve.

Pull the tank module front panel forward off the retaining clips.

Slide the tank module into position over the jig and align with the isolation valves.

NOTE: If there is restricted clearance where the boiler is to be located, the tank and boiler modules can be assembled before sliding into position over the jig.

Position the plastic sealing washers as shown in diagram 8.3 and connect the isolation valves. The pipe retaining bracket can be slackened to ease connection.





Diagram 8.1

8 Gas, Water & Boiler Connection



8.3 Boiler Module Connection


Unpack the boiler module from its carton.

Position the boiler on top of the tank ensuring the correct engagement of the locating pins, see diagram 8.3.

Remove the front panel securing screws and lift the panel off at the top locating bracket.

Position the plastic sealing washers as shown in diagram 8.3 and secure to the pipes to the connectors beneath the boiler as shown in diagram 8.2.

On completion secure the pipe retaining bracket if previously slackened and level the boiler using the adjustable feet.





9 Condensate & Safety Discharge Valve Connections

9.1 Safety Discharge Valve

The pipes must be extended, using not less than 22mm o.d. pipe, to discharge, in a visible position, outside the building, facing downwards, preferably over a drain.

The pipe must have a continuous fall and be routed to a position so that any discharge of water, possibly boiling, or steam cannot create any danger to persons, damage to property or external electrical components and wiring.

It is advisable to use a 22mm compression elbow to aid in future servicing, see diagram 9.1.




9.2 Condensate Drain Connection

A flexible condensate hose runs from a push-fit connection at the bottom of the heat exchanger and terminates on the boiler module base plate, see diagram 8.2.

Connect the flexible condensate hose to the boiler module, see diagram 9.2.

A flexible condensate connection pipe is supplied in the loose items pack and should be fitted between the condensate trap & siphonic drain to the condensate drain pipe, see diagram 9.3, and refer to section 6 to discharge condensate



10 Telescopic Flue - Length, Preparation and Installation

10.1 Flue Length

The maximum achievable rear and side flue length for a telescopic flue, diagram 10.2, is as shown in diagram 10.1.

The maximum permissible horizontal flue length is 8 metres plus the flue terminal assembly, this can be achieved by use of the accessories, see diagram 10.3, however should additional 90° or 2 x 45° elbows be used then the length MUST be reduced by 1metre.


When extension pipes are used the flue system must be designed to have a continuous fall to the boiler of at least 2.5° 44mm/metre to allow condensate to run back into the boiler and out via the condensate trap & siphonic drain.

The flue can be installed from inside the building, when access to the outside wall face is not practicable.

The diagrams below describe the lengths achievable without the use of extensions or elbows.

Horizontal Telescopic Flue


* NOTE. If necessary, it is permitted to increase this dimension to 600mm max.



13337

* NOTE. If necessary, it is permitted to increase this dimension to 600mm max.



A
Max. distance from outside wall face to min clearance. LH - 269mm RH - 482mm
Min. distance from outside wall face to min clearance. LH - 75mm RH - 75mm



13339

Diagram 10.1

10 Telescopic Flue - Length, Preparation and Installation



10 Telescopic Flue - Length, Preparation and Installation

10.2 Horizontal Telescopic Flue

Refer to diagram 10.2 for kit contents.

10.3 REAR Flue

If a wall thickness is between 233mm min. to 522mm max. then the flue can be used without extensions.

With the flue elbow temporarily fitted, measure the distance from the outside wall to the butt joint, see diagram 10.4. If the measurement 'Y' exceeds 522mm, then the appropriate length of extension pipe is required.

If the dimension is less than 320mm DO NOT cut the flue, it can project to a maximum of 600mm, if this is not desirable then a Standard flue MUST be used and cut to length.

10.4 SIDE Flue

With the flue elbow temporarily fitted, measure the distance from the outside wall to the butt joint, see diagram 9.6. If the measurement 'Y' exceeds LH 204mm, RH 417mm, then the appropriate length of extension pipe is required.

If the dimension is less than 320mm DO NOT cut the flue, it can project to a maximum of 600mm, if this is not desirable then a Standard flue MUST be used and cut to length.

10.5 Flue Fitting

With the air duct seams aligned and the flue set to the required length 'Y', mark the securing hole position in the air duct. Drill a 3mm diameter hole at this position, take care not to pierce the inner flue duct. Secure with screw provided and tape the joint, see diagram 10.7.

Fit the sealing collar onto the locating ring on the flue terminal, see diagram 10.8.

With the flue elbow removed, push the flue assembly into the wall, externally or internally, until the end of the assembly protrudes a short way from the inside face of the wall. This will enable the internal trim ring (if required) to be positioned and allow the flue assembly to be drawn back up to the flue elbow.

Secure the flue elbow in position on top of the boiler with four torque headed screws supplied.

Draw the flue assembly from wall and engage the flue duct into the elbow and butt fit between the air duct and flue elbow.

Check the correct alignment of the flue.




Fit the securing collar in position, mark through two of the pre drilled holes in the securing collar. Remove securing collar and drill two 3mm diameter holes one in the elbow and one in the air duct, take care not to pierce the inner flue duct. Fit the securing collar and secure with screws provided, see diagram 10.9.

Slide the internal trim ring back against the wall, securing in place with a small amount of sealant if required.




The cut ducts must be de-burred and all filings and debris removed.

Insert the flue duct into the air duct terminal assembly, remembering to engage the catch within the terminal.

NOTE: If the seals require lubricant to ease installation, do not use mineral oils or grease, only silicon grease or water is recommended.



10 Telescopic Flue - Length, Preparation and Installation



10 Standard Flue - Length, Preparation and Installation

10.6 Flue Length

The maximum achievable rear and side flue length for a standard flue, diagram 10.12, is as shown in diagram 10.11.

The maximum permissible horizontal flue length is 8 metres plus the flue terminal assembly, this can be achieved by use of the accessories, see diagram 10.13, however should additional 90° or 2 x 45° elbows be used then the length MUST be reduced by 1metre.


When extension pipes are used the flue system must be designed to have a continuous fall to the boiler of at least 2.5° 44mm/metre to allow condensate to run back into the boiler and out via the condensate trap & siphonic drain.

The flue can be installed from inside the building, when access to the outside wall face is not practicable.

The diagrams below describe the lengths achievable without the use of extensions or elbows.

Standard Horizontal Flue


★ NOTE. If necessary, it is permitted to increase this dimension to 600mm max.



13401

★ NOTE. If necessary, it is permitted to increase this dimension to 600mm max.



A
Max. distance from outside wall face to min clearance. LH - 334mm RH - 547mm
Min. distance from outside wall face to min clearance. LH - 75mm RH - 75mm



13338

Diagram 10.11

10 Standard Flue - Length, Preparation and Installation



10 Standard Flue - Length, Preparation and Installation

10.7 Standard Horizontal Flue

Refer to diagram 10.12 for kit contents.

10.8 REAR Flue

With the flue elbow temporarily fitted, measure the distance from the outside wall to the butt joint, see diagram 10.14. If the measurement 'Y' exceeds 667mm, then the appropriate length of extension pipe is required. The minimum dimension is 156mm to suit a 75mm min wall thickness. The flue can project to a maximum of 600mm, if this is desirable, refer to diagram 10.16.

10.9 SIDE Flue

With the flue elbow temporarily fitted, measure the distance from the outside wall to the butt joint, see diagram 10.15. If the measurement 'Y' exceeds 667mm, then the appropriate length of extension pipe is required. The minimum dimension for LH is 408mm and RH 195mm to suit a minimum wall thickness of 75mm. The flue can project to a maximum of 600mm, if this is desirable, refer to diagram 10.16.

10.10 Flue Fitting

Remove the flue elbow.

Separate the flue duct from the terminal by twisting to release the terminal catch, then pull out of the retaining seal, refer to diagram 10.17.

The flue duct cutting length (L + 11mm.) is shown in diagram 10.17.

The air duct should be cut at the opposite end to the terminal

The plastic flue duct **MUST** be cut at the opposite end to the terminal catch.

The plastic flue duct extensions **MUST** be cut at the opposite end to seal.

The cut ducts must be de-burred and all filings and debris removed.




Insert the flue duct into the air duct terminal assembly, remembering to engage the catch within the terminal.

NOTE: If the seals require lubricant to ease installation, do not use mineral oils or grease, only silicon grease or water is recommended.

Fit the sealing collar onto the locating ring on the flue terminal, see diagram 10.8.

Push the flue assembly into the wall, externally or internally, initially until the end of the assembly protrudes a short way from the inside face of the wall. This will enable the internal trim ring (if required) to be positioned and allow the flue assembly to be drawn back into the flue elbow.

Secure the flue elbow in position on top of the boiler with four torque headed screws supplied.



10 Standard Flue - Length, Preparation and Installation



Draw the flue assembly from wall and engage the flue duct into the elbow and butt fit between the air duct and flue elbow.

Ensure the correct alignment of the terminal.

Fit the securing collar into position, mark through two of the pre drilled holes in the securing collar. Remove securing collar and drill two 3mm diameter holes one in the elbow and one in the air duct, take care not to pierce the inner flue duct. Fit the securing collar and secure with screws provided, see diagram 10.18.

Slide the internal trim ring back against the wall, securing in place with a small amount of sealant if required.

NOTE: If the air and flue ducts have been correctly cut to the instructions the sealing collar should fit flush with the outside wall.




10 Vertical Flue - Length, Preparation and Installation

10.11 Vertical flue


The vertical flue system is available as an option where the boiler position does not permit the use of the top outlet horizontal concentric flue pack.

The system is made up of accessories. The accessories include terminal assembly, bends 45° and 90°, flue extensions, fixing bracket and appropriate weather collar, see diagram 10.20.

The maximum permitted straight flue length is 12 metres plus the terminal. for each 90° or 2x45° bends fitted, the maximum length must be reduced by 1 metre, see diagram 10.19.



10 Vertical - Flue Length, Preparation and Installation



NOTE: 2x45° bends can replace 1x90° bend if necessary. When using 90° bends any horizontal extension pipe should be inclined by a minimum of 44mm/metre (2.5°) towards the boiler to facilitate condensate removal, see (a) in diagram 10.19.

Alternatively use 45° bends to avoid horizontal runs, see (b) in diagram 10.19.

The terminal should be positioned at least 600mm from any opening into the building, refer to diagram 3.2.

Measure the distance of flue length required for the installation.

The flue must be designed with a continuous fall towards the boiler.

Flue Terminal Installation

Refer to diagram 10.21. Secure the flue adapter in position on top of the boiler with four torx headed screws supplied, making sure the nib fits into the locating slot in the boiler casing to ensure correct orientation.

The rubber 'O' rings of each section should be lubricated prior to assembly.

NOTE: Do not use mineral oils or grease, silicon grease or water is recommended.

Secure the first extension pipe to the flue adapter with the securing collar supplied by positioning the collar centrally over the joint, then tighten the two screws on the securing collar, see diagram 10.22.

Fit more extension pipes as required using the collar and screws supplied with each extension pipe. To fit position the collar centrally over the joint, tighten the two screws on the securing collar. Using the holes provided in the securing collar, drill and insert the two self tapping screws supplied, see diagram 10.23.

The rubber 'O' rings of each section should be lubricated prior to assembly.

NOTE: Do not use mineral oils or grease, silicon grease or water is recommended.

When building the flue up it is recommended that it is supported every 2 metres and at every bend by a fixing bracket.

Project the rise of the flue pipe to roof level and cut a 150mm hole in the roof.

10 Vertical Flue - Length, Preparation and Installation

Flue Terminal Installation

(a) Pitched Roof

Fit the required pitched roof weather collar over the 150mm hole in the roof. Make good the tiling or slating around the collar incorporating the flashing of the weather collar. Position the angle cap over the weather collar in the correct orientation to attain the correct angle for your roof.





(b) Flat Roof

Fit the aluminium weather collar over the 150mm hole in the roof ensuring a weather tight seal.


From above carefully place the flue terminal through the weather collar.

Completion of Installation

With the flue terminal positioned in the roof the length of the final pipe can be determined. If a telescopic length cannot be used, then a standard flue length can be cut to make the correct length. Cut the flue to the desired length measuring from the 'O' ring end and discard the plain end of the tube. The cuts must be square and made free of burrs to allow correct assembly. **(NOTE: The flue pipe is 10mm longer than the air pipe),** see diagram 10.24. Carefully push the terminal assembly upwards to allow room for fitting the final flue piece. Fit a fixing bracket to the terminal assembly. Pull the terminal assembly down and join to the flue system. Ensure that the terminal is making a weather tight seal on the weather collar. Secure the fixing bracket fitted to the terminal to the roofing struts or a purpose made baton.




10 Twin Flue - Length, Preparation and Installation



13320

Diagram 10.25

10 Twin Flue - Length, Preparation and Installation



10.12 Twin flue

The twin flue system is available as an option when the top outlet horizontal concentric rear or vertical flue system is not appropriate, see diagram 10.25.

The system is made up of accessories. The accessories include terminal assembly, bends 45° and 90°, flue extensions, fixing bracket and appropriate weather collar, see diagram 10.26.

The system can provide an independent horizontal air inlet and flue outlet, horizontal air inlet and vertical flue outlet or vertical air inlet and flue outlet via a concentric terminal.

NOTE: The air and flue outlets do not have to be equal lengths. 2x45° bends can replace 1x90° bend if necessary.

The maximum permitted combined straight pipe length is 40 metres plus terminal assemblies, for each 90° or 45° x 2 bends fitted, the maximum length must be reduced by 1 metre.

NOTE: When using 90° bends any horizontal run should be inclined by a minimum of 44mm/metre (2.5°) towards the boiler to facilitate condense removal.

Alternatively use 45° bends to avoid horizontal runs in the flue pipe.

Terminal Position

The clearances for a flue outlet are given in the "Flue Location and Ventilation" section.

In addition the horizontal air inlet must not be closer than 300 mm from a flue outlet on the same wall or 1200mm from an opposing flue outlet.

10 Twin Flue - Length, Preparation and Installation

Installation Details

The parts available for a twin flue system installation are shown in diagram 10.26.

Boiler Connection

Push the twin flue adaptor onto the outlet of the boiler with the air inlet to the left hand side. Secure the adaptor to the top panel with the screws provided. Care should be taken when inserting the screw through the hole in adaptor top.

To facilitate engagement, it is recommended that the rubber 'O' rings are lubricated with silicone grease or water prior to assembly.

Air and Flue Pipe Installation

The air and flue pipes can now be built up from the boiler.

The flue must be designed with a continuous fall towards the boiler. If using the horizontal flue pipe or 90° bends the pipe must be inclined at 44mm/metre (2.5°) minimum, see diagram 9.25.

Alternatively if space allows, use 45° bends in place of 90° bends.

The rubber 'O' rings of each section should be lubricated prior to assembly with silicone grease.

When building the flue up it is recommended that it is supported every 2 metres and at every bend by a fixing bracket.

Horizontal Terminal Installation

With due consideration to terminal clearances mentioned in Section 3.2 drill the one or two holes as required with a 90mm core drill.

Push the horizontal terminal through the wall allowing approx. 100mm to protrude outside.

Push a grey rubber wall seal onto either side of the wall ensuring that both wall seals are pushed up to the wall surface, see examples (b) and (c) diagram 9.25.

Vertical Terminal Installation

With due consideration to terminal clearances mentioned in Section 3.2, project the rise of the flue pipe to roof level and cut 150mm hole in the roof.

(a) Pitched Roof

Fit the required pitched roof weather collar over the 150mm hole in the roof. Make good the tiling or slating around the collar incorporating the flashing of the weather collar. Position the angle cap over the weather collar in the correct orientation to attain the correct angle for your roof. One way round gives a pitch of 25°-38° and the other gives 37°- 50°.

(b) Flat Roof

Fit the aluminium weather collar over the 150mm hole in the roof ensuring a weather tight seal.




Diagram 10.27

Horizontal Pipes-Completion of Installation

Having built the pipe(s) from the boiler to the terminal(s), the length of the final pipe piece can be determined. Cut pipes at the opposite end to the 'O' ring seal making square and free from burrs. Push the horizontal terminal through the wall to engage the final pipe piece and pull back ensuring the grey wall seals are fully pulled up to the outside and inside wall faces.


Vertical Pipes-Completion of Installation

Refer to diagram 10.25.

For installation of (a), attach the twin pipe to concentric flue adaptor, part number A2011600, to the base of vertical terminal assembly. For installation of (b), attach the single pipe to concentric adaptor, part number A2011500, to the base of vertical terminal assembly.

With the vertical terminal assembly positioned in the roof, the length of the final pipe can be determined. Cut the flue to the desired length measuring from the 'O' ring seal end and discard the plain end of the tube. The cut end should be square and free from burrs. Carefully push the terminal assembly upwards to allow room for fitting the final flue piece(s). Fit a 100mm fixing bracket to the terminal assembly Part No2000460486. Pull the terminal assembly down and join to the flue system. Ensure that the terminal is making a weather tight seal on the weather collar. Secure the fixing bracket fitted to the terminal to the roofing struts or a purpose made baton.

10 Plume Management Kit



10.13 Plume Management Kit

The Plume Management Kit: Part No. A2044100 (white) or A2044000 (black) can be used to overcome many site issues.

The Plume Management Kit will fit to the Top Horizontal Telescopic, Rear Horizontal Telescopic and Standard Horizontal Flue. This enables the flue products to exhaust further away from the boiler, thereby reducing the impact of pluming. The flue air inlet can be sited closer to doors, opening windows and air bricks, see diagram 10.28.

The maximum length of the Plume Management Kit must NOT exceed 6m with a horizontal concentric flue length of 2m max.

For each 90° bend or 2 x 45° bends the maximum length of the Plume Management Kit must be reduced by 1m.

For more information contact Glow-worm, refer to page 2.

The Plume Management Kit is supplied with installation instructions.

Refer to BS5546 or BS6798 for advice on disposal of boiler condensate.

11 Electrical Connection

WARNING: This appliance MUST be earthed.

This appliance must be wired in accordance with these instructions. Any fault arising from incorrect wiring cannot be put right under the terms of the Glow-worm guarantee.

All system components must be of an approved type.

Electrical components have been tested to meet the equivalent requirements of the BEAB.

Do not interrupt the mains supply with a time switch or programmer.

Connection of the whole electrical system and any heating system controls to the electrical supply must be through a common isolator.

Isolation should preferably be by a double pole switched fused spur box having a minimum contact separation of 3mm on each pole. The fused spur box should be readily accessible and preferably adjacent to the boiler. It should be identified as to its use.

A fused three pin plug and shuttered socket outlet may be used instead of a fused spur box provided that:

- They are not used in a room containing a fixed bath or shower.
- Both the plug and socket comply with the current issue of BS1363.

Immersion Heater - the thermostatically controlled immersion heater with manual reset is fitted to the cylinder as a back up for domestic hot water in the event of the boiler being inoperable, it MUST be wired separately from the boiler electrical connections.

The heater should be wired through a double-pole switch or controller having a minimum contact separation of 3mm on each pole. Use a cable size of at least 1.5sq. mm flexible cable, 85 deg.C rubber insulated HOFR sheathed to comply with BS6141 Table 8 and must be fully earthed.

11 Electrical Connection

11.1 Electrical Connection

Take the previously laid electrical cable and route along the left hand side of the tank module through the two grommets and the cable ties and across to the installers interface as shown in diagram 11.1.

Take the electrical cartridge from the loose items pack.

Remove the securing screw to open the cartridge.

NOTE: There are two screws supplied loose in the electrical cartridge, these will be required to secure the cartridge into the electrical interface housing.




Loosen the two screws of the cable strain relief in the electrical cartridge, see diagram 11.2.

Route the mains supply and systems cables through the strain relief and connect to the relevant plug dependant upon your choice of system controls, refer to relevant sections 11.2 and 11.3.


Initially, if system controls are not fitted then fit a wire link in place between "L" and "R", this will allow the boiler to run continuously on heating.

Fit electrical cartridge into the interface housing on completion of the wiring, see diagram 11.3.

Secure with the two cartridge retaining screws provided in the cartridge body.



11 Electrical Connection



11.2 System Controls 24V

WARNING: UNDER NO CIRCUMSTANCES MUST ANY MAINS VOLTAGE BE APPLIED TO ANY OF THE TERMINALS ON THE 24V CONNECTION PLUG.

Connect the mains supply and system heating controls e.g. room thermostat as diagram 11.4. External controls should be fitted in accordance with the rules in force.

If fitting a proprietary programmer as part of the system controls the internal central heating programmer will need to be disabled as described in section 11.4.

11.3 Mains Voltage System Controls

WARNING: UNDER NO CIRCUMSTANCES MUST ANY MAINS VOLTAGE BE APPLIED TO ANY OF THE TERMINALS ON THE 24V CONNECTION PLUG.

Connect mains supply and system controls as diagram 11.5.


External controls should be fitted in accordance with the rules in force.

If fitting a proprietary programmer as part of the system controls the internal central heating programmer will need to be disabled as described in section 11.4.

11.4 Disabling the internal CH Programmer

If fitting an external proprietary CH Programmer, it is necessary to disable the Internal Programmer.

- Press and hold the 'mode' button for 5 seconds. The display will change to flashing '0'.
- Use the '+' or '-' button to scroll to 96.
- Press 'MODE' to confirm.
- The display now shows a flashing 'd. 0' Use the '+' or '-' key to scroll to 'd. 92'.
- Press 'MODE' to confirm.
- The display now shows a flashing '3' above the 'd. 92'.
- Use the '+' or '-' button to change this value to '7'.
- Press 'MODE' to confirm, '7' stops flashing and is saved.
- Press and hold 'MODE' to exit.



The CH Programmer has now been disabled. The DHW Programmer is still active. See the diagnostic menu instructions in the Fault Finding section for further details.

11.5 Tank Thermistor


The tank thermistor should be connected between the boiler and tank modules.

When connecting, ensure that the cable and connection plug from the control box passes through its grommet on the base of the boiler module to the connection on the LH side of the tank module, see diagram 11.6.


11.6 Electrical Connections - Testing

Carry out preliminary electrical system checks as below:

- Test insulation resistance to earth of mains cables.
- Test the earth continuity and short circuit of cables.
- Test the polarity of the mains.



12 Commissioning



to a drain. The drain pipe 22mm to 25mm OD. non corrosive plastic pipe should have a fall of at least 2.5° away from the boiler.

12.1 Filling Domestic Water Circuit

Make sure that the isolation valves are securely tightened.

Open all domestic hot water taps.

Fully open the DHW outlet and DCW inlet valves, see diagram 12.1. Water will now flow through the boiler to the domestic water tank and to the hot water taps.

Starting at the lowest tap, turn the hot taps off one at a time until the hot water pipework is purged of air.

If necessary, carefully slacken, but DO NOT remove the air vent screw on the domestic pump to release any trapped air within the boiler, see diagram 12.4, secure when procedure completed.

Note: The water pressure at the vent point is that of the incoming water main.

Check for water soundness of the complete domestic water system.


12.2 Filling the Heating System

Refer to diagrams 12.1, 12.2 and 12.3.


With the boiler in place:

1. Ensure that the filling loop flexible hose is securely connected to the double check inlet valve.
2. Ensure that the gas service cock is closed.
3. Switch on the power supply to the appliance.

The boiler should be in OFF mode. This is indicated



12 Commissioning



by the 'OFF' symbol on the user interface display. If not, press the 'mode' button repeatedly until the 'OFF' symbol is displayed.

The display will now show a flashing system pressure.



4. Fully open the taps on the filling loop to fill the heating system to a pressure of 1.0bar. Close the filling taps. If the domestic cold water is below 10°C the tank frost protection may operate and a F1 will be displayed, clear by pressing "Reset", you may have to repeat this process until the pressure is 1 bar.
5. Vent all air from the system - repeat step 4 as necessary until the system is full and all the air has been removed.
6. Make sure that the automatic air vent works correctly and that the black cap is loosely fitted to allow air to escape.
7. To comply with the water regulations the flexible hose must be disconnected from the double check inlet valve - undo the nut and pull the flexible hose from the valve.

12.3 Initial Lighting

The lighting procedure of the boiler is fully automated.

Check that all external controls are calling for heat.

Open the gas service cock.

Repeatedly press the "MODE" button until the  and  symbols are displayed.


The hot water tank has priority over central heating.

The appliance will enter a self-checking routine then the ignition sequence will commence.

The digital display will show the tank temperature setting in hot water mode.

If the burner fails to light the fan will stop. Initially this may be due to air in the gas supply line. The boiler will automatically have five attempts at ignition.

If the burner fails to ignite the display will show F1.



Depress the "reset" button on the fascia to clear the display and repeat the ignition sequence.

When the tank is full (and after a short pump overrun period) a central heating demand will be initiated.

Once the system has been purged of air set the hot water to the desired temperature by using the hot water "+" and "-" buttons.

Open a hot water tap, check that hot water is available and then close the hot water tap.

Set the central heating water temperature to the desired temperature by using the central heating "+" and "-" buttons.

The appliance will then continue to fire in central heating mode until the user controls are satisfied or there is another demand made for hot water.

NOTE: After ignition in central heating demand the boiler will remain at minimum power for one minute before going to full rate.

12.4 Re-pressurising System (if required)

1. Ensure that the filling loop flexible hose is securely connected to the double check inlet valve, see diagram 12.2.
2. Fully open tap "A", then gradually open tap "B" to fill the heating system to a pressure of 1.0bar. When completed close the filling taps.
3. Vent all air from the system - repeat step 2 as necessary until the system is full and all the air has been removed.

12 Commissioning

4. **IMPORTANT:** To comply with the water regulations the flexible hose must be disconnected from the double check inlet valve - undo the nut and pull the flexible hose from the valve.

12.5 Gas Rate

Should any doubt exist about the gas rate, check it using the gas meter test dial and stop watch at least 10 minutes after the burner has lit, making sure that all other gas burning appliances and pilot lights are off.

The boilers are fully modulating for central heating, and it is therefore not necessary to range rate the boiler.

For approximate gas rates, refer to section 1 Specification Table.

The gas valve is factory set for natural gas (G20) and should need no adjustment. It should be checked that the supply pressure is 20mbar when the boiler is firing at full rate. This can be achieved by turning on several hot water taps and checking the inlet pressure at the pressure test point on the gas service cock, see diagram 12.1. Turn taps off and disconnect pressure gauge.

In the unlikely event that the gas valve needs adjusting, refer to section 13 Servicing - Combustion Check. Re-setting of the gas valve requires a combustion analyser and any adjustment should only be carried out by a **competent person**.

NOTE: The burner pressure cannot be measured at the gas valve as it is altered by the suction of the fan and modulated according to demand.

Testing Flue Gases: If any doubt exists that the flue products are not exhausting correctly, investigate by use of a flue gas analyser.

12.6 Range Rating

The boilers are fully modulating for central heating, and it is therefore not necessary to range rate the boiler. However, if desired, it is possible to range rate the boiler between 9 and 24kW in 1kW increments as follows:

- Press and hold the 'MODE' button for 5 seconds. The display will change to flashing '0'.
- Use the '+' or '-' button to scroll to 96.
- Press 'MODE' to confirm.
- The display now shows a flashing 'd. 0'. The part load setting is displayed above in kW
- Press 'MODE' to change, use the '+' or '-' button to change this value to the desired setting.

kW	m3/hr	ft3/hr	kW	m3/hr	ft3/hr
24	2.5	88.6	16	1.7	58.9
23	2.4	84.7	15	1.6	55.4
22	2.3	81.2	14	1.5	51.5
21	2.2	77.3	13	1.4	48.0
20	2.1	73.8	12	1.3	44.1
19	1.1	69.9	11	1.2	40.6
18	1.9	66.4	10	1.0	36.7
17	1.8	62.9	9	0.9	33.2

- Press 'MODE' to confirm, the new setting has been saved.
- Press and hold 'MODE' to exit.

NOTE: For approximate gas rates at part load, refer to table below.

12.7 Water Systems

Check that all external controls are calling for heat, the boiler will fire automatically. Fully open all radiator valves and the flow control valve, if fitted, see diagram 4.1.

Balance the radiators as required and if fitted adjust the valve to give the required system differential. Turn off all radiators that can be shut off by the user and check to see if less than the maximum differential allowed of 20°C can be achieved across flow and return.

The pump has two speeds and can be adjusted depending on the requirements of the central heating system, see diagram 4.2.

The boiler has an inbuilt automatic adjustable bypass valve. The pressure can be adjusted between approx 1.5 and 3.5mH₂O but is factory pre-set to approx 2.5mH₂O. The pressure changes by approx 0.1mH₂O for each full turn of the bypass screw, see diagram 12.4. Turning clockwise increases the pressure and turning anti-clockwise decreases the pressure.

Allow the system to reach maximum temperature then switch off the boiler by isolating from the electrical supply.




Diagram 12.4

12 Commissioning

Lock or remove the handle from the control valve, if fitted.

Adjust the boiler temperature controls and any system controls to their required settings.

We recommend that the domestic hot water should be run for a short period until clear.

12.8 Benchmark

It is necessary to complete the appropriate sections of the “Benchmark” document.

For IE, it is necessary to complete a “Declaration of Conformity” to indicate compliance to I.S.813. An example of this is given in the current edition of I.S.813.

12.9 Instruct the User

Demonstrate, then instruct the User about the lighting procedure and heating system controls operation.

Advise the user on the use and maintenance of any scale reducer and pass on any relevant instructional documents.

Advise that to ensure the continued efficient and safe operation of the boiler it is recommended that it is checked and serviced at regular intervals. The frequency of servicing will depend upon the installation conditions and usage, but in general, once a year should be enough.

Draw attention, if applicable, to the current issue of the Gas Safety (Installation and Use) Regulations, Section 35, which imposes a duty of care on all persons who let out any property containing a gas appliance in the UK.

The user shall not interfere with or adjust sealed components.

It is the Law that any servicing is carried out by a **competent person**.

Advise the user that, like all condensing boilers this appliance will produce a plume of condensation from the flue terminal in cool weather.

This is due to the high efficiency and hence low flue gas temperature of the boiler.

Advise the user of the precautions necessary to prevent damage to the system, boiler and the building, in the event of the heating system being out of use during frost or freezing conditions.

Advise the user that the permanent mains electrical supply SHOULD NOT be switched off, as the built in frost protection and pump/valve saver program will not operate.

Advise the User if the mains electricity and gas are to be turned off for any long periods during severe weather, it is recommended that the whole system, including the boiler,

13 Servicing

IMPORTANT NOTES

1. To ensure the continued efficient and safe operation of the boiler it is recommended that it is checked and serviced at regular intervals. The frequency of servicing will depend upon the particular installation and usage, but in general once a year should be enough.
2. It is the Law that any servicing is carried out by a **competent person**.
3. Before commencing with a service or replacement of parts the boiler should be isolated from the electrical supply and the gas supply should be turned off at the gas service cock, see diagram 12.1.
4. When replacing a part on this appliance, use only spare parts that you can be assured conform to the safety and performance specification that we require. Do not use reconditioned or copy parts that have not been clearly authorised by Glow-worm.
5. On completion of servicing the "Benchmark" log book should be completed.

13.1 General Inspection

Prior to servicing carry out an initial inspection of the following:

1. Condition of case and flue.
2. Flue terminal for obstructions.
3. Electrical supply connection
4. Water connections.
5. Gas connection.
6. System pressure.

13.2 Functional Checks

With the appliance operational carry out the following functional checks:

1. COMBUSTION - preferably with a flue gas analyser as section 13.8. If no flue gas analyser is available remove the tank module front panel to gain access to the boiler module front panel securing screws, see diagram 13.1, and taking care not to touch any components, check the flame picture through the viewing window, see diagram 13.2.



Should the flame show signs of lift, sooting or appear yellow then it will be necessary to service the burner, if the servicing does not correct the condition, then proceed to the combustion test described in section 13.8.

2. GAS RATE - If the gas rate is lower than the minimum gas rate the burner will require servicing. However should the combustion measurement or flame and gas rate be correct, then it is not necessary to remove the burner assembly for a service.





3. CHW FLOW RATE - agrees with the technical specification, if it does not, clean the filter and if necessary check the gas rate as described in commissioning.

13.3 Servicing

For ease of servicing, the control box and domestic expansion vessel can be moved into their service positions, this will improve access to components, see diagrams 13.3 to 13.6.



13 Servicing



13.4 Silencer

For access to the heat exchanger the silencer will need to be removed, see diagram 13.7.

Remove the securing screw and pull the silencer from the fan, this is a push fit.

13.5 Spark Electrode

Disconnect the ignition lead and two securing screws. Withdraw the spark electrode carefully from the combustion chamber, see diagram 13.8 and 13.9.

Inspect the tips for damage.

Clean away any debris and check the spark gap is 3.5 to 4.5 mm.

Check the electrode gasket for signs of damage and replace if necessary.

13 Servicing




Diagram 13.7




Diagram 13.8




Diagram 13.9

13.6 Burner

NOTE: If the functional checks did not indicate poor combustion then it is not necessary to service the burner.

The following procedure will require that you replace the burner door seal and nyloc nuts.

After turning off the gas supply at the gas service cock, see diagram 12.1, loosen the gas connection at the union nut between the boiler module and tank module.

Remove the gas supply pipe securing clip and withdraw the gas pipe from gas valve, see diagram 13.10.

Disconnect the electrical connection at the gas valve and disconnect the electrical connection from the fan.

Disconnect the ignition lead and earth lead from the burner door, see diagram 13.9.

Disconnect the flue overheat thermostat, see diagram 13.11.

Remove the four burner door nyloc nuts, one of these also holds the silencer bracket, see diagram 13.11.

Gently remove the fan, gas valve and burner assembly from the combustion chamber.


Clean the burner with a soft brush taking great care not to damage the front insulation. DO NOT use wire or sharp instruments to clean the holes of the burner. Inspect the burner for any signs of damage.

Remove and discard the burner door seal and replace with new.

Removal of the burner is not necessary during a normal service.

NOTE: If the burner has to be removed it will require a new gasket when refitted, see diagram 13.12.

13 Servicing



13.7 Heat Exchanger

Refer to diagram 13.11.

Remove loose debris from inside the heat exchanger using a soft brush and vacuum cleaner.

Carefully flush by spraying water into the heat exchanger, any remaining debris should pass through the condensate trap (Ensure the water is kept away from electrical components).

13.8 Combustion Setting

A combustion check should not be necessary unless a gas carrying component has been replaced or the combustion setting is suspect.

Connect a flue gas analyser to the sampling point, see diagram 13.13.

IMPORTANT: Products of combustion will be discharged when the cap is removed. It is important to replace the cap immediately.

If no flue gas analyser is available and with the boiler module front panel removed, check the flame picture through the viewing window

Turn on the gas service cock, see diagram 12.1.

Turn on the electrical supply, the appliance will begin the ignition sequence.

A **competent person** only should carry out any adjustment to the gas valve, refer to diagram 13.14.

Monitor the combustion reading and at max rate the reading should be $9.2\% \pm 0.5$.



If adjustment proves necessary then proceed as follows:

Press the “reset” button on the controls fascia, release and immediately press and hold in the “+” button. After approximately 5 seconds “Hi” will be displayed.



Pressing the mode button when “Hi” is selected will force the boiler to maximum rate, the display will flash between “Hi” and the “default display” this will indicate the boiler has been forced to maximum.

Adjust the maximum rate CO_2 with the throttle to 9.3%. (Rotate anti-clockwise to increase).

To exit the check sequences press the “+” buttons, this will reset the boiler to the default display.




13 Servicing



13.9 Condense Trap & Siphonic Drain

The condense trap and siphonic drain does not normally need removing during servicing unless the service fill level is at full, see diagram 13.15.

To flush the condense trap and siphonic drain carefully pour water into the heat exchanger and check that water flows freely to drain.



14 Fault Finding

WARNING

Always isolate the boiler from the electrical supply before carrying out any electrical replacement work.

Always check for gas soundness after any service work.

NOTE:

Before trying to operate the boiler make sure that :

- All gas supply valves are open and that the gas supply has been purged of air.
- There is a permanent mains supply to the boiler.
- There is a heating demand from the external controls.


Electrical Testing

Should there be any doubt about the voltage supply to any of the components, it is possible to carry out a simple electrical test.

IMPORTANT: On completion of the Service/Fault Finding tasks which have required the breaking and remaking of the electrical connections the earth continuity, polarity, short circuit and resistance to earth checks must be repeated using a suitable multimeter.

To carry out the electrical test, gain access, as follows:


Hinge down the control box and unclip the cover to gain access. Refer to the wiring diagram 14.1 and fault finding charts, diagrams 14.2 to 14.5.



14 Fault Finding

CENTRAL HEATING

13012



DHW

13411




Diagram 14.2

14 Fault Finding

Fault Codes

13412

CODE	DESCRIPTION	POSSIBLE CAUSE
F1	Boiler has attempted to light 5 times and failed on all occasions	Gas tap is closed. Gas valve connector is loose, unconnected, faulty, or wires are trapped. Ignitor connectors are loose, unconnected, faulty, trapped. Faulty Ignitor. Low gas inlet pressure. Incorrect gas valve adjustment. Electrode Ignition leads loose, unconnected, faulty, trapped. Electrode broken, defective, or position incorrect. Air inlet blocked, flue inlet blocked, flue duct leaking. Earthing connection loose, disconnected.
F2	Overheat - Flue thermostat	Boiler has overheated.
F3	Fan fault	Fan speed incorrect. Fan connector loose, unconnected, faulty or wires trapped. Faulty fan.
F4	Flame goes out whilst lit during a demand	Gas tap is closed. Gas valve connector is loose, unconnected, faulty, or wires are trapped. Ignitor connectors are loose, unconnected, faulty, trapped. Faulty Ignitor. Low gas inlet pressure. Incorrect gas valve adjustment. Electrode Ignition leads loose, unconnected, faulty, trapped. Electrode broken, defective, or position incorrect. Air inlet blocked, flue inlet blocked, flue duct leaking. Earthing connection loose, disconnected.
F5	Overheat	Boiler has overheated – press reset button
F6	Central Heating Flow Thermistor connection fault	Thermistor wires unconnected, faulty, trapped.
F7	DHW Thermistor connection fault	Thermistor wires unconnected, faulty or trapped.
F8	Tank Thermistor connection fault	Thermistor wires unconnected, faulty or trapped.
F9	Pressure	Water pressure Connector loose, unconnected, faulty or wires trapped. Water Pressure Sensor Faulty Pump ceased, faulty. No water in the system
F10	Central Heating Return Thermistor connection fault	Thermistor wires unconnected, faulty, trapped.
F11	Flow and/or return NTC faulty	Thermistor wires unconnected, faulty, trapped.
F13	PCB Memory or sensing fault	Loose connections on Main PCB or display PCB. Central Heating Flow or Return Thermistor wires unconnected, faulty, trapped. Electrode Ignition leads loose, unconnected, faulty, trapped. Earthing connection loose, disconnected.
F14	Gas Valve control defective	Gas valve connector loose, wires unconnected, faulty or trapped. Faulty main board. Faulty gas valve.
F15	eBus Voltage failure	Short circuit on eBus, overload on eBus.

Diagram 14.3

14 Fault Finding

13447

Fault Codes (continued)

F22	Low Water pressure or Ignition temperature rise too slow	Not enough water in the system. Central Heating Flow or Return Thermistor wires loose, faulty, trapped. Central Heating Flow or Return Thermistor not connected to pipe correctly Air in the system. Faulty pump or pump speed too fast.
F25	Central Heating Flow temperature rise too high during operation. Central Heating Return temperature rise or temperature difference too high during operation. Central Heating Temperature difference (between Flow and Return) too high during operation.	Check thermistors are connected to pipes correctly. Air in the system. System is too restrictive.
F43	Generic error	Check all electrical connections - internal & external
F70	Software incompatible	Telephone Group Service
F77	Condensate pump error (Option)	Trapped, faulty wiring, blockage in condensate pump.
NO DISPLAY or 'Er' displayed - Check connection from display PCB to main PCB connector X51		

Diagram 14.3a


Fault Memory

The Fault memory stores details of the ten most recent faults.

To access this menu:

- Press and hold 'MODE' for 5 seconds.
- When the display shows a flashing '0' press 'MODE' button.
- Press a '+' button to scroll back through the fault memory (Position 1 is most recent), see fault memory display.

To exit this menu, press the 'MODE' button.



13452

14 Fault Finding


Diagnostic Menu

The Diagnostic Menu provides the ability to view and change certain parameters.

See Diagram 14.4 for available parameters.

To enter the diagnostic menu:


- Press and hold the 'MODE' button for 5 seconds. The display will change to flashing '0'.
- Use the '+' or '-' buttons to scroll to 96 (This is the installer level access password).
- Press 'MODE' to confirm, see diagnostic display 1.



Use the '+' or '-' buttons to view the appropriate diagnostic number, see diagram 14.4.

If necessary the values can be changed by:

- Pressing the 'MODE' button.
- The diagnostic value flashes, see diagnostic display 2.



- Use the '+' and '-' buttons to cycle through available values.
- The change is saved by pressing 'MODE' once more.

(NOTE: Only certain parameters can be adjusted)

To exit the diagnostic menu press and hold the 'MODE' button for 5 seconds.

14 Fault Finding

Diagnostic Menu - Level 1 Installer Access

13454

Display	Description	Range
■ d.0	Heating part load	Adjustable heating part load in kW (factory setting: max. output)
■ d.1	Water pump over run time for heating mode	2 - 60 min (factory setting: 5 min)
■ d.2	Max. burner anti cycling period at 20°C Flow temperature	3 - 60 min (factory setting: 20 min)
d.3	Domestic hot water flow temperature reading	in °C
d.4	Tank temperature	in °C
d.5	Flow temperature setpoint	In °C, min. 38 and max. 82
d.6	Domestic hot water setpoint	In °C, 40 to 62°C
d.7	Tank setpoint	in °C
d.8	External controls heat demand (Clamp 3-4)	0= no heat request (open) 1 = heat request (closed)
d.9	Flow target temperature from external analogue regulator to terminal 7 R	In °C, minimum from ext. eBUS target value and target value terminal 7
d.10	Status internal heating pump	1,2 = on, 0 = off
d.11	Status external heating pump	1 to 100 = on, 0 = off
d.13	Hot water circulation pump (via accessory module)	1 to 100 = on, 0 = off
d.22	Domestic hot water demand	1 = on, 0 = off
d.23	Summer/Winter function	1 = Winter, 0 = Summer
d.24	System water pressure	in bar.
d.25	Hot water activation via eBUS Control	1 = yes, 0 = no
■ d.27	Option Relay 1	Reserved for future use
■ d.28	Option Relay 2	Reserved for future use
d.33	Fan speed target value	in rpm/100
d.34	Fan speed actual value	in rpm/100
d.35	Position of diverter valve	0 = Heating; 1 = Hot water; 2 = Centre position
d.40	Flow temperature	Actual value in °C
d.41	Return temperature	Actual value in °C
d.44	Ionisation current	Actual value (10nA)
d.47	Outside temperature	in °C
d.60	Number of safety temperature limiter cut offs	Quantity
d.61	Number of lock outs	Number of unsuccessful ignitions in the last attempt
d.64	Average ignition time	In seconds
d.65	Maximum ignition time	In seconds
d.67	Remaining burner anti cycling time (block time)	Quantity
d.68	Unsuccessful ignitions in the first attempt	Quantity
d.69	Unsuccessful ignitions in the second attempt	Quantity
d.76	Appliance variant (device specific number)	00 to 99
d.80	Heating operating hours	in h
d.81	Water heating operating hours (combination boilers only)	in h
d.82	Cycles in heating mode	Quantity
d.83	Cycles in hot water operation	Quantity in h
■ d.84	Maintenance indicator: Number of hours until next maintenance	Quantity
d.90	Digital regulator status	1 = identified, 0 = unidentified (eBUS Address <= 1 0)
■ d.91	Internal Programmer type	0:24 hour 1:7 day (default)
■ d.92	Enable/Disable Internal Programmer	0: CH Off, DHW Off 1: CH Off, DHW On 2: CH On, DHW Off 3: CH On, DHW On (Default)
■ d.97	Activation of the second diagnostic level	Password needed
d.99	State List	(see table opposite)

■ Indicates read and write function - all other diagnostics are read only

Diagram 14.4

14 Fault Finding

State list - Accessed through Diagnostic Codes - Level 1, Installer Access d.99

13011

STATE LISTS

	Central heating mode (Priority 3)	Possible Causes
S.00	no heating required	
S.01	fan pre-run	
S.02	pump pre-run	
S.03	ignition	
S.04	burner on	
S.05	pump / fan overrun	
S.06	fan overrun	
S.07	pump overrun	
S.08	Anti cycling period	
	Domestic hot water mode (Priority 2)	
S.10	domestic hot water demand	
S.11	fan pre-run	
S.13	ignition	
S.14	burner on	
S.15	pump / fan overrun	
S.16	fan overrun	
S.17	pump overrun	
	Cycling / preheat mode (Priority 1)	
S.20	domestic hot water cycling mode active	
S.21	fan pre-run	
S.22	Pump pre run	
S.23	ignition	
S.24	burner on	
S.25	pump / fan overrun	
S.26	fan overrun	
S.27	pump overrun	
S.28	Anticycling period	
	Special cases of status messages	
S.30	No Heating demand from external controls 230V	Check wiring in external controller. Check wiring at Installer Interface.
S.31	summer mode	Check CH setpoint / Check external controls
S.32	Antifreeze active – fan speed variation too high – waiting during blocking function	Check fan connection.
S.34	frost protection active (Priority 4)	Temperature below 8°C - check thermistor connection if this is not true.
S.36	No Heating demand from external controls 24V	Check wiring in external controller. Check wiring at Installer Interface.
S.42	Accessory Module is blocking burner operation	Check accessory module.
S.53	waiting time: temperature difference flow - return sensor too high (Check thermistor fit)	Check flow & return thermistor connections to pipes. Check harness connection to thermistor. Check harness wires are not trapped between any internal components.
S.54	waiting time: no water in system, temperature (gradient error) rise flow / return sensor too high	Check flow & return thermistor connections to pipes. Check harness connection to thermistor. Check harness wires are not trapped between any internal components.
S.76	Waiting period – pressure sensor	Check system pressure - default display.
S.96	Return-Sensor check is running, demand (DHW or heating) is blocked	Check return thermistor connection to pipe. Check harness connection to thermistor.
S.97	Water pressure sensor check is running, demand (DHW or heating) is blocked	Check connection to pressure sensor. Check pump has not seized.
S.98	Flow / Return - sensor check is running, demand (DHW or heating) is blocked	Check flow & return thermistor connections to pipes. Check harness connection to thermistor. Check harness wires are not trapped between any internal components.

Diagram 14.5

15 Replacement of Parts

15.1 General

Replacement of parts must be carried out by a **competent person**.

Before replacing any parts the boiler and immersion heater should be isolated from the mains electric supply and the gas should be turned off at the service cock on the boiler, see diagram 12.1.

Unless stated otherwise parts are replaced in the reverse order to removal.

After replacing any parts always test for gas soundness and if necessary carry out functional test of the controls.

For replacement of parts the front casing panels will need to be removed.

The tank module front panel will need to be removed first to gain access to the boiler module front panel securing screws.

Remove the two screws on the underside of the panel and lift off, see diagram 13.1.

For ease of servicing, the control box and domestic expansion vessel can be moved into their service positions, this will improve access to hydraulic components, see diagrams 13.3 to 13.6.

Draining of Boiler Primary Circuit

To drain the boiler primary circuit, isolate the flow and return valves, see diagram 12.1.

Open the top tap on the filling loop to drain the boiler out through the filling loop hose.

After servicing or replacing parts open the heating flow and return isolating valves and refill, vent and pressurise the heating circuit, refer to section 12.2.

Close the drain valve and disconnect the hose.

Check for leaks.

Draining of Boiler Hot Water Circuit

Drain the Domestic Hot Water circuit by closing the cold-water isolation valve, see diagram 12.1.

Open one or more hot water taps to drain the hot water circuit.

After servicing or replacing parts open the cold-water isolation valve and slowly open a hot water tap to remove air. Close the hot water tap and check for any leaks.

15.2 Domestic Expansion Vessel

For access, refer to section 15.1.

Isolate the DHW inlet valve, see diagram 12.1 and drain through a domestic tap.

Loosen the locknut at the top of the vessel, see diagram 15.1.

To remove the expansion vessel slide forward out of its hanging bracket.

Remove the flexible hose from the expansion vessel by undoing the union nut and lock nut, see diagram 15.1.

Fit the replacement unit.

Refill, vent and pressurise the boiler.

Check for leaks.

15.3 Silencer assembly

For access, refer to section 15.1.

To aid access to the silencer and securing screw, loosen the locknut at the top of the domestic expansion vessel, see diagram 15.1 and slide the vessel forward out of its bracket and put in its service position, see diagram 13.6.

To remove, undo the securing screw and pull the silencer from the fan, this is a push fit so no tools or fixings are required for its removal or fitting, see diagram 13.7.




Diagram 15.1




Diagram 15.2

15 Replacement of Parts

15.4 Ignition Lead

For access, refer to section 15.1.

Refer to diagram 13.9.

Pull the spark plug style connector off the spark electrode and the ignition lead connected to the igniter unit, see diagram 15.2.

15.5 Igniter Unit

For access, refer to section 15.1.


To aid access to the igniter unit, loosen the locknut at the top of the domestic expansion vessel and slide forward out of its bracket and put into its service position, see diagrams 13.5 and 13.6.

Remove ignition lead and electrical connections then remove igniter unit by removing two securing screws, see diagram 15.2.

15.6 Spark Electrode

For access, refer to section 15.1.

Remove the spark plug ignition lead, earth lead and two securing screws. Withdraw the spark electrode carefully from the combustion chamber, see diagram 15.3.



15.7 Gas Valve

For access, refer to section 15.1.

Remove the electrical plug from the gas valve, see diagram 13.10.

Refer to section 13.6 for removal of the fan, gas valve and burner assembly.

Before removing the gas valve from the fan note its position and mark its orientation on the fan and gas valve bodies, this will help when re-assembling.

Remove the two screws that secure the gas valve to the fan, see diagram 15.4.

Remove the gas valve.

Fit new gasket when replacing.

After re-fitting check the combustion CO₂ and adjust if necessary, see section 13 Servicing.

After assembly test for gas soundness and purge in accordance with the current issue of BS6891 or in IE, the current edition of I.S.813 "Domestic Gas Installations".

15.8 Fan


For access, refer to section 15.1.

Refer to section 13.6 for removal of the fan, gas valve and burner assembly.

Remove the two screws securing the fan to the gas valve.

Remove the fan.

Fit new gasket when replacing.



15 Replacement of Parts

15.9 Burner

For access, refer to section 15.1.

Refer to section 13.6 for removal of the fan, gas valve and burner assembly.

Remove the four screws that secure the burner, see diagram 13.12.

NOTE: THE BURNER WILL REQUIRE A NEW GASKET WHEN REFITTED.

15.10 Front Insulation

For access, refer to section 15.1.

Refer to section 13.6 for removal of the fan, gas valve and burner assembly.

Remove spark electrode, see section 15.6.

Remove burner as per section 15.9 and withdraw the insulation, see diagram 13.12.

NOTE: THE BURNER WILL REQUIRE A NEW GASKET WHEN REFITTED.

15.11 Rear Insulation

For access, refer to section 15.1.

Refer to section 13.6 for removal of the fan, gas valve and burner assembly.

Remove securing screw and washer in the centre of the insulation and withdraw insulation, see diagram 15.5.

15.12 Viewing Window

For access, refer to section 15.1.



Refer to diagram 15.6.

Remove circlip.

Remove steel washer.

Remove glass.

Remove fibre washer.



15 Replacement of Parts





Diagram 15.8

15.13 Primary Expansion Vessel

For access, refer to section 15.1.

Drain the boiler primary circuit, refer to section 15.1.

Remove the retaining clip from the flexible hose at the central heating pump, see diagram 15.7.

Remove the flexible hose from the pump, ensure the 'O' ring on the connection is seated correctly before re-fitting.

Remove the expansion vessel clamp, see diagram 15.7.

Slide the expansion vessel forward and out from the retaining bracket.

Remove the flexible hose union nut from the expansion vessel. When re-fitting ensure that a new sealing washer is fitted and that the elbow of the flexible connection faces towards the front of the appliance.

15.14 Heat Exchanger

Refer to Manual Handling Operations, 1992.

For access, refer to section 15.1.

Drain the boiler primary circuit, see section 15.1.

Drain the boiler hot water circuit, see section 15.1.

Disconnect the flue connection, refer to section 10.

Remove the silencer, refer to section 13.4.

Remove the igniter unit electrical connections, refer to diagram 15.2.

Refer to section 13.6 for removal of the fan, gas valve and burner assembly.

15 Replacement of Parts

Remove the two connection clips securing the flow and return pipes to the heat exchanger, see diagram 15.9.




Move the pipes away from the heat exchanger.

Remove the four heat exchanger securing screws and clamps, see diagram 15.8.

CAUTION: There will be water in the heat exchanger.

Remove the push fit condensate pipe from the bottom of the heat exchanger, see diagram 15.10.

Carefully remove the heat exchanger and disconnect the flue overheat thermostat, see diagram 13.11.



15 Replacement of Parts

15.15 Central Heating Pump

For access, refer to section 15.1.

Drain the boiler primary circuit, see section 15.1.

Unscrew the union nut of the return pipe to the pump connection, see diagram 15.11.

Unscrew the union nut from the safety discharge valve.

Remove the flexible connection from the CH pump, see diagram 15.7.

Disconnect the electrical connections inside the control box to the main PCB, see diagram 15.11.

Remove the securing screw from the pump retaining bracket and ease off the bracket from the spigot on the rear of the pump.

Remove the pump retaining clip.

The pump can now be pulled sideways away from its three way valve connection.

When re-fitting, ensure that all seals are in place.

15.16 Three Way Valve

For access, refer to section 15.1.

Remove the CH pump, refer to section 15.15.

Refer to diagram 15.12.


Remove the electrical plug.

Undo the CH inlet connection at the union nut between the boiler module and the tank module.

Remove the retaining clip.

Remove the three securing screws.

Carefully remove the three way valve assembly.



15.17 Domestic Pump

For access, refer to section 15.1.

Drain the boiler hot water circuit, see section 15.1.

Remove the domestic expansion vessel and place in its service position, see diagram 13.6.

Disconnect the electrical connection from the main PCB, see diagram 15.13.

Unscrew the union nut at the pump top connector to the DHW pipe.

Unscrew the pipe union nut from the bottom pump connection, see diagram 15.13.


Remove pump securing clip at the bottom pump connection. The pump can now be lifted up and clear of the boiler.

Remove the pump top and bottom connectors making note of the orientation of the top connection.

When re-fitting the top and bottom connectors ensure that the rubber seals are in place and that the top connector is orientated correctly, with the DHW pipe connection at 90° to the pump axis.

When re-fitting any part, ensure that all seals and clips are in place.

After replacing parts open the cold-water isolation valve and slowly open a hot water tap to remove air. Close the hot water tap and check for any leaks.



15 Replacement of Parts

15.18 Safety Discharge Valve

For access, refer to section 15.1.

Refer to section 15.1 and drain the boiler primary circuit.

The safety discharge valve is situated towards the RH side of the boiler module, refer to diagram 15.14.

Unscrew the pipework union nut from the safety discharge valve.

Remove the securing clip and withdraw the safety discharge valve.

Fit new 'O' ring.

15.19 Domestic Hot Water Thermistor

For access, refer to section 15.1.

The domestic hot water thermistor is situated centrally in the boiler module on the DHW inlet pipe, refer to diagram 15.15.

Disconnect the domestic hot water thermistor electrical connections

Remove hot water thermistor.

NOTE: When reconnecting electrical connections, polarity is not important.

Carry out a functional test of the controls.

15.20 Primary Flow Thermistor




For access, refer to section 15.1.

The primary flow thermistor is situated underneath the heat exchanger, refer to diagram 15.16.


Remove the electrical connections from the thermistor.

Remove the thermistor noting its position on the flow pipe.

NOTE: When reconnecting, the polarity of the wiring to thermistors is not important.



15 Replacement of Parts



15.21 Primary Return Thermistor

For access, refer to section 15.1.

Refer to diagram 15.17.

Remove the electrical connections from the thermistor.

Remove the thermistor and noting its position on the return pipe.

NOTE: When reconnecting, the polarity of the wiring to thermistors is not important.

15.22 Automatic Air Vent

For access, refer to section 15.1.

Refer to section 15.1 and drain the boiler primary circuit.

Refer to diagram 15.18.

Remove the retaining clip to release the automatic air vent.

Fit the new automatic air vent and 'O' ring ensuring the vent cap is left loose.

15.23 Water Pressure Sensor

For access, refer to section 15.1.



Refer to section 15.1 and drain the boiler primary circuit.

Refer to diagram 15.19.

Disconnect the electrical lead and withdraw the lead plug.

Remove the retaining clip to remove the low water pressure sensor.

Fit new 'O' ring.



15 Replacement of Parts

15.24 Plate-to-Plate Heat Exchanger

For access, refer to section 15.1.

Refer to section 15.1 to drain the boiler primary circuit.

Refer to section 15.1 and drain the boiler hot water circuit.

Refer to diagram 15.20.

Remove the four screws securing the plate-to-plate heat exchanger to the hydroblock.

There will still be water present so carefully pull the plate-to-plate heat exchanger upwards to remove.


When replacing the plate-to-plate heat exchanger ensure that the four rubber seals are fitted into the hydroblock.

NOTE: The plate-to-plate heat exchanger only fits one way.

Open the cold-water isolation valve and slowly open a hot water tap to remove air.

Close the hot water tap and check for any leaks.

Open the heating circuit isolation valves, re-pressurise the system as necessary.



15 Replacement of Parts

15.25 Hydroblock and Bypass Tube

For access, refer to section 15.1.

IMPORTANT: To replace the bypass tube the LH and RH hydroblocks will need to be removed. The following procedure must also be used for the replacement of either the LH or RH hydroblock.

Refer to section 15.1 and drain the boiler primary circuit and the boiler hot water circuit.

Isolate the gas supply at the gas service cock, see diagram 12.1.

Remove the silencer, refer to section 15.3.

Remove the plate to plate heat exchanger, refer to section 15.24.

Remove the low water pressure sensor from the LH hydroblock, refer to section 15.23.

Remove clips from the plastic LH and RH hydroblocks retaining the DHW, DCW and primary flow pipes, see diagram 15.21.

Remove the primary flow pipe from the LH hydroblock.

Remove the CH filter from the primary flow pipe port in the LH hydroblock. The filter is a push-fit in the hydroblock port.

Undo the union nuts on the CH outlet pipe and gas pipe at the connections between the top and bottom modules.

Undo the locknuts retaining the CH outlet pipe and the gas pipe to the boiler chassis.

Rotate the gas pipe upwards and clear of the chassis panel.

Remove the 3 screws which retain the three way valve, refer to section 15.16.

Grip the LH and RH hydroblocks simultaneously and lift clear of the spigots on the mounting bracket. The RH hydroblock should be drawn upwards past the plastic three way valve body.


NOTE: Before removing the bypass tube from the hydroblocks, take note of the tube position and orientation.

Fit the new bypass tube with new 'O' ring seals and re-assemble to hydroblocks.

NOTE: Before lowering the assembly onto the bracket spigots, ensure that the two port axis in each hydroblock run parallel to each other and also that the bottom faces of the hydroblocks are level and aligned.

Lower the assembly onto the bracket ensuring that the brass washers on the DHW and DCW pipes are not displaced. Check also that the seals on the front of the RH hydroblock remain in place as it slides past the three way valve body. Before refitting the plate to plate heat exchanger ensure that the four rubber seals are in place, two in the LH and two in the RH hydroblock.

Fit new 'O' rings to pipes.



15 Replacement of Parts

15.26 Filling Loop

For access, refer to section 15.1.

Refer to section 15.1 and drain the boiler hot water circuit.

Refer to diagram 12.2.

Undo the union nuts on the filling loop valve and the double check inlet valve to remove the filling loop.

Fit new 'O' rings.

After replacing the filling loop open the cold-water isolation valve and slowly open a hot water tap to remove air. Close the hot water tap and check for any leaks.

IMPORTANT: To comply with the water regulations the flexible hose must be disconnected from the double check inlet valve - undo the nut and pull the flexible hose from the valve.

15.27 Automatic Bypass Valve

For access, refer to section 15.1.

Refer to section 15.1 and drain the boiler primary circuit.

Refer to diagram 15.22.

Remove the retaining clip to remove the bypass valve.

Fit new 'O' rings.

Replace the bypass valve, refill, vent and pressurise the boiler.

Adjust the bypass as described in commissioning, see section 12.7.

15.28 Pressure Reducing Valve

For access, refer to section 15.1.

Refer to diagram 15.23.

Slacken the three screws securing the pipe retaining bracket, see diagram 8.3.

Undo the union connection at the isolation valve and then the union nuts to remove the reduced pressure zone valve.

Fit new 'O' rings.

15.29 Safety Relief Valve

For access, refer to section 15.1.

Refer to diagram 15.23.

Undo the two nuts securing the safety relief valve pipe and remove.

Loosen the grub screw to remove the safety relief valve.

15.30 Temperature and Pressure Relief Valve

For access, refer to section 15.1.

Refer to section 15.1 and drain the boiler hot water circuit.

Refer to diagram 15.24.

Undo the union nut on the right hand side of the valve and disconnect pipe, unscrew the valve body to remove.

Apply the sealant supplied before replacing the relief valve.




Diagram 15.22




Diagram 15.23




Diagram 15.24

15 Replacement of Parts

15.31 Immersion Heater

For access, refer to section 15.1.

Refer to section 6.3 and drain the hot water storage tank.


Remove the flexible condensate hose from the condensate trap and siphonic drain, see diagram 13.15.

Isolate any electrical connections to the immersion heater.

Unscrew the large locknut holding the immersion heater in place on the hot water tank, see diagram 15.25.

Remove immersion heater and gasket.

When replacing the immersion heater a new gasket is also supplied.



15.32 Condense Trap & Siphonic Drain

For access, refer to section 15.1.

Remove the flexible condensate hose by pulling out of condensate trap and siphonic drain, see diagram 13.15.

Refer to diagram 15.25.


Remove the securing screw holding the trap/drain.

Remove the float to clean it. When replacing, ensure that the float is inserted correctly as shown in diagram 15.26.

Flush water through the trap/drain to remove any remaining solids.

Check for any debris in the outlet pipe of the condensate trap and siphonic drain and clean as necessary.

Reassemble and refit.



15 Replacement of Parts

15.33 Access to Switches and User Interface

For access, refer to section 15.1.

Release the front of the control box by carefully pushing on the retaining clips to release, see diagram 15.27. Carefully rotate the control box front forward on its hinges to gain access to electrical connections, main PCB and user interface.

Do not allow the front of the control box to swing down and be loosely held by its electrical connections.

15.34 Main PCB

For access, refer to section 15.33.

Remove the electrical connections to the PCB.

Ease back the four PCB retaining clips and withdraw the PCB from the retaining lugs, see diagram 15.28.

When refitting the control box cover ensure the leads do not become trapped.

15.35 Fuse, Main PCB - Control Box

For access, refer to section 15.33.

The fuse is located at top left hand side of the main PCB, see diagram 15.28.

15.36 User Interface

Refer to section 15.33 for access.




Remove the main PCB, refer to section 15.34.

Remove the electrical connection.

Gently ease back the retaining clips, see diagram 15.29.

Withdraw the board.

When replacing the board refer to instructions supplied with replacement PCB.



16 Spare Parts

16.1 Spare Parts

When ordering spare parts, contact Glow-worm's own service organisation using the telephone number on the inside front cover of this booklet. Please quote the name of the appliance and serial number, to be found on the data label. If ordering from British Gas also quote the G.C. number of the part.

Key No.	Part No.	Description	GC Part No.
1	103565	Plate to Plate Heat Exchanger	*****
2	2000460124	Igniter Unit	*****
3	256700	DHW Thermistor	*****
4	048940	Burner	*****
5	507010	Flow/Return Thermistor	*****
6	980632	Burner Door Seal	*****
7	0020022579	Domestic Pump	*****
8	043123	Electrode	*****
9	0020005804	Central Heating Pump	*****
10	103516	Safety Discharge valve	*****
11	0020012959	Appliance Interface	*****
12	053349	Gas Valve	*****
13	0020016405	Fan	*****
14	0020026285	Main PCB	*****
15	*****	Fuse	*****
16	101050	Primary Expansion Vessel	*****
17	0020022569	Domestic Expansion Vessel	*****
18	0020023005	Temperature & Pressure Relief Valve	*****
19	*****	6 bar Safety Relief Valve	*****
20	0020022759	Immersion Heater	*****
21	253550	NTC	*****
22	253586	Water Pressure Switch	*****

16 Spare Parts

13325





Diagram 16.1





0020023706

0020023706-02 08.06

Glow-worm, Nottingham Road, Belper, Derbyshire. DE56 1JT


Because of our constant endeavour for improvement, details may vary slightly from those shown in these instructions.

Ultrapower sxi Flueing Options & Accessories



Flueing Options & Accessories

Horizontal Flue Options: Top Rear



L = Flue length, measured from outside wall face to centre line of flue outlet. If **L** is less than 589mm then only the horizontal flue is required.

If **L** is greater than 589mm then extensions are required. If **L** is less than 384mm then use horizontal top flue A2043400, which can be cut to suit a minimum wall thickness of 75mm.

X = wall thickness.

Z = distance from centre line of flue outlet to inside wall face.

The horizontal flue can be extended by up to 8m. The maximum flue length with extensions must not be exceeded (refer to **L** in table to the right).


For each additional 90° or 2 x 45° bends fitted, the maximum flue length must be reduced by 1m.

The vertical flue adaptor E is required for vertical flue connections to the boiler.


	Model	L Max with Extensions	X (mm)		Z	A Horizontal Telescopic Flue A2043600
			Min	Max		
A	Ultrapower 100sxi 170sxi	8m	239	444	145	

Horizontal Flue Accessories

	B	C	D	E
	45° Bend 2000460485 (2 off)	90° Bend 2000460484 (1 off)	0.5m Extension 2000460481 (1 off) or 1m Extension 2000460482 (1 off) or 2m Extension 2000460483 (1 off)	Vertical Flue Adaptor A2024600



Horizontal Flue Options: Top Side



L = Flue length, measured from outside wall face to centre line of flue outlet.

If **L** is less than 589mm then only the horizontal flue is required.

If **L** is greater than 589mm then extensions are required. If **L** is less than 384mm then use horizontal top flue A2043400, which can be cut to suit a minimum wall thickness of 75mm.

X = wall thickness.

Y = distance from the side of the boiler to the inside wall face

Z = distance from centre line of flue outlet to the side of the boiler.


Flueing Options & Accessories

The horizontal flue can be extended by up to 8m. The maximum flue length with extensions must not be exceeded (refer to **L** in table below)


For each additional 90° or 2 x 45° bends fitted, the maximum flue length must be reduced by 1m.

The vertical flue adaptor E is required for vertical flue connections to the boiler.

	Model	L Max with Extensions	X (mm)		Z	A	Horizontal Telescopic Flue A2043600
			Min	Max			
	Ultrapower 100sxi 170sxi	8m	-	190	394	Left	
			198	403	181	Right	



Vertical Flue Options



L = Flue length, measured from the top of the boiler to the underside of the roof flashing. Maximum flue length is 12m plus vertical roof terminal.

The maximum flue length must not be exceeded (refer to **L** in table opposite).


For each 90° or 2 x 45° bends fitted the maximum flue length must be reduced by 1m.

Vertical flue options use the same 100mm diameter flue components as the horizontal flue options.

The vertical flue adaptor **E** is required for vertical flue connections to the boiler.

Horizontal sections must have a continuous fall of at least 2.5° (44mm/metre) back to the boiler.

	Model	L Max with Extensions	Description of Parts	Part Number
	Ultrapower 100sxi 170sxi	12m	D 0.5m Extension (1 off) or	2000460481
			D 1m Extension (1 off) or	2000460482
			D 2m Extension (1 off)	2000460483
			E Vertical Flue Adaptor	A2024600
			F Vertical Roof Terminal	2000460480



Vertical Flue Accessories

	B	C	D
	45° Bend (2 off) 2000460485	90° Bend 2000460484	0.5m Ext 2000460481 1m Ext 2000460482 2m Ext 2000460483
	E Vertical Flue Adapter A2024600	F Vertical Roof Terminal 2000460480	G Pitched Roof Flashing 2000460479
	H Flat Roof Flashing 2000460478	I Sliding Sleeve 2000460487	J Fixing Bracket (5 off) 2000460486
		K Telescopic Extension A2036900	

Flueing Options & Accessories

Twin Flue Options


$L = L1 + L2$ Maximum available combined flue length (L1 air inlet and L2 flue outlet), measured from top of boiler (not including terminals)

Maximum flue length is 40m (L1 + L2) plus terminals.


For each 90° or 2 x 45° bends fitted the maximum flue length must be reduced by 1m.

Air inlet and flue outlet terminals must be installed so that they


Twin Flue Adaptor

K Twin Flue Adaptor A2011000	Model	i(mm)	ii(mm)	iii(mm)
	Ultrapower 100sxi 170sxi	274	120	181

Option 1

	Model	$L = L1 \text{ air} + L2 \text{ flue}$ Max Combined Flue Length	Description of Parts	Part Number
	Ultrapower 100sxi 170sxi	40m	F Vertical Roof Terminal	2000460480
			K Twin Flue Adaptor	A2011000
			L 1m Extension (1 off)	A2011100
			O 45° Bend (2 off)	A2011300
			S Twin Pipe to Concentric Adaptor	A2011600

Option 2


	Model	$L = L1 \text{ air} + L2 \text{ flue}$ Max Combined Flue Length	Description of Parts	Part Number
	Ultrapower 100sxi 170sxi	40m	F Vertical Roof Terminal	2000460480
			K Twin Flue Adaptor	A2011000
			L 1m Extension (1 off)	A2011100
			N 90° Bend (1 off)	A2011400
			P Horizontal Terminal	A2011200
			R Single Pipe Adaptor	A2011500

are exposed to external air.


The flue outlet must be above the air inlet if mounted vertically.

Horizontal sections must have a continuous fall of at least 2.5° (44mm/metre) back to the boiler.




The minimum distance between flue and air terminals is 120mm (between terminal centres).



Option 3

	Model	$L = L1 \text{ air} + L2 \text{ flue}$ Max Combined Flue Length	Description of Parts	Part Number
	Ultrapower 100sxi 170sxi	40m	K Twin Flue Adaptor	A2011000
			L 1m Extension (1 off)	A2011100
			N 90° Bend (1 off)	A2011400
			P Horizontal Terminal	A2011200

Twin Flue Accessories

	F	G	H	J
	Vertical Roof Terminal 2000460480	Pitched Roof Flashing 2000460479	Flat Roof Flashing 2000460478	Ø 100mm Fixing Bracket 2000460486 (5 off)
	K	L	M	N
	Twin Flue Adaptor A2011000	1m Extension A2011100	Ø 80mm Fixing Bracket A2012800 (5 off)	90° Bend A2011400
	O	P	R	S
	45° Bend A2011300 (2 off)	Horizontal Terminal A2011200	Single Pipe Adaptor A2011500	Twin Pipe to Concentric Adaptor A2011600



Nottingham Road, Belper, Derbys DE56 1JT

Tel: (01773) 824639 Fax: (01773) 828555

www.glow-worm.co.uk

Ultrapower sxi

High Efficiency System Store

Instructions for Use

To be left with the user

WARNING

GAS LEAK OR FAULT

Turn off the gas emergency control valve immediately. Eliminate all sources of ignition, i.e. smoking, blowlamps, hot air guns etc. Do not operate electrical lights or switches either on or off.

Open all doors and windows, ventilate the area.

METAL PARTS

This boiler contains metal parts (components) and care should be taken when handling and cleaning, with particular regard to edges.

SEALED COMPONENTS

Under no circumstances must the user interfere with or adjust sealed parts.

Glow-worm service call: 01773 828100 Technical helpline: 01773 828300

General and Sales enquiries Tel: 01773 824639 Fax: 01773 820569




*The code of practice for the installation,
commissioning & servicing of gas central heating*

100sxi

G.C. No. 41-019-09

170sxi

G.C. No. 41-019-10



Contents	Page
Important Information	5
Boiler Design & Clearances	6
Boiler Safety Devices	7
Servicing, Maintenance & Spare Parts	8
User Control Panel	9
Lighting the Boiler	10
Adjusting Temperature	11
Setting the Clock	12
Setting the Programmer	13
Advancing Programmer	14
Fault Finding	15

These instructions are an integral part of the boiler and must, to comply with the current issue of the Gas Safety (Installation and Use) Regulations, be left with the user.

Please read these instructions and follow them carefully for the safe and economical use of your boiler.

Important Information

Gas Safety (Installation and Use) Regulations

In your own interests and that of safety, it is the Law that ALL gas appliances have been installed by a **competent person** in accordance with the current issue of the regulations.

Gas Category

This boiler is for use only on G20 natural gas.

Testing and Certification

This boiler is tested and certificated for safety and performance. It is, therefore, important that no alteration is made to the boiler, without permission, in writing, by Glow-worm.

Any alteration not approved by Glow-worm, could invalidate the certification, boiler warranty and may also infringe the current issue of the statutory requirements.

Electrical Connection

Boiler

The boiler **MUST** be earthed.

The boiler **MUST** be connected to a permanent 230V ac, 50Hz supply, fused at 3A.

Connection of the whole electrical system of the boiler, including any heating controls, to the electrical supply must be through one common isolator.

The colours of three core flexible cable are, blue - neutral, brown - live, green and yellow - earth.

Immersion Heater

The immersion **MUST** be earthed.

The immersion **MUST** be connected to a permanent 230V ac, 50Hz supply, fused at 13A.

Boiler Design & Clearances

Description

The Ultrapower sxi is a high efficiency central heating appliance, close coupled to an un-vented cylinder. The pump, expansion vessels and associated safety devices are all fitted within the appliance, providing a one box solution for properties requiring a high domestic hot water demand. The intelligent control system is designed for both simple operation and maximum control. Once the controls are set the boiler will operate automatically.


Additionally an immersion heater is supplied fitted to the cylinder. It is intended for use as a back up should the boiler fail, it will not give optimum DHW performance.

Plumbing from flue terminal

Like all condensing boilers it will produce a plume of condensation from the flue terminal in cool weather. This is due to the high efficiency and hence low flue gas temperature of the boiler. It is normal and not a fault indication.

Compartment or Cupboard Installations

Ventilation is not required for compartment or cupboard installations. Do not use the compartment or cupboard for storage.



Boiler Safety Devices

Boiler Shutdown

The boiler software is designed to recognise the potential for an overheat lockout and will shutdown before this happens. To restart the boiler, press the reset button, see diagram 2.

If the boiler fails to resume normal operation and all external controls are calling for heat, then call your Installation/Service company or Glow-worm service.

Frost Protection

With the gas and electric supplies ON and irrespective of any room thermostat setting, the integral frost protection device will operate the pump when the temperature of the boiler water falls below 8°C.

The pump will stop after 10 minutes if the temperature is higher than 10°C or has already reached 35°C.

The burner will only activate if the boiler temperature does not reach 10°C after 30 minutes or at any time if the temperature drops to 5°C.

The burner will switch off when the temperature reaches 35°C.

NOTE: Any other exposed areas of the system should be protected by a separate frost thermostat.

Cylinder Protection

The cylinder also has integral frost protection and should the temperature fall below 10°C the cylinder water will be heated to 15°C.

Condensate Drain Blockage

As a safety feature the boiler will stop working if the condensate drain becomes blocked. During freezing conditions this may be due to the forming of ice in the condensate drain external to the house. Release an ice blockage by the use of warm cloths on the pipe. The boiler should then restart. Contact your Installation/Service company or Glow-worm service if the fault persists.

Disinfection Cycle

The cylinder has a built in disinfection cycle which raises the water temperature to 70°C for 1 hour every Wednesday at 2.00am.

Safety Discharge Valves

Safety discharge valves and discharge pipes are fitted to the boiler. These valves **MUST NOT** be touched. If there is any discharge from the pipes, switch off the boiler electrical supply, then call your Installation/Service company or Glow-worm service.

Servicing, Maintenance & Spare parts

General Note

Servicing/maintenance should be carried out by a **competent person** in accordance with the rules in force in the countries of destination.

If this boiler is installed in a rented property in the UK there is a duty of care imposed on the owner of the property by the current issue of the Gas Safety (Installation and Use) Regulations, Section 35.

Servicing

To ensure the continued efficient and safe operation of the boiler it is recommended that it is checked and serviced at regular intervals. The frequency of servicing will depend upon the site conditions and usage, but in general, once a year should be enough.

To obtain service, please call your installer or Glow-worm's own service organisation using the telephone number on the inside front cover of this booklet.

Cleaning

The boiler casing can be cleaned using a mild liquid detergent with a damp cloth, then a dry cloth to polish.

Do not use any form of abrasive or solvent cleaner as you may damage the paintwork.

Frost Protection

If the mains electricity and gas services are to be turned off for any long periods during severe weather, it is recommended that the whole system, including the boiler, should be drained to avoid the risk of freezing.

Sealed Water Systems

The draining, refilling and pressurising **MUST** be carried out by a **competent person**, contact your Installation/Servicing company or Glow-worm Service.

Spare Parts

REMEMBER, When replacing a part on this boiler, use only spare parts that you can be assured conform to the safety and performance specification that we require. Do not use reconditioned or copy parts that have not been clearly authorised by Glow-worm.

If replacement parts are required contact Glow-worm's own service organisation using the telephone number on the inside front cover of this booklet.

Please quote the name and model of the boiler.


The name badge is on the top front case, and the model label is on the top edge of the bottom front panel, pull the panel forward slightly to reveal the label.

If in doubt seek advice from the local gas company or Glow-worm's own service organisation using the telephone number on the inside front cover of this booklet.

User Control Panel

General Description

The User Control panel consists of three toggle buttons, a reset button and display, which will indicate with symbols the status of the boiler, refer to diagram 2.



Lighting the Boiler

Initial Lighting


Check that all isolating valves and the gas cock, on the appliance are open and that water flows from the hot water taps, then close taps, refer diagram 3.

Note: If you are in any doubt about the boiler being filled with water contact your installer or Glow-worm's own service organisation using the telephone number on the inside front cover of this booklet.

Do not operate the boiler without water.

1. With no demand from any external controls, switch on the electrical supply to the boiler.

Note: If the electrical supply has been interrupted for any reason, you may need to set the clock and day before continuing, refer to diagram 5.



2. Select your required function by pressing " Mode ", scroll through your options and select one of the following:-

Timed central heating with domestic hot water.



Constant central heating with domestic hot water.



Domestic hot water only.



Boiler functions ALL swicthed off.

OFF

3. Turn ON your external controls and select the room temperature required.

The boiler will operate automatically.

Note: The display will indicate the Heating system pressure in bar or:

- Water temperature, when heating is on.
- Domestic Hot Water temperature setpoint, when there is a demand.
- Fault Code (see section Fault Finding)

Adjusting Temperature

Domestic Hot Water

Domestic hot water has priority over central heating.


The temperature is factory preset to the minimum 40°C, but can be adjusted to a maximum of 62°C as required, refer to diagram 4.

Economy Setting

The "ECO" setting of 50°C is recommended and ideally suited to normal family use.

Central Heating

The temperature is factory preset to the minimum 38°C, but can be adjusted to a maximum of 82°C as required, refer to diagram 4.




Setting the 24 hour Clock.

To set the clock, refer to diagram 5.

STEP 1




Press and hold "PROG" 5 secs.
the "hours" symbol will flash.



13177

STEP 2

Press the "+" or the "-"
to set the hour.



STEP 3



Press "PROG" to confirm.
The process will automatically scroll to minutes,
then days, set as previously described.

Diagram 5

Setting the Programmer

The symbol indicates - Timed Central Heating

factory preset timed intervals are:-

Monday to Friday - ON 6.00 - OFF 8.00 ON 16.00 - OFF 23.00



Saturday & Sunday ON 8.00 OFF 23.00

The symbol indicates - Domestic Hot Water



factory preset timed intervals are:-

Monday to Sunday - ON 6.00 - OFF 24.00



To alter the times to suit your requirements, follow "Steps" 1 to 4

STEP 1  


Press the "PROG" button once to view Mondays factory default central heating running times.


STEP 2  

Press + or - to move the flashing cursor to the desired time.


STEP 3  

Press "+" to add a time segment or "-" to remove a time segment.



STEP 4 

Press "PROG" to validate the time intervals. The days will automatically change, repeat the process or refer to the "Copy Function". After the 7th. day the "Domestic Hot Water" time intervals will be displayed, follow the same process steps 1 to 4.

STEP 4 

Press "PROG" to validate the time intervals. The days will automatically change, repeat the process or refer to the "Copy Function". After the 7th. day the process will exit to show the boiler status.

IMPORTANT NOTE.
If there is no activity within a 2 minute period whilst setting the times, then the times will revert to the previous periods and you will have to press "PROG" to continue.

STEP 4 - COPY FUNCTION.
When validating the timed intervals you can hold the "PROG" button for 5 seconds and the times will be duplicated onto the next day, hold the button continually and the times will be copied to all days.

13180

Diagram 6

Advancing the Programmer

Advancing the timed central heating programmer ON /OFF times

This function will only work when the appliance is in timed operating mode, "Clock symbol".



Refer to diagram 8.

The activated/deactivated segments will flash for 5 seconds.

Advancing the Integral Domestic Hot Water Cylinder programmer ON /OFF times

Refer to diagram 8.

The activated/deactivated segments will flash for 5 seconds.



Fault Finding

Appliance fails to light

The LCD will display a flashing 'F' and code number, press the reset button on the control panel, see diagram 2.

If the display shows a flashing pressure of 0.4bar or less, then you will need to pressurise the system as described below.

If any fault persists, contact your installer/service provider or Glow-worm Service, using the telephone number on the inside front cover of this booklet.


Filling Central Heating System

1. Ensure that the filling loop flexible hose is securely connected to the double check inlet valve, see diagram 9.
2. Fully open tap "A", then gradually open tap "B" to fill the heating system to a pressure of 1.0bar. When completed close the filling taps.
3. **IMPORTANT:** To comply with the water regulations the flexible hose must be disconnected from the double check inlet valve - undo the nut and pull the flexible hose from the valve.


Electrical Supply Failure

The boiler will not work without an electrical supply and normal operation of the boiler should resume when the electrical supply is restored.

If the boiler does not resume normal operation, check the external controls, it may be necessary, to "reset" the boiler, refer to the section, "Boiler Safety Devices".



0020023707-02
04.08.06



0020023707

Because of our constant endeavour for improvement, details may vary slightly from those shown in these instructions.

Glow-worm, Nottingham Road, Belper, Derbyshire. DE56 1JT