



# TEMPRA 30

**COPPER WALL-MOUNTED SYSTEM,  
GAS FIRED BOILER FOR CENTRAL HEATING,  
FAN ASSISTED, ROOM SEALED COMPARTMENT,  
ELECTRONIC FLAME IGNITION AND CONTROL**



**INSTALLATION, SERVICE AND USER  
INSTRUCTIONS**



### IMPORTANT

**Your "benchmark" Installation, Commissioning and Service Record Log Book will be enclosed in your customer information pack.**

**"This record must be completed and left with the end user"**

**"All CORGI Registered Installers carry a CORGI ID card and have a registration number. Both should be recorded in your central heating log book. You can check with the CORGI register by calling CORGI on 01256 372300".**

Ferroli is a member of the Benchmark initiative and fully supports the aims of the programme. Benchmark has been introduced to improve the standards of installation and commissioning of central heating systems in the UK and to encourage the regular servicing of all central heating systems to ensure safety and efficiency. Please see installation and servicing guidelines.

### **CE MARK**

CE mark documents that the Ferroli gas appliances comply with the requirement contained in European directives applicable to them.

In particular, the appliances comply with the following CEE directives and the technical specifications provided from them:

- Gas appliances directive 90/396
- Efficiencies directive 92/42
- Low tension directive 73/23 (modified from the 93/68)
- Electromagnetic compatibility directive 89/396 (modified from the 93/68)

### **INDEX**

|  |    |
|--|----|
| 1. DESCRIPTION .....                               | 3  |
| 2. TECHNICAL AND DIMENSIONAL CHARACTERISTICS ..... | 4  |
| 3. INSTALLATION DETAILS.....                       | 9  |
| 4. COMMISSIONING AND TESTING .....                 | 28 |
| 5. ADJUSTMENT AND GAS CONVERSION .....             | 29 |
| 6. MAINTENANCE AND CLEANING .....                  | 31 |
| 7. REPLACEMENT OF PARTS.....                       | 33 |
| 8. FAULT FINDING.....                              | 37 |
| 9. ELECTRICAL AND FUNCTIONAL SCHEME .....          | 39 |
| 10. USER INSTRUCTIONS .....                        | 41 |

---

## 1. DESCRIPTION

---

### 1.01 Introduction

The **Tempra 30** is defined as a "room sealed" boiler, all air required for combustion is taken from outside the room in which it is installed. It is a new high performance gas fired heat generator for central heating. A special feature of this boiler is its built-in electronic flame ignition and control unit making burner operation completely automatic and safe. The main components are as follows:

- Copper heat exchanger consisting of four finned tubes specifically shaped for high efficiency.
- Ceramic fibre insulated combustion chamber
- 16 stainless steel bladed burners specifically designed for this boiler.
- Fan for discharge of combustion products and intake of combustion air.
- Differential air pressure switch. For safety reasons, this ensures the burner ignites only when the fan is functioning correctly.
- Hermetically sealed compartment made from corrosion-resistant steel enclosing the above components.
- Combination gas safety valve with modulator, complete with pressure stabiliser.
- Pressure relief valve for the central heating circuit set to open at 3 bar.
- Built-in Expansion vessel.
- Variable speed pump.
- Central heating flow temperature adjustment thermostat.
- Central heating limit thermostat.
- Overheat safety thermostat.
- Electronic control unit for automatic flame ignition and control.
- Central heating flow temperature sensor.

### 1.02 Instructions and regulations

Assembly, installation, first start up and maintenance must be carried out by competent persons only, in accordance with all current technical regulations and directives.

### C.O.S.H.H.

Materials used in the manufacture of this appliance are non hazardous and no special precautions are required when servicing.

### Related Documents

**This appliance must be installed strictly in accordance with these instructions.**

The Gas Safety Regulations (Installations & Use) 1996.

The Local Building Regulations.

The Building Regulations.

The Buildings Standards (Scotland - Consolidated) Regulations.

British Standards Codes of Practice:

|                  |  |
|------------------|--|
| B.S. 7593        | TREATMENT OF WATER IN DOMESTIC HOT WATER CENTRAL HEATING SYSTEMS |
| B.S. 5546        | INSTALLATION OF HOT WATER SUPPLIES FOR DOMESTIC PURPOSES         |
| B.S. 5440 Part 1 | FLUES  |
| B.S. 5440 Part 2 | AIR SUPPLY   |
| B.S. 5449        | FORCED CIRCULATION HOT WATER SYSTEMS                             |
| B.S. 6798        | INSTALLATION OF GAS FIRED HOT WATER BOILERS                      |
| B.S. 6891        | GAS INSTALLATIONS  |
| B.S. 7671        | IEE WIRING REGULATIONS   |
| B.S. 4814        | SPECIFICATION FOR EXPANSION VESSELS                              |
| B.S. 5482        | INSTALLATION OF LPG  |

Model Water Bye Laws

For Northern Ireland the rules in force apply

## 2. TECHNICAL AND DIMENSIONAL CHARACTERISTICS

### 2.01 Technical information

**Tempra 30** boilers are central heating generators and are produced as standard to function with natural gas or Liquid Petroleum Gas converted appliances.




Fig. 1

## Technical Data

| <b>Output</b>                                     |                    | <b>Pmax</b> | <b>Pmin</b> |
|---|--------------------|-------------|-------------|
| Nominal Heat Input (Net)                          | kW                 | 33,1        | 14,5        |
| Nominal Heat Output                               | kW                 | 30,0        | 12,7        |
| <b>Gas supply</b>                                 |                    | <b>Pmax</b> | <b>Pmin</b> |
| Main injectors, Natural Gas (G20)                 | mm                 | 16 x 1.25   |             |
| Supply pressure, Natural Gas (G20)                | mbar               | 20,0        |             |
| Burner pressure, Natural Gas (G20)                | mbar               | 13,0        | 2,5         |
| Natural gas rate (G20)                            | nm <sup>3</sup> /h | 3,50        | 1,53        |
| Main injectors, LPG (G31)                         | mm                 | 12 x 0.75   |             |
| Supply pressure, LPG (G31)                        | mbar               | 35,5        |             |
| Burner pressure, LPG (G31)                        | mbar               | 35,5        | 7,0         |
| LPG gas rate (G31)                                | kg/h               | 2,57        | 1,13        |
| <b>Central heating</b>                            |                    |             |             |
| Maximum central heating operating temperature     | °C                 | 90          |             |
| Maximum central heating operating pressure        | bar                | 3           |             |
| Safety valve                                      | bar                | 3           |             |
| Minimum central heating operating pressure        | bar                | 0,8         |             |
| Expansion vessel capacity                         | litres             | 10          |             |
| Expansion vessel pre-fill pressure                | bar                | 1           |             |
| Hot water capacity                                | litres             | 1,7         |             |
| <b>Dimensions, weights, fittings</b>              |                    |             |             |
| Height  | mm                 | 760         |             |
| Width   | mm                 | 460         |             |
| Depth   | mm                 | 363         |             |
| Weight with packaging                             | kg                 | 45          |             |
| Gas system fittings (with isolation valve fitted) | mm                 | 22          |             |
| C.H. flow (with isolation valve fitted)           | mm                 | 22          |             |
| C.H. return (with isolation valve fitted)         | mm                 | 22          |             |
| <b>Power supply</b>                               |                    |             |             |
| Max Power Absorbed                                | W                  | 125         |             |
| Power supply voltage/frequency                    | V/Hz               | 230/50      |             |
| Index of protection                               | IP                 | 44          |             |

N.B. - **The gas pressures at the burner and gas flows during the central heating phase given in the table refer to nominal boiler output. To reduce this output (where necessary), gas pressure must be reduced until the required output level is reached (see figures 4 and 5).**

- Maximum working temperature for central heating flow: 85°C

## 2.02 Boiler main components




Fig. 2

## 2.03 Boiler water flow diagram




Fig. 3

### Key

- 5 Room sealed compartment
- 7 Gas inlet
- 10 Central heating flow
- 11 Central heating return
- 14 Safety valve
- 16 Fan
- 19 Combustion chamber
- 20 Burner assembly
- 21 Main injector
- 22 Burner
- 26 Combustion chamber insulation
- 27 Copper heat exchanger
- 28 Flue collector from heat exchanger
- 29 Internal flue exit
- 32 Central heating pump
- 34 Central heating flow temperature sensor

- 36 Automatic air vent valve
- 43 Air pressure switch
- 44 Gas valve
- 49 Safety overheat thermostat
- 50 Central heating flow limit thermostat
- 56 Expansion vessel
- 62 Time clock (option)
- 63 Central heating temperature adjustment
- 81 Ignition electrode
- 82 Sensor electrode
- 84 Primary gas valve solenoid
- 85 Secondary gas valve solenoid
- 98 On/Off/Reset switch
- 145 Central heating pressure gauge
- 187 Flue restrictor

## 2.04 Central heating adjustment (not normally required)

To adjust boiler heat input (thus also regulating heat output to the central heating water) simply adjust the main burner via the electronic control board (fig. 4 and see paragraph 5.04).

The diagrams indicate the variation in heat output to the water as burner working pressure is varied.

Adjusting boiler output to the actual requirements of the central heating system will minimise boiler cycling thus saving fuel, varying the output has virtually no effect on the efficiency and combustion characteristics of the boiler.

### Diagram of pressures and outputs with Natural gas and with LPG (Propane)




Fig. 4

## 2.05 Pump characteristics

The pump head available for circulating the water is given in fig. 5.

**N.B.** - The pump is factory set at position 3. The pump is a Grundfos type 15-50 UPS series.


### Grundfos Pump performance graph

**Note** - Minimum flow through boiler heat exchanger at any time should not fall below 6 litres per minute.

If the total volume of water in the system exceeds 40 litres an additional expansion vessel must be fitted to the central heating return pipe.

- 1 2 3 Speed settings  
A Boilers pressure drop  
B Available pump head C.H.

Fig. 5



## SIZING OF ADDITIONAL EXPANSION VESSELS:

Deduct from the value given in the table the 10 litre vessel supplied.

### Note:

1. Fill C.H. installation to min. 1.5 bar.
2. Expansion vessel must be fitted to central heating return pipe.
3. The standard 10 litre expansion vessel is charged to 1 bar.
4. The additional expansion vessel should be charged to 1 bar.

| SAFETY VALVE SETTING (bar)  | 3.0                              |       |       |       |       |      |
|---|----------------------------------|-------|-------|-------|-------|------|
| VESSEL CHARGE PRESSURE (bar)  | 0.5                              |       | 1.0   |       | 1.5   |      |
| INITIAL SYSTEM PRESSURE (bar)   | 1.0                              | 1.5   | 2.0   | 1.5   | 2.0   | 2.0  |
| TOTAL WATER CONTENT OF SYSTEM   | EXPANSION VESSEL VOLUME (litres) |       |       |       |       |      |
| LITRES  |                                  |       |       |       |       |      |
| 25  | 3.5                              | 6.5   | 13.7  | 4.7   | 10.3  | 8.3  |
| 50  | 7.0                              | 12.9  | 27.5  | 9.5   | 20.6  | 16.5 |
| 75  | 10.5                             | 19.4  | 41.3  | 14.2  | 30.9  | 24.8 |
| 100   | 14.0                             | 25.9  | 55.1  | 19.0  | 41.2  | 33.1 |
| 125   | 17.5                             | 32.4  | 68.9  | 23.7  | 51.5  | 41.3 |
| 150   | 21.0                             | 38.8  | 82.6  | 28.5  | 61.8  | 49.6 |
| 175   | 24.5                             | 45.3  | 96.4  | 33.2  | 72.1  | 57.9 |
| 200   | 28.0                             | 51.8  | 110.2 | 38.0  | 82.4  | 66.2 |
| For syst. volumes other than those given above, mult. the syst. volume by the factor across | 0.140                            | 0.259 | 0.551 | 0.190 | 0.412 | 0.33 |

## Pressure loss diagram




Fig. 6



---

### 3. INSTALLATION DETAILS

---

#### Gas Safety (Installation & Use) Regulations

In the interest of safety, **it is the law** that all gas appliances are installed by a competent person in accordance with the above Regulations, Building Regulations/Building Standards Scotland, Codes of Practice, current I.E.E. Regulations and the byelaws of the Local Water Undertaking. **Failure to comply with the Regulations may lead to prosecution; it is your responsibility to ensure that the law is complied with.**

**N.B.** For Northern Ireland the rules in force apply.

**Important** - If the boiler is to be fitted in a timber framed building it should be fitted in accordance with the Institute of Gas Engineers document IGE/UP/7. If in doubt advice should be sought from the Local Supplier.

#### Location of Boiler

The installation of the Temptra 30 must be on a suitable non-combustible load bearing wall which will provide an adequate fixing for the boiler mounting bracket assembly. The location should be in an area where the water pipes will not be subjected to frost conditions. In siting the combination boiler the following limitations **must** be observed:

The boiler may be installed in any room or internal space, although particular attention is drawn to the requirements of the current I.E.E. wiring regulations and in Scotland the electrical provisions of the building regulations applicable in Scotland, with respect to the installation of the combination boiler in a room or internal space containing a bath or shower.

Where a room sealed appliance is installed in a room containing a bath or shower any electrical switch or appliance control utilising mains electricity must be situated so that it cannot be touched by a person using the bath or shower.

#### Air Supply

The room or compartment in which the boiler is installed does not require a purpose provided vent when using the standard concentric flue.

#### Flue System

The boiler allows the flue outlet to be taken from the rear of the boiler, from either side or vertically.

A standard flue length of 0.75 metres is provided. Alternative lengths of two or three metres can be supplied (equivalent to wall thicknesses of up to 565, 1815 and 2815mm for rear flues, deduct 91mm plus distance from side wall for side outlet flues). It is absolutely **essential, to ensure that products of combustion discharging from the terminal cannot re-enter the building, or enter any adjacent building, through ventilations, windows, doors, natural air infiltration or forced ventilation/air conditioning.**

#### Gas Supply

If necessary the local Gas supplier should be consulted, at the installation planning stage, in order to establish the availability of an adequate supply of gas.

An existing service pipe must **not** be used without prior consultation with the Local Gas supplier.

A gas meter can only be connected by the Local Gas supplier, or by a Local Gas suppliers Contractor.

Installation pipes should be fitted in accordance with BS6891-1988.

Appliance inlet working pressure must be 20mbar MINIMUM, for NG and 37 mbar minimum for LPG.

Pipework from the meter to the boiler must be of an adequate size.

The boiler requires 3.5 m<sup>3</sup>/h of natural gas, and 2,6 kg/h of LPG.

Do not use pipes of a smaller size than the combination boiler inlet gas connection.

The complete installation must be tested for gas soundness and purged as described in BS6891-1988. All pipework must be adequately supported. An isolating gas valve is provided and should be fitted on the boiler gas inlet. Please wait 10 minutes when lighting from cold before checking gas rate. **Gas pressures should be checked after the boiler has operated for 10 minutes to reach thermal equilibrium.**

## Central Heating

Detailed recommendations are given in BS6798, BS5449, BS6700 and CP342 Part 2. Pipework not forming part of the useful heating surface should be insulated to prevent any heat losses or possible freezing (i.e. in roof spaces or ventilated underfloor spaces). Drain taps should be positioned at the lowest point of the system in accessible locations to permit the whole system to be drained down. The drain taps should be in accordance with BS2879. Copper tubing to BS2871, Part 1 is recommended for water carrying pipework. Pipework in horizontal runs should have a gradient where possible to facilitate the removal of air. Ensure that the boiler heat exchanger is not a natural point for air collection. A typical heating system with domestic hot water circuit is illustrated in fig. 9.

**Important** - If thermostatic radiator valves are fitted **a automatic bypass must be fitted to ensure a minimum flow rate through the boiler of 6 l/min.** The bypass should be fitted as far as possible from the boiler.

## Make Up Water

Provision must be made for replacing water lost from the sealed system. Reference should be made to BS6798, for methods of filling and making up sealed systems. There must be no direct connection between the boiler's central heating system and the mains water supply. The use of mains water to charge and pressurise the system directly, is conditional upon the Local Water Byelaws. Again any such connection must be disconnected after use.

**Attention** - is drawn to the Model Water Byelaws.

Fittings manufactured from duplex (alpha-beta) brass are not acceptable for underground use and certain water undertakings will not accept their use above ground.

Ensure all pipework is adequately supported

**NOTE:** A by-pass that will ensure a minimum flow rate of 6 l/min. at all all time must be fitted as far as possible from the boiler if thermostatic radiator valves are fitted throughout.

**AUTOMATIC BY-PASS**  
The by-pass must be capable of passing 6 l/min of water when all the trv's are shut down





Fig. 7

## CLEARANCES:

\* 600mm minimum clearance for servicing access

Top clearance only applies to 100Ø concentric flue system

Fig. 8



## Terminal Position




Fig. 9

## Minimum dimensions of flue terminal positions

| Dimensions | Terminal position<br>(kW input expressed in net)                       | Balanced flues room sealed |
|------------|--|----------------------------|
|            |  | Fanned draught             |
| A          | Directly below an opening, air brick, opening windows, etc.            | 300 mm                     |
| B          | Above an opening, air brick, opening windows, etc.                     | 300 mm                     |
| C          | Horizontally to an opening, air brick, opening windows, etc.           | 300 mm                     |
| D          | Below gutters, soil pipes or drain pipes                               | 75 mm                      |
| E          | Below eaves  | 200 mm                     |
| F          | Below balconies or car port roof                                       | 200 mm                     |
| G          | From a vertical drain pipe or soil pipe                                | 150 mm                     |
| H          | From an internal or external corner                                    | 300 mm                     |
| I          | Above ground roof or balcony level                                     | 300 mm                     |
| J          | From a surface facing the terminal<br>(also see 6.1.2)                 | 600 mm                     |
| K          | From a terminal facing the terminal                                    | 1200 mm                    |
| L          | From an opening in the car port ( e.g. door, window) into the dwelling | 1200 mm                    |
| M          | Vertically from a terminal on the same wall                            | 1500 mm                    |
| N          | Horizontally from a terminal on the same wall                          | 300 mm                     |
| O          | From the wall on which the terminal is mounted                         | N/A                        |
| P          | From a vertical structure on the roof                                  | N/A                        |
| Q          | Above intersection with roof   | N/A                        |

**NOTE** N/A = Not applicable

\* In addition, the terminal should not be nearer than 150 mm (fanned draught) or 300 mm (natural draught) to an opening in the building fabric formed for the purpose of accommodating a built-in element such as a window frame.

### 3.01 Drilling Template (Top Flue Application)

Select suitable mounting position for boiler, using the template mark flue outlet and boiler mounting points. Drill two 10mm holes 90mm deep to accept the wall plugs, fit wall plugs. Fit two special wall plugs on the wall as described in the fig. 10a. Fasten the wall bracket to the wall using two standard nuts (M8). Mount the boiler on the wall bracket and fix using two standard nuts (M8). Using a core drill cut a 118mm diameter hole for the flue.




Fig. 10a




Fig. 10b

- 1. CH flow (22 mm)
- 4. Gas supply (22 mm)
- 6. CH return (22 mm)

### 3.02 Restrictor

For boiler operation, the restrictor supplied with the unit must be mounted following the instructions below. Determine the correct size of flue restrictor required. Before inserting the flue gas duct in the boiler, check that the restrictor fitted is correct and that it is correctly positioned (see fig. 11).




Fig. 11

### CHOICE OF RESTRICTOR:

- With **2 pipe system**:
  - Calculate the total flow resistance of the air and flue pipes in metres (cap. 3.04.2)
  - utilise the table shown below to choose the more suitable restrictor for the flow resistance calculated


| RESTRICTOR FOR TWO PIPE SYSTEM       |         |                     |
|--------------------------------------|---------|---------------------|
| Total flow resistance of flue system |         | Use restrictor size |
| minimum                              | maximum | mm                  |
| 0 m                                  | 15 m    | 47                  |
| 15 m                                 | 30 m    | 50                  |
| 30 m                                 | 40 m    | 52                  |
| 40 m                                 | 45 m    | No restrictor       |

- With **concentric systems**:
  - Choose correct restrictor from table below.

| RESTRICTOR FOR CONCENTRIC SYSTEM |                   |                     |
|----------------------------------|-------------------|---------------------|
| Flue lenght up to:               |                   | Use restrictor size |
| Concentric 60 / 100              | 1 bend + 1 meter  | 52 mm               |
|                                  | 1 bend + 3 meters | No restrictor       |
| Concentric 80 / 125              | 1 bend + 3 meters | 50 mm               |
|                                  | 1 bend + 4 meters | No restrictor       |
|                                  | 1 bend + 5 meters | No restrictor       |

### 3.03 Top Outlet Concentric Flue Connection

#### 3.03.1 Vertical concentric connection



A vertical connector can be supplied for vertical discharge with concentric pipes. The simple mounting and use of double lip gaskets at the joints makes this an extremely easy and safe option.

For flue length up to 1 m long the 50 mmØ restrictor is required. Longer than this no restrictor is required.

Fig. 12

#### 3.03.2 Horizontal concentric connection

A 90° bend (fig. 13) is supplied for the horizontal connection of air and flue gas pipes. This can be oriented towards the chosen wall in degrees of 45°.




Fig. 13

Slope downwards away from the boiler at a rate of about 3 mm/m to avoid rainwater entering the boiler.

### 3.03.3 Direct concentric back exit

Boiler could be converted for direct back exit as showed on picture 14.

A special kit is necessary for connecting the rear concentric pipe. Conversion procedure and installation instructions are inserted into the kit.




Fig. 14

### 3.03.4 Maximum concentric flue length

First table below shows the maximum flue lengths available for boilers with concentric systems.

For correct calculation remember to include the reduction for bends on second table. Please refer to 3.03 for use of restrictor

| Maximum flue lenght permissible | 100 mm concentric |            | Direct back exit         | 125 mm concentric |            |
|---------------------------------|-------------------|------------|--------------------------|-------------------|------------|
|                                 | Vertical          | Horizontal |                          | Vertical          | Horizontal |
| <b>Tempra 30</b>                | 4 m               | 3 m        | 1 m<br>(no bend allowed) | 5 m               | 5 m        |

**\*For horizontal Flueing the reduction for appliance bend or turret are already included.**

| Reduction for bend         |        |
|----------------------------|--------|
| 100 mm concentric bend 90° | 1 m    |
| 100 mm concentric bend 45° | 0,5 m  |
| 125 mm concentric bend 90° | 0,5 m  |
| 125 mm concentric bend 45° | 0,25 m |




Fig. 15a




Fig. 15b

### 3.04 Top Outlet: Two Pipe Flue System

#### 3.04.1 Two pipe connection

Two separate ducts Ø80 for air intake and flue gas discharge can be directly connected to the boiler. For conversion to top outlet (see 3.05) mount the separate outlet kit ①

**Insert blanking plate ②  
in remaining air intake**




Fig. 16

Connect flue duct to central hole Ø80 and air duct to left or right air intake hole Ø80. Insert blanking plate ② in remaining air intake.

A varied number of accessories for two pipe systems are available from Ferroli (ref. to page 17). Before installing your system please check via calculation table at 3.04.2 you are not exceeding the maximum permissible length for the appliance.

Notes on two pipe system installation:

When using the two pipe system the flue discharge pipe must have a 25mm air gap when passing through combustible materials.

Where the flue discharge pipe passes through the airing space of an airing cupboard it must be protected by a non combustible guard or expanded metal giving an annular air gap of at least 25mm.

Where the flue discharge pipe passes through a wall containing cavity insulation, a non combustible sleeve must be fitted. Additionally a gap of 25mm between the sleeve and the insulation should be provided by cutting back the insulation or packing loose fill bead insulation with mineral fibre.

Where the flue pipe is run through an unheated roof space it should be insulated with non combustible insulating material to prevent condensation. The flue pipe should be supported at intervals of not more than 1.8m and the support should be preferably below a joint.

#### 3.04.2 Two pipe flue system

##### • Calculating maximum permissible flue length.

The calculation method is based on a standard reference parameter (1 metre of horizontal air flue 80 diameter 80) for the maximum length permissible for all the pipes + fittings flow resistance coefficient. In other words, for all components and pipes in the different installation configurations (vertical or horizontal, air or flue, etc.) and for all the fittings, a flow resistance (reduction) equivalent to  $x$  metre of horizontal air induction pipe is indicated. For every boiler model a maximum pipe length is provided, expressed in  $n$  metres of horizontal air pipe. In this way, to calculate the length of a proposed 2 pipe air-flue system, add the flow resistance (reduction) in equivalent metres-air. For every component and fitting present in the system, and to check that the total is less than the maximum length the permissible for the boiler model.

**IMPORTANT:** the pipes and fittings flow resistance (reduction) have been summarised on the following pages. The flow resistance values written refer only to Ferroli pipes and fittings.

##### Calculation routine

1. Utilise the pipes and fittings flows resistance tables on the following pages and calculate the total flow resistance in metres-air, by adding the flow resistances of the components in the whole air-flue system, based on their position (vertical or horizontal, air inlet or flue outlet).

Please note that the same fitting, identified by a one code (i.e. 1 pipe diameter 80, code KWMA83A), can offer different flow resistances if positioned as air inlet or flue outlet, if placed vertically or horizontally.








**The flow resistance of the special two pipe flue-air adapters do not have to be included in the calculation as they are already included in the maximum length calculation.**

2. For the restrictors, please refer to cap. 3.04 to determinate the correct diaphragm.
3. Check that the total flow resistance calculated is less or equal to 45 metre, the maximum permissible for Temptra 30.



## 3.04.2 (continued)

Tab. 1 - Pipes and fittings reduction table

| Description        |   | Reduction   |            |          |            |
|--------------------|---|---|------------|----------|------------|
|                    |   | Air   |            | Flue     |            |
|                    |   | Vertical  | Horizontal | Vertical | Horizontal |
| Accessories<br>Ø80 | Male-female flue Ø80                                    |    | 1          | 1        | 2          |
|                    | Male-female bend 45° Ø80                                |    | 1,2        | 2,2      |            |
|                    | Male-female bend 90° Ø80                                |   | 1,5        | 2,5      |            |
|                    | Condensate flue outlet                                  |  |            | 3        |            |
|                    | Airwall terminal products of combustion Ø80             |  |            |          | 5          |
|                    | Air terminal of inlet protection Ø80                    |  | 2          |          |            |
|                    | Outlet flue air inlet for connection with split end Ø80 |  | 12         |          |            |

For further accessories please refer to:  
"Flue system manual for room sealed boiler"

Example of calculation for wall inlet/outlet  
with 2 pipe system  
maximum total flue length: 48 metres

Attention:

Resistance of flue restrictor (if req.) is included  
Remove the flue restrictor.

The flue and air pipes must have an inclination  
downward equal to 3% from boiler to outside.




Fig. 17

| REF.  | N° OF PIECES | DESCRIPTION                   | CODE | LENGTH OR REDUCTION |
|-------|--------------|-------------------------------|------|---------------------|
| 1     | 1            | Air bend 80 mm R/D = 0,75     |      | 1,5 m               |
| 2     | 13           | Horizontal air pipe           |      | 13,0 m              |
| 3     | 1            | Air wall terminal             |      | 2,0 m               |
| 4     | 1            | Air inlet closing flange      |      | —                   |
| 5     | 1            | Flue bend 80 mm R/D = 0,75    |      | 2,5 m               |
| 6     | 12           | Horizontal flue               |      | 24,0 m              |
| 7     | 1            | Air wall terminal outlet flue |      | 5,0 m               |
| TOTAL |              |                               |      | 48,0 m              |

### 3.04.3 Example of other installation with two pipe systems




Fig. 18

Example  
of roof inlet/outlet




Fig. 20

### 3.05 For installation (back flue connection)

For direct back flue connection it is necessary to use the optional kit, and it is required to alter the fan direction inside the boiler.

Follow carefully next procedure:

Remove fan by pulling off electrical connections. Pull off air pressure switch tubes from the air pressure switch remove 2 screws b. Rotate the fan downward to disengage it from the securing pin a.




Fig. 21a




Fig. 21b




Fig. 21c

Take off the four screws which fix the back plate on sealed chamber, remove and rotate the plate through 90° and fit it to the top of the boiler to cover the original flue outlet. Secure it in place with the four screws removed previously.

Fix with 4 screws the connections for concentric pipe A.




Fig. 21d

Remove fan mounting plate by undoing the three fixing screws d. Rotate the fan through 90° so that the fan nozzle points sideways. Secure the fan to the plate in the new position using screws in position c. Insert the fan adaptor and fix with screws provided. The spigot should be sealed with heat resistant silicone (not supplied).




Fig. 21e




Fig. 21f




Fig. 21g

Fix with the screws (b). Refit wiring connections to fan and air pressure switch tubes ensuring correct orientation. I.E. red tube to air pressure switch connection with red dot (+) and clear tube to air pressure switch connection with no paint marking (-).  
Fit the fan into the boiler rotating the front to engage with the pin a. Secure with the screws b.




Fig. 21h

## Drilling Template (Top Flue Application)

Select suitable mounting position for boiler, using the template mark flue outlet and boiler mounting points. Drill two 10mm holes 90mm deep to accept the wall plugs, fit wall plugs. Fit two special wall plugs on the wall as described in the fig. 10a. Fasten the wall bracket to the wall using two standard nuts (M8). Mount the boiler on the wall bracket and fix using two standard nuts (M8) o. Using a core drill cut a 118mm diameter hole for the flue.




Fig. 2a

1. CH flow (22 mm)
4. Gas supply (22 mm)
6. CH return (22 mm)





Fig. 22b



### Back flue outlet (Diagram 1-7)

- 1. Core drill 127mm diameter hole as detailed above.**





Fig. 23a

- 2. Push outer flue through wall.**




Fig. 23b

- 3. Gently pull back the flue until the wall seal is flush.**





Fig. 23c


- 4. Cut outer flue pipe as per dimensions shown above.**



80mm

Fig. 23f

- 5. Insert inner flue pipe through outer flue pipe & ensure correct location into wall terminal. Cut inner flue pipe 60mm longer than outer flue as per diagram opposite.**



80 mm

60 mm

Fig. 23g

- 6.** Before mounting boiler remove fan assembly as per fig. 21a page 19.  
Lift the appliance on to the hanging bracket ensuring the outer is engaged correctly.




Fig. 23h

- 7.** Re-fit fan assembly to boiler ensuring the inner flue pipe is located correctly at both terminal and fan spigot (Secure appliance using fixings supplied).




Fig. 23i

### 3.06 Connecting the central heating

Connect to the relevant connections as indicated in fig. 1.

Connect the pressure relief valve discharge pipe (15mm) to the outside of the building, where possible over a drain. The discharge must be such that it will not be hazardous to occupants and passers-by or cause damage to external electric components or wiring. The pipe should be directed towards the wall.

To ensure long life, the heating circuit should be correctly sized and fitted with all the controls necessary to ensure correct functioning and operation. The differential between the boiler flow and return pipes should not be more than 20°C. You are advised not to use the boiler with return temperatures of less than 50°C in order to prevent patches of condensation forming and having a corrosive effect on boiler components.

### 3.07 Water treatment

if water treatment is used Ferroli Ltd recommend only the use of Fernox or Sentinel water treatment products, which must be used in accordance with the manufacturers instructions. For further information contact:

Fernox Manufacturing Co. LTD.  
Cookson Electronics, Forsyth Road  
Woking, Surrey, GU21 5RE  
Tel. 0870 8700362

Sentinel Division  
Betz Dearborn LTD  
Widnes, Cheshire WA8 5351  
Tel. 0151 424 5351

**Note** - If the boiler is installed in an existing system any unsuitable additives must be removed by thorough cleansing.

All systems should be cleansed according to B.S. 7593.

**Note** - In hard water areas treatment to prevent lime scale may be necessary.

**Note** - It is important that the correct concentration of the water treatment product is maintained in accordance with the manufactures instructions.

### 3.08 Filling

When cold, system pressure should be about 1 bar. If while running venting off of air dissolved in the water causes the pressure of the central heating system to drop below 0,5 bar, the user must utilise a filling loop to bring it back to the original value. During operation, water pressure in the boiler when hot should be about 1.5 - 2 bars. After filling, always close and disconnect the filling loop.

**Note** - If there is a possibility of air pockets forming in certain points of the central heating system flow and return pipes, you are recommended to fit an air vent valve at these points.

**Note** - When the boiler is installed below the level of the central heating a system, single check valve should be fitted in the flow to prevent gravity circulation around the heating system.

### 3.09 Gas connection

Gas connection should be carried out using a rigid pipe.

The flow at the gas meter should be sufficient for the simultaneous use at full gas rate of all appliances connected to it. Connect the gas supply to the boiler according to current regulations. The diameter of the gas tube leaving the boiler is not the determining factor in choosing the diameter of the pipe between the appliance and the meter. This must be selected in relation to length and pressure drop and in any instance should not be less than 22mm.

**The whole of the gas installation including the meter should be inspected and tested for soundness and purged in accordance with BS6891-1988.**

**N.B.** - The filling loop will be fitted by the installer in accordance with water by laws at the time of installing the system. **It is NOT a part of the boiler.**

### 3.10 Electrical connection

The boiler must be connected to a single phase 230 V 50 Hz electricity supply with a 3 A max. fuse and a bipolar switch with contact opening of at least 3 mm fitted between the boiler and the electricity supply. The boiler must always be connected to an efficient earth installation. Under the electrical box, there is a 3 pole terminal board for connecting the boiler to the mains (230 V 50 Hz) and a 2 pole board for connecting a room thermostat (RT). To connect, undo the screws fixing the terminal board box and connect the wires, ensuring correct polarity of the terminals. It should be noted that there is low voltage (24 V) between the room thermostat contacts.

When the boiler is connected to an electricity main, it is essential TO OBSERVE CORRECT POLARITIES (LIVE: brown cable, NEUTRAL: blue cable, EARTH: yellow-green cable).

All wiring must conform to current I.E.E. regulations.

**Note:** If the power supply cable has to be replaced, use "0.75mm (24/0.20) heat resisting cable only to BS6500 with a maximum external diameter of 8 mm.

**Note** - When connecting a room thermostat or external timer, do not link the power supply of these devices to the switching contacts. The switch contacts must be voltage free. Any mains powered devices must utilise mains power solely to drive the timer motor.

**Applying mains voltage to the switch contacts will irreparably damage the circuit board.**

Although this boiler can also be used without a room thermostat, you are recommended to install one for the following reasons:

Greater comfort conditions due to more accurate control of room temperature.

Greater energy savings.

### 3.11 Differential air pressure switch (fig. 2 - part 43)

The differential air pressure switch is a safety device which allows the main burner to ignite only after having verified that the fan is working correctly. If the difference in pressure between the flue gas discharge pipe and the air intake pipe is not at least equal to the minimum pressure switch calibration value, the pressure switch contacts do not close and the gas valve is thus prevented from opening.

In addition, the electrical circuit of the boiler is designed so that if for any reason the air pressure switch contacts remain closed when the fan stops, the burner will not start up again.

### 3.12 Checks

Fill the central heating system as described previously (3.10) and check there are no leaks in the water circuits. Check that there are no gas leaks on the boiler or the supply to the boiler. Also check that the electrical connections are correct.



### 3.13 Installing a room thermostat (72) (fig. 34) and external controls

To connect external controls:



Open the electrical wiring box, connect switched line from external controls to terminal 2 (remove factory link wire if fitted).



**Tempra 30 "S" Plan**



## Tempra 30 "Y" Plan



### 3.14 Ferroli Tempra boiler time clock fixing (optional) (EIRE only)

- Remove outer case by removing two securing screws from the rear bottom corners and lift off.
- Remove screw securing fascia panel and swing fascia panel down.
- Remove rear cover from fascia.
- Remove clock blanking plate from the boiler fascia panel.
- Mount clock into fascia panel using two screws and spacers provided.
- Take the black cable containing the blue and brown wires and connect the loose spades to clock terminals 1 & 2.
- Connect the plug end of the cable to terminal X2 of main circuit board.
- Remove the connector link from the 2 wires located behind the clock position.
- Connect these to terminal 3 and 5 of the clock.
- Replace everything in reverse order.
- Please refer to page 48 of User manual for use of time clock

Note: this option is not suitable for the U.K. building regulations.

## Existing wiring





Fig. 25a

### Wiring for integral clock and/or external controls



**External control  
i.e. Room Stat or  
programmable  
room thermostat**

Fig. 25b

---

## 4. COMMISSIONING AND TESTING

---

### 4.01 Checks to be carried out before starting up for the first time

When starting the boiler up for the first time check:

- that the gate valves between the boiler and central heating systems are open;
- that the central heating system is filled and vented;
- that there are no gas or water leaks from the central heating system or boiler;
- that the electric connections are correct and the earth wire of the boiler is connected to an efficient earthing installation and a 3amp. fuse is fitted to the isolator;
- that there are no flammable liquids or materials near the boiler;

### 4.02 Starting up the boiler

- Open the gas cock upstream of the boiler.
- Vent air present in the pipe upstream of the gas valve.
- Turn on electrical supply to the boiler.
- Rotate the ON-OFF RESET switch (fig. 2 - part 98) into the ON position.
- Check inlet working gas pressure, burner pressures and gas rate.

Turn the knob 63 (fig. 2) to the "Winter" position. Set the knob above 50°C and set the room thermostat (if fitted) to maximum. The burner ignites and the boiler starts to function automatically, controlled by its control and safety devices.

In "Summer" position is always shut down.

**Note** - If after completing the start-up procedure correctly, the burners fail to ignite and the boiler shut down warning lights up, wait about 15 seconds then rotate the knob 98 (fig. 2) against spring pressure to the RESET position and release it. The reset electronic control unit will repeat the start-up cycle.

**Note** - In central heating mode after resetting the boiler will go into it 2 minue delay before starting up again. If after a second attempt the burners still fail to ignite, consult the paragraph "Troubleshooting".

**Note** - If there is a power failure while the boiler is in operation, the burners automatically go out and re-ignite when the power returns.

### 4.03 Shutting down

Close the boiler isolation gas cock and turn off the electricity to the boiler.

**Important:** If the boiler is not to be used for lengthy periods during the winter, to avoid frost damage, you are recommended to drain the water from the circuits (domestic hot water and central heating). Alternatively, drain the domestic hot water system only and add special anti-freeze to the central heating system.

### 4.04 Checks and controls after first start-up

- Check there are no leaks in the gas and water circuits.
- Check correct boiler start up by carrying out start up and shut down tests using the boiler stat.
- Check the integrity of the air-flue pipes during boiler operation.
- Check that the gas consumption indicated on the meter corresponds to that given in Technical Data (page 5).
- Check that water is circulating correctly. Balance the radiators to ensure that the flow and return differential does not exceed 20°C.
- Check that the gas valve modulates correctly during the central heating phase.
- Determine the combustion efficiency and the composition of the flue gases (refer to 6.04)
- If any of the above are not correct refer to Technical Data (page 5). Adjustment (refer to 5) and Fault finding.

## 5. ADJUSTMENT AND GAS CONVERSION

### 5.01 Adjusting the pressure and flow rate to the main burner



This boiler operates on the flame modulation principle. It has two fixed pressure values, minimum and maximum, which must be as shown in the table (pages 5), whichever type of gas is used.

**Note** - Because correct minimum and maximum pressures are critical to the efficient operation of the boiler it is **ESSENTIAL** that the following adjustments are carried out by **COMPETENT** personnel **ONLY**.

### 5.02 Adjusting minimum and maximum pressure Honeywell V K4105G gas valve

- Connect suitable pressure gauge to burner test point "B" downstream of the gas valve.
- Disconnect the pressure compensation tube «F».
- Remove the protective cap «C».
- Adjust potentiometre **P3** (on the main board) at minimum (clockwise).
- Operate boiler for central heating
- Adjust minimum pressure by rotating screw «D» clockwise to reduce pressure and anticlockwise to increase pressure.
- Adjust potentiometre **P3** at maximum (anticlockwise)
- Adjust max pressure by rotating screw «E», clockwise to increase pressure and anticlockwise to reduce pressure.
- Reconnect the pressure compensation tube «F».
- Replace protective cap «C».

**Maximum + Minimum possible gas pressures are now set. Range Rating the central heating is not necessary (see paragraph 5.04).**




#### Key

- A = Gas inlet test point
- B = Gas outlet test point
- C = Protection cup
- D = Min. pressure adjusting screw
- E = Max. pressure adjusting screw
- F = Balancing tube

Fig. 26

### 5.03 Adjustment potentiometers



P1 = C.H. temperature adjustment  
P2 = Factory set - Don't touch  
P3 = C.H. output adjustment  
P4 = Ignition gas pressure adjustment  
P5 = Factory set - Do not adjustment

Fig. 27

### 5.04 Adjusting maximum output for central heating system (fig. 27)

This adjustment must be carried out electronically using the "P3" adjustment screw starting with a cold central heating system. Connect a pressure gauge to the pressure test point downstream of the gas valve. Rotate the temperature adjustment screw to maximum then regulate the pressure to the value required, consulting the diagram (figs. 4 ). Once this operation is complete, start up and shut down the burner two or three times using the thermostat. Check each time that the pressure values remain as adjusted and that the burner ignites correctly. Otherwise further adjustment is necessary until the pressure remains stable on this value.

**N.B. - when carrying out this operation ensure that the boiler thermostat is set to maximum otherwise the adjustment will not be accurate.**

### 5.05 Adjusting central heating flow temperature

Central heating water temperature is adjusted by rotating the control knob (fig. 2 - part 63). Rotate the knob clockwise to increase water temperature, anticlockwise to reduce water temperature. Temperature can be varied from a minimum of 30°C to a maximum of 85°C. However, we recommend not operating the boiler below 50°C.

### 5.06 Adjusting room temperature (when a room thermostat is fitted)

Room temperature is controlled by positioning the room thermostat knob to the required value. The thermostat automatically controls the boiler, temporarily interrupting the electrical supply subject to the room heat requirements.

### 5.07 Adjusting the central heating flow t by varying pump flow-head

The thermal head t (the difference in temperature between the delivery water and return water in the central heating circuit) must be less than 20° C. This is obtained by varying pump flow rate and head using the multi-speed variator (or switch) on the pump itself. Increasing the pump speed reduces t and vice versa. The minimum differential must not be less than 11°C.

### 5.08 Adjusting central heating system pressure

The pressure of water in the central heating system, read on the control panel pressure gauge, is adjusted as described in paragraph 3.07.

**N.B. - To avoid incurring unnecessary expense, in the event of boiler shut down, check that this is not caused by a lack of electricity or gas, or low water pressure before calling the Customer Technical Service Helpline.**

### 5.09 Gas conversion

The following adjustment and conversion operations must be carried out by competent personnel. FERROLI Limited accepts no liability for damage to property or personal injury resulting from tampering with the boiler by unauthorised persons.

To convert the boiler from Nat Gas to LPG and vice versa, the main burner injectors must be replaced. Minimum and maximum pressures must then be adjusted on the gas valve (see Adjustment page 23).

**Note: After converting the boiler from natural gas to liquid gas, fit the orange plate in the conversion kit near the data plate.**

**Note: injector diameters and pressures at the main burner are given in Technical Data (page 5).**

---

## 6. MAINTENANCE AND CLEANING

---

The following operations must be carried out by Corgi registered engineers only.

### 6.01 Annual Servicing

The following should be checked at least once a year:

- Water pressure in the central heating system when cold should be about 1 bar. If this is not the case, bring it back to this value.
- Check control and safety devices (gas valve, flow meter, thermostats, etc) are functioning correctly.
- The burner and heat exchanger must be clean. To avoid damage, always clean them with a soft brush or compressed air. Never use chemical products.
- The expansion vessel must be checked (precharge 1 bar).
- Check there are no leaks in the gas and water circuits.
- Check the air-flue gas duct terminal is free from obstructions and sound.
- The electrodes must be free from corrosion build up and correctly positioned.
- Gas flow and pressure must correspond to the values given in the Technical Data (page 5).
- The pump must be free to rotate.

### 6.02 Cleaning the boiler and burner

The boiler should be serviced annually. The heat exchanger and burner must never be cleaned with chemical products or steel brushes. Particular attention must be paid to all seals and fixings associated with the room-sealed compartment (gaskets, grommets, etc). Air leakage would cause pressure inside the compartment to drop, possibly tripping the differential pressure switch and thus shutting down the boiler. After cleaning particular attention should also be paid to checking stages of start-up and operation of the thermostats, gas valve and pump.

### 6.03 Servicing procedure

1. Visually check boiler for correct installation and flueing.
2. Isolate electricity supply + check fuse is 3amp.
3. Remove case by undoing the two screws located at the bottom rear corners, lift slightly and pull forward.
4. Carry out preliminary electrical checks at boiler junction box. This is located in the centre of the boiler at the bottom and can be accessed by the removal of a single screw. Any faults found must be rectified before proceeding.
5. If electrical checks prove O.K. replace cover and secure with screw.
6. Attach a manometer to the boiler gas inlet test point, turn on electricity and fire boiler for hot water, check inlet pressure. This should be 20mbar **minimum** for NG and 37mbar for LPG. If this is not the case there is a supply problem and this will need to be remedied.
7. If inlet pressure is O.K. shut down boiler and remove manometer from gas inlet pressure test point and attach it to the boiler burner pressure test point. Reseal inlet pressure test point.
8. Fire boiler for hot water and check that the maximum pressure is 13.0 mbar for NG and 35.5 mbar for LPG. Turn off tap. Turn P3 on the main circuit board to minimum and fire the boiler for heating, check that the burner pressure reads 2.5 mbar for NG and 7.0 mbar for LPG. Turn P3 back to max position. Shut down boiler, remove manometer, seal test point. If the pressures are not as specified they will need to be adjusted on the gas valve (see page 23 - installation manual).
10. Remove fan by undoing the two fan securing screws tilt the front of the fan upwards (downwards for rear outlet flue) to detach it from the securing pin and withdraw it from the boiler, disconnect the wires and air pressure switch tubes.
11. Take off the combustion chamber cover by removing the three securing screws.
12. Lift off flue hood and flue baffle plate.
13. Pull off the ignition and flame rectification leads from their respective electrodes.
14. Undo the gas union in the centre of burner rail and take out the two securing screws. Remove the burner rail and clean rail and injectors.
15. Remove two screws securing the burner assembly and remove the assembly. Clean burners.
16. Clean heat exchanger with a soft brush.
17. Re-assemble baffle, flue hood and fan assembly, secure with screws previously removed.
18. Refit burner assembly and burner rail.

19. Reconnect ignition and flame rectification leads.
20. Reconnect gas union and tighten.
21. Refit combustion chamber cover, secure with screws.
22. Examine seals on room sealed cover refit cover and secure with screws.
23. Turn on gas and electricity.
24. Fire boiler and check all gas joints for soundness.
25. Check flame picture and all controls for correct operation.
26. Check room sealed cover for leakage.
27. Check operation of all safety cut off devices.
28. If a combustion analyser is to be used there are test points provided on the front of the room sealed cover. The right hand grommet is for air and the left hand one is for flue gas. The boiler must reach operating temperature before this test is carried out (normally 10-15 minutes). CO/CO<sub>2</sub> ratio should not exceed 0.0080. Immediately after servicing (0.0040 at any other time)
29. Refit case and secure with screws.
30. Leave boiler set to customers requirements.

#### 6.04 Flue Gas Analysis

1. The appliance should be checked visually for obvious defects.
2. After removing the jacket on the boiler there are two test point, one for flue gas and the other for air.
3. Open the air and flue gas test points;
4. Introduce the probes as far as the retainer;
5. Turn on the hot water tap;
6. Turn the domestic hot water stat to maximum;
7. Allow the boiler to reach thermal equilibrium (10 - 15 min.);
8. Take reading;
9. The CO/CO<sub>2</sub> ratio should be 0.0040 or below. If the reading is above this then a full strip down service must be carried out and the cause remedied.
10. Following a full strip down service and after reaching thermal equilibrium the permissible reading is 0.008 or below.

**N.B.:** To ensure correct readings the boiler **must** have reached **normal operating temperature**. Testing the boiler **before thermal equilibrium** has been attained **will give incorrect readings**.

**N.B.:** If you have only 1 probe, measure separately air and flue gas, close the test point not in use.



Fig. 28



## 7. REMPLACEMENT OF PARTS

### 7.01 Initial procedure

- a) The boiler is cold, electricity supply is isolated, and the gas supply is turned off at the inlet of the boiler
- b) For replacement of parts where water connections are broken, it will be necessary to isolate and drain either or both the central heating or domestic hot water circuits of the boiler only. The cold water mains inlet is isolated at the inlet cock. The D.H.W. is drained by opening a hot tap.  
The C.H. flow and return cocks are turned off at the isolation cocks. The C.H. is drained via the pressure relief valve (twist about 1/2 of a turn).
- c) Remove components following special notice below and replace in reverse order.
- d) Ensure water and gas washers are in good condition.

### 7.02 Final procedure

- Re-open cocks and re-charge the system to about 1 bar, and vent boiler and radiators.  
Re-charge to 1 bar if necessary.
- Upon completion of the work the following. Should be checked:
  - I) Gas soundness of all joints
  - II) Water soundness of all joints
  - III) The electricity supply.
  - IV) The pressure of the sealed system and top up where necessary.

### 7.03 To lower the control panel (fig. 29)

- Remove the two fixing screw (fig. 29) "A"
- Rotate down the front panel "C"




Fig. 29

#### 7.04 Gas valve (fig. 30)

- Isolate gas and electricity supplies
- Remove outer case (two screws bottom rear corners)
- Remove the two securing screws and lower control panel
- Disconnect electrical connections from valve ("A")
- Disconnect plastic tube "C"
- Loosen the connection "D" on gas pipe and the gas inlet connection of the boiler "E"
- Remove the two fixing screw "E" below gas valve
- Slide out gas valve
- Remove four fixing screw "F" on top of the valve and disconnect the gas pipe
- Remove bottom connection from gas valve.
- Fit top + bottom gas connections to the new gas valve and replace in reverse order




Fig. 30

#### 7.05 Air pressure switch (fig. 31)

- Isolate electricity
- Remove outer case (two screws bottom rear corners)
- Open room sealed department
- Remove the two screw "A" fixing air pressure switch
- Disconnect electrical leads "B"
- Remove pressure sensing tubes (white=D; Red=C)
- Note relevant positions of all connections and replace in reverse order.




Fig. 31

#### 7.06.1 Central Heating Temperature Sensor (fig. 32)

- Isolate electricity and water supplies
- Remove outer case (two screws bottom rear corners)
- Remove the two securing screws and lower control panel
- Identify the sensor from figure 32
- Disconnect electrical connection to the sensor
- Drain the C.H.
- Unscrew the sensor
- Replace in reverse order

#### 7.06.2 Safety Valve (fig. 32)

- Isolate electricity and water supplies
- Remove outer case (two screws bottom rear corners)
- Remove the two securing screws and lower control panel
- Identify valve from fig. 32
- Drain the boiler
- Release the outlet union to the valve and undo the valve union connection
- Remove the valve outlet fitting
- Replace in reverse order




Fig. 32

### 7.07 Removal of burner (fig. 33)

- Isolate gas and electricity supplies
- Remove outer case (two screws bottom rear corners)
- Remove room sealed cover
- Disconnect ignition and flame rectification leads "A"
- undo gas rail union "B"
- Undo two screws securing the burner assembly to the boiler combustion chamber "D"
- Withdraw the burner assembly




Fig. 33

### 7.08 Injectors (fig. 33)

- Proceed as 7.07
- Remove fixing screw "C" on both sides of gas collector
- Remove gas collector
- Unscrew and remove injectors;
- Clear or change injectors

### 7.09 Removal of fan (fig. 34)

- Isolate gas and electricity supplies
- Remove outer case (two screws bottom rear corners)
- Remove room sealed cover
- Disconnect fan electrical leads "A" and note positions
- Disconnect air pressure tubes from air pressure switch "B" + note positions
- Undo two screws securing fan assembly "C"
- Remove fan from boiler
- Swap mounting plate over to new fan + replace in reverse order

### 7.10 Limit thermostat, or overheat cut off thermostat (fig. 34)

- Isolate electricity
- Remove outer case (two screws bottom rear corners)
- Remove room sealed cover
- Identify the location of thermostat from fig. 31
- Pull out thermostat from tube, with its spring
- Remove electrical connections from thermostat
- Remove spring from thermostat
- Replace in reverse order




Fig. 34

### 7.11 Spark or flame detect electrode (fig. 35)

- Isolate gas and electricity supply
- Remove outer case (two screws bottom rear corners)
- Open room sealed compartment and combustion chamber
- Identify electrode from fig. 32
- Unplug electrical connection "A" from sensing electrode
- Remove fixing screw and remove flame detect electrode
- Remove the two fixing screw from spark electrode plate and remove it.




Fig. 35

### 7.12 Pump (fig. 36)

#### Replacement of pump head

- Isolate electricity and flow and return pipes
- Remove casing (two screws bottom rear corners).
- Remove the two securing screws and lower control panel
- Release pressure from boiler via pressure relief valve
- Unplug the pump lead "A" from the pump head
- Place a piece of cloth or other absorbent material over the rear of the control panel to catch any drops of water that may fall when the pump head is removed.
- Using a 4mm allen wrench undo the four allen screws "B" in the pump head, lift away pump head from the pump body
- fit new head into pump body and secure with the allen screws tightening evenly.
- Replace electrical connection.




Fig. 36

#### Replacement of pump body (fig. 36)

- Proceed as for removal of pump head
- Disconnect the expansion vessel connecting pipe "E" from the rear of the pump body by removing the clip from the left hand side
- Disconnect the boiler return pipe
- Disconnect the pump to heat exchanger connection by removing the clip "F"
- Unscrew the nut on bottom of pump
- Turn the pump body through 90°, pull the bottom forward and withdraw the pump body
- Reassemble in reverse order taking care to ensure the O-rings are in place and undamaged.

### 7.13 Removal of heat exchanger

- Isolate gas, water and electricity supplies
- Remove casing (2 screws bottom corners)
- Remove the two securing screws and lower control panel
- Drain heat exchanger for both CH + DHW
- Remove sealed compartment front panel
- Disconnect the overheat thermostat and central heating limit thermostat
- Remove the main burner, fan, flue hood and flow meter as described previously
- Remove the pump to heat exchanger flow connection and locknut
- Undo the domestic water outlet connection and locknut
- Lift out heat exchanger
- Re-assemble in reverse order

## 8. FAULT FINDING

Before beginning any fault finding ensure that gas, water and electricity are available.

**WARNING:** DO NOT link any terminals on block X10 or X11 as this will damage the PCB beyond repair.

### 8.01 Operating Sequence

With the power established the boiler is in its stand-by mode i. e. power on but no demand. The operational sequence for C.H. and D.H.W. are as follows:

#### Central Heating Mode

**External Call for Heat:** The temperature regulator, built in or remote clock and room thermostat, if fitted, must all call for heat. This will cause the pump to run.

**Internal Call for Heat:** C.H. flow temperature sensor, 88°C high limit all calling for heat. If both external and internal calls for heat are present the PMF03 PCB will energise.

In demand the fan will go to high speed causing the air pressure switch to operate. If the overheat (100°C) stat is closed circuit the ignition will operate and the gas valve will be energised.

The burner will light at ignition burner pressure, automatically range rating itself up to the heating load, then modulating down when the boiler reaches the desired flow temperature. When the central heating is satisfied the burner will go off and the fan stops i.e. stand-by mode.

**Note** - If the boiler thermostat is set to maximum than the burner pressure will go to maximum effectively bypassing the auto range rating facility

### 8.02 Limit thermostats

| T/Stat            | Location                    | Function   | Nominal Operating Temperature | Circuit        | Wiring Colours |
|-------------------|-----------------------------|--|-------------------------------|----------------|----------------|
| <b>C.H. Limit</b> | Top RHS of Heat Exchanger   | Shuts down main burner if boiler thermostat fails                    | 88°C                          | Low voltage DC | Blue<br>Brown  |
| <b>Frost</b>      | Incorporated in C.H. Sensor | Fires the boiler and runs pump to maintain minimum water temperature | 7°C - 14°C                    | Low voltage DC | Red<br>Red     |
| <b>Overheat</b>   | Top LHS of Heat Exchanger   | Protect boiler by stopping ignition and cuts power to gas valve      | 100°C                         | 240V AC        | Brown<br>Blue  |

### 8.03 PMF03F PCB

The PMF03 PCB has five diagnostic lights, each light corresponds to a particular function and will light in turn as the boiler goes through its sequence of operations.

In order, the four lights indicate:

- 1 Boiler On Indicate
- 2 Boiler Shut down warning
- 4 Central heating standby (Flashing Light)  
Central Heating circuit ON (Permanent Light)
- 5 Insufficient pressure in Central Heating System (Flashing Light)  
Electric power supply ON (Permanent Light)

**Note:** Always check for sufficient gas supply (20mbar inlet working pressure for NG and 37mbar for LPG). Minimum of 22 mm diameter pipework on C.H. flow and return with adequate by-pass. A correctly installed flue system and a 3 amp fuse.

When operating the C.H. the following lights should be on: 4, 5 and flame on light.



#### **8.04 Temperature sensors (thermistors)**

Identical, but individual, negative temperature co-efficient (NTC) thermistors are fitted in the C.H. outlets from the heat exchanger. As the water temperature increases the resistance in the thermistor decreases. This causes the PCB to reduce the voltage to the modureg, in turn reducing the burner pressure. The wiring for each thermistor is colour coded red for C.H.. The sensors are fitted in wet pockets.

#### **8.05 Limit thermostats**

Two surface mounted auto reset bi-metal thermostats are located on the heat exchanger secured by spring clips. Heat sink compound is used.

#### **8.06 Ignition PCB**

Located to the right hand side of the electrical control compartment accessed by lowering the facia then removing the rear cover.

#### **8.07 Main printed circuit board**

Secured by four plastic tabs the PCB is situated inside the control compartment. The transformer for low voltage AC is attached to the PCB as is the DC rectifier. Potentiometers control C.H. output and maximum D.H.W. temperature, both are adjustable by the controls on the facia and because the boiler features automatic range rating no adjustments need to be made. Electro mechanical relays control pump operation and put switched live to the ignition PCB (demand relay), they have transparent plastic covers so that their contacts can be seen moving.

#### **8.08 Air pressure switch**

Operating at 230 V AC and situated next to the fan. Different coloured tubes connect the switch to the fan. It is a make on pressure switch and only uses two terminals, the middle terminal is not used.

## 9. ELECTRICAL AND FUNCTIONAL SCHEME

### 9.01 Main components layout on electronic boards

#### Potentiometer adjustment

**P1** = Central heating flow temperature adjustment

**P2** = Factory set; don't touch

**P3** = Central heating flow output adjustment

**P4** = Ignition gas pressure adjustment

**P5** = Factory set - Do not adjustment




Fig. 37

**JP01 ON** = Delay between shutdown and re-ignition disabled  
**JP01 OFF** = Delay between shutdown and re-ignition enabled

**JP02:**

☒ Jumper on for natural gas

☐ Jumper on for LPG

| Temp. sensor NTC (34) (42) | temp. | Ohm       |
|----------------------------|-------|-----------|
|                            | 10 °C | 20 kOhm   |
|                            | 25 °C | 10 kOhm   |
|                            | 60 °C | 2,5 kOhm  |
|                            | 80 °C | 1,25 kOhm |

## 9.02 General wiring diagram





Fig. 38



## 10. USER INSTRUCTIONS



| LED |  |  | KEY | DESCRIPTION                                 |
|-----|--|--|-----|---|
| 1   |  | Burner on indicator  | A   | Switch OFF/ON/RESET                         |
| 2   |  | Boiler shut down warning   | B   | Central heating flow temperature regulation |
| 4   |  | Central heating stand-by (Flashing light)                        | C   | Water pressure gauge                        |
|     |  | Central heating circuit on (Permanent light)                     |     |   |
| 5   |  | Insufficient pressure in central heating system (Flashing light) | D   | Time clock (option) (EIRE only)             |
|     |  | Electric power supply (Permanent light)                          |     |   |

Fig. 39

The boiler is designed for use with two types of gas: natural gas NG or propane (LPG). The type of gas can be selected when purchasing the boiler or the appliance can be converted later on site by a competent person. It operates with technologically advanced systems such as electronic control, safety and control devices.

The boiler is fitted with automatic electronic ignition so there is no pilot to worry about.

Pull down cover to reveal control fascia panel.

Make sure that the gas, water and electricity supplies to the boiler are turned on.

The boiler pressure gauge (D) should read at least 1 bar.

Low pressure will be indicated by flashing light in the middle of the facia illuminating ( $\triangle_{\text{bar}}$ ).



**Heating - "WINTER" ( ❄️ )**

To obtain heating from the boiler, turn the temperature regulator (B) clockwise to the "Winter" position, ensure that any other heating controls e.g. room thermostats, clock etc. are in the on position.

The boiler may be in heating delay of three minutes as indicated by the red light (egg timer symbol) on the left of the fascia panel. When this light goes out the green light (radiator symbol) will come on. The fan and pump will run and the burner will light indicated by the green flame symbol light. Adjust the temperature regulator to the desired setting. (In winter do not run boiler below 50°C).



### Boiler lock out

In the event of the red lockout light () coming on, the on/off/reset switch (A) should be turned clockwise against the spring tension to the reset position and released (this will put the boiler into three minute delay if in the heating mode). If the lockout light () illuminates repeatedly, contact an approved Ferroli service engineer.

### Frost Protection

In cold weather the boiler may appear to run when there is no demand for heating (i.e. clocks or room thermostats turned off). This is due to the central heating sensor going into frost protection mode. Once the boiler has reached 14°C or more it will close down until either the temperature again falls below 7°C or the clock or room thermostat is turned on.

For this reason we recommend that the electricity to the boiler is left turned on. If you wish to turn off the electricity to the boiler in winter you should drain completely the heating and hot water circuits.

### Cleaning

The casing requires no special cleaning, a wipe with a soft duster or damp cloth will suffice.

### Maintenance

Ferroli recommend that the appliance is serviced **at least once every twelve months** by a competent engineer.

### Gas Supply

It is the law that all gas appliances are installed and serviced by a competent person in accordance with the Gas Safety Regulations (Installation & Use) 1996, and the manufacturers instructions. Failure to observe these requirements may lead to prosecution.

### Electrical Supply

#### **WARNING - This appliance must be earthed.**

The electrical wiring must be carried out by a competent electrician.

The colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminal in the plug. Therefore, proceed as follows:

The wire coloured green and yellow must be connected to the terminal in the plug marked with either the letter E or by the earth symbol or coloured green or green and yellow. The wire coloured blue must be connected to the terminal marked either with the letter N or coloured black. The wire coloured brown must be connected to the terminal marked either with the letter L or coloured red.


### MINIMUM CLEARANCE

The minimum clearance around the appliance should be as follows:

|       |       |             |
|-------|-------|-------------|
| Sides | 5mm   |             |
| Front | 600mm |             |
| Below | 200mm |             |
| Above | 100mm | Top Flueing |

## Time Clock

A 24 hour single channel time clock can be fitted to the boiler to control the central heating, and hot water systems (EIRE only). this option is not suitable for the U.K. building regulations.



**A** Slide switch: set clock - auto - set programme

**B** Display. Symbol ☼ in Display = Timer ON

**P** Select programme ON/OFF 1.....8

**D** Push buttons Time + Time -

**E** Override: Boiler will switch ON if it is OFF; and OFF if it is ON

**F** I=Heating continuous - AUTO=Heating timed - O=Heating disabled

**R** Reset (with pencil) only with switch **A** in set clock position

### To set time of day

- Slide switch (**A**) to left position
- Using button + and - adjust until the correct time is shown on display (**B**).

**Pre Set Programmes.** The timer is pre programmed with 3 ON and 3 OFF times.

6:30 - 8:30  
12:00 - 12:00  
16:30 : 22:30

If these are suitable no programming is required and the slide switch (**A**) can be moved to the Auto position and the central heating will be ON for these periods.  
(12:00 - 12:00 will not switch on the boiler)

### To Set Own ON and OFF times. Symbol ☼ in Display = ON time

- Slide switch (**A**) to right position (**P**)

Display 6:30 1 ☼

- Press button (**P**)

Display 8:30 2

- Press button (**P**)

Display 12:00 3 ☼

- Press button (**P**)

Display 12:00 4

- Press button (**P**)

Display 16:30 5 ☼

- Press button (**P**)

Display 22:30 6

- The timer can be programmed with up to 8 ON and 8 OFF times by repeating the above procedure.

- 1.1 Use buttons + and - to set 1st ON time eg. 6:00

Display 6:00 1 ☼

- 2.1 Use buttons + and - to set OFF time, eg. 9:00

Display 9:00 2

- 3.1 Use button + and - to set 2nd ON time, eg. 12:30

Display 12:30 3 ☼

- 4.1 Use button + and - to set 2nd OFF time eg. 14:00

Display 14:00 4

- 5.1 Use button + and - to set 3rd ON time, eg. 16:00

Display 16:00 5 ☼

- 6.1 Use button + and - to set 3rd OFF time eg. 23:30

Display 23:30 6

8. On completion of programming slide switch (**A**) to Auto position, the time of day will be displayed and the central heating will switch ON and OFF according to the programme set.

### Over ride

By pressing the over ride button (**E**) the timer programme is over ridden ie, if programme is in OFF time it will come ON and if in ON time will go OFF.

The timer will revert back to it set programme on reaching the next ON or OFF time.

When the programme is on over ride the sign ⌂ will be shown in the display window (**B**).

### Reset Button

By the use of a pencil the reset button can be pushed (**R**). This will clear all programmes apart from those factory pre set.

**Reset is only possible with switch (A) in set Clock position!**

Phone numbers:

Installer \_\_\_\_\_

Service Engineer \_\_\_\_\_

**BECAUSE OF OUR CONSTANT ENDEAVOUR FOR IMPROVEMENT DETAILS  
MAY VARY SLIGHTLY FROM THOSE QUOTED IN THESE INSTRUCTIONS.**



**ALL SPECIFICATIONS SUBJECT TO CHANGE**

**Please note** - to avoid incurring unnecessary expense, in the event of a boiler shut down, check this in not caused by lack of electricity supply, gas supply or low water pressure before calling our Customer Service Helpline.

**Lichfield Road, Branston Industrial Estate, Burton Upon Trent, Staffordshire DE14 3HD  
Tel. 08707 282 885 - Fax 08707 282 886**

---


# **TEMPRA 30**

System or open vent applications



## **REAR FLUE INSTALLATION AND WIRING INSTRUCTIONS**

# TEMPRA 30



## Back flue outlet (Diagrams 1 to 7)

1. Core drill 127mm diameter hole as detailed above.




Fig. 22a

2. Push outer flue through wall.




Fig. 22b

3. Gently pull back the flue until the wall seal is flush.




Fig. 22c

4. Cut outer flue pipe as per dimensions shown below.




Fig. 22f

5. Insert inner flue pipe through outer flue pipe & ensure correct location into wall terminal. Cut inner flue pipe 60mm longer than outer flue as per diagram opposite.




Fig. 22g

# TEMPRA 30

6. Before mounting boiler remove fan assembly as per fig.21a page 19 of the installation manual.

Lift the appliance on to the hanging bracket ensuring the outer flue is engaged correctly.




Fig. 22h

7. Re-fit fan assembly to boiler ensuring the inner flue pipe is located correctly at both terminal and fan spigot. (Secure appliance using fixings supplied)






Fig. 22i

# TEMPRA 30



## Tempra 30 'S' Plan





# TEMPRA 30

## Tempra 30 'Y' Plan



# TEMPRA 30

## 9.02 General wiring diagram




Fig. 40